LOCATION OF THE NUMBER AS STANDARD

The serial numbers of the frame and/or motor are they use to enrol the moticiota. It was also used help 6 your dealer when ask for parts or to refer to information about special service.

The frame number () is stamped on the head tube. The engine number it's stamped on the crankcase.