Operation of O turn signals) Position "R" - for right wing turn spin sens Position "L" - for left wing turn signals.

SPEAKER SWITCH (2) Press this switch to sound the horn