A spark plug heavily curboned or otherwise feuled will not produce strong starting. Remove curbon deposits with a feet or a pop and edjust the spark plug gap to 0.5 0.7 that 10074 - 0.025 int by measuring with a chickness gauge.

D8EA *DR8ES-L	X24ES-U *X24ESR-U	Estándar
D9EA *DR8ES	X27ES-U *X27ESR-U	Si la bujía estándar está muy blanca o vidriada en apariencia, cámbiela por está bujía.

^{...} Para Alemania