Tools To assist you in maintenance loreslization. sen supplies a set of tools. which is located under the seat,