

LOCALIZACION PIEZAS

DE LAS

- 1 Palanca de embrague
- 2 Interruptores del manillar izquierdo
- 3 Velocimetro
- 4 Interruptor de encendido
- (5) Tacómetro
- 6 Interruptores del manillar derecho
- Tempuñadura del acelerador
- B Palanca del freno delantero

LOCATION OF Parts

- O Clutch lever
- D left-hand stun switches. (Or speedometer
- Q power switch.
- O Tacometer
- (Or right handlebar switches. Or Throttle slam.
- (0 Front brake lever.

The