## INSPECTION AND MAINTE-NANCE

## MAINTENANCE SCHEDULE

At the end of each service interval, be sure to inspect, check, fubricate and service as instructed. If your vehicle is used under high performance conditions, certain service should be performed more often to incure the reliability of the machine.

- (4) Al aumenar la velocidad, cambie a una marcha superior. Cierre el acelerador y apriete la palanca del embrague simultáneamente. Levante la palanca de cambio de marchas hacia arriba. Libere suavemente la palanca del embrague y abra de nuevo la empuñadura del acelerador.
- (5) Cierre el acelerador, apriete la palanca del freno delantero y presione suavemente el pedal del freno trasero al mismo tiempo. La motocicleta desacelerará suavemente.