MARK POSITION INDICATION (6) The gear position indicator indicates the posi- marches.

GIRO SIGNAL INDICATION LIGHT 6) The turn-turning sign indication light is turned on. Will you know when the turn marks are used.

## REVOLUTIONS (2)

The rev counter indicates the speed of the engine at revs per minute (rpm, The engine I must accelerate to the red zone under none