_ Light intensity regulator operation (4) Position "HI" - for long ring light. Position "LO" for overtaking light

"Operation of overtaking light E) 'Pushing the operation switch of the lights further down the "LO" position will cause it to be hundredth the fro.