

Remote ID, in plain language

Remote ID is a broadcast. A cooperative aircraft tells nearby receivers who it is and where it is. Fusion Sensor puts that broadcast on a map. Aircraft that are not broadcasting, or that have Remote ID off, do not appear as Remote ID contacts.

What you can say

You can say what the sensors heard: a Remote ID track, radio energy on 2.4 or 5.8 GHz, ADS-B for crewed traffic. Authorized aircraft are marked as authorized. Other transmitting aircraft are flagged.

What you cannot say

You cannot say the air is empty of drones from Remote ID alone. Quiet is not a clearance. Analog FPV and some RID-off aircraft will not give you a cooperative identity.

If something goes wrong

The remote PIC reports to the FAA within ten days when there is serious injury, loss of consciousness, or property damage over \$500 that is not the aircraft (14 CFR 107.9). 911 first. Then the file.

How to run a monitoring session

1. Name the place and the hours. Put the laptop where it can see the sky and receive 2.4 / 5.8 GHz.
2. Load the authorized-aircraft list before you go live. Any other transmitting aircraft is flagged.
3. Keep ADS-B on so crewed traffic is on the same map.
4. When an unauthorized contact appears, hold it. Do not auto-clear. Write time, band, and who you told.
5. Export the log at close. That is the record.

Hardware for Fusion Sensor

Laptop. ESP32-S3 Remote ID receiver. ADS-B 1090. SDR on 2.4 and 5.8 GHz. Antennas, USB, power. Fusion Sensor is receive-only. It identifies what is transmitting; it does not jam, spoof, or intercept aircraft.

Size-up when a drone is in the problem

LOOK	DONE
Scene: people under the aircraft, manned traffic, TFR	☐
Life safety: who is at risk if it comes down	☐
Abort: land if you are the PIC and the box is gone	☐
Handoff: 911 sentence, named contact, last heading	☐
Battery: heat, odor, vent — exclusion, water to cool	☐
Do not chase a flyaway into a TFR or into people	☐

This pack is awareness training. It is not a Part 107 course and it is not a license to transmit. CyberReaper TX unlock is briefing-only for qualified entities.