USB Connection

Original Handwheel

Atmega for Handwheel

Analoge Sensoren

Microcontroller

Inputs

5V Power

I2C Atmega

ICSP Atmega

FogPulse PWM Out

Programming

Freq Pulse counter input

OCS2 Controller connector

Handwheel Select

STEP / DIR Connections

OCS2.0
Controller Module