




Figure 001 / 53-00-00 (SHEET 1) - Fuselage - Section Division






Figure 002 / 53-00-00 (SHEET 1/2) - Fuselage - Main Panel and Section Configuration



NOTE:
ALL STA DIMENSIONS ARE GIVEN IN mm.

N_SR_330002_3_SAC0002_01_01


Figure 003 / 53-00-00 (SHEET 1) - Frame and Station Numbers



NOTE:
ALL STA DIMENSIONS ARE GIVEN IN mm.

N_SR_530000_5_6ACA000A_01_00

Figure 003 / 53-00-00 (SHEET 1) - Frame and Station Numbers



N_MM_063000_0_AAM0_01_01

Figure 06-30-00-11700-00-A (SHEET 1) - Typical Arrangement of Stringers on the Frames
**** ON A/C FSN ALL**