Lumora S7 Robot Vacuum

What's in the box

The Lumora S7 ships with the robot, a charging dock, two side brushes, one HEPA filter (pre-installed) and a power cord.

Battery and runtime

The S7 uses a 5200 mAh lithium-ion battery. Runtime is up to 180 minutes in Eco mode, 120 minutes in Standard mode and 75 minutes in Max mode. A full charge from empty takes about 4 hours.

Setup and app pairing

Install the Lumora Home app on iOS or Android and create an account. The S7 only supports 2.4 GHz Wi-Fi networks; 5 GHz networks are not supported.

To enter pairing mode, hold the Power and Home buttons together for 3 seconds until the light ring pulses orange. Then follow the steps in the app.

Cleaning modes and specifications

Specification	Value
Suction (Eco / Standard / Max)	1500 / 3000 / 5500 Pa
Dustbin capacity	450 ml
Noise level (Standard)	58 dB
Weight	3.6 kg

Spot mode cleans a 1.5 m x 1.5 m square around the robot.

Maintenance

Clean the main brush once a week. Replace the HEPA filter every 3 months and the side brushes every 6 months.

Factory reset

To restore factory settings, hold the Home and Spot buttons together for 10 seconds until the light ring flashes blue. A factory reset erases saved maps and Wi-Fi settings.

Safety

Do not use the S7 on wet floors or outdoors. The operating temperature range is 0 to 40 °C. Keep the cliff sensors clean so the robot can detect stairs.