Writing Low-Power Applications

From TinyOS Wiki

This lesson demonstrates how to write low power sensing applications in TinyOS. At any given moment, the power consumption of a wireless sensor node is a function of its microcontroller power state, whether the radio, flash, and sensor peripherals are on, and what operations active peripherals are performing. This tutorial shows you how to best utilize the features provided by TinyOS to keep the power consumption of applications that use these devices to a minimum.

Contents

- 1 Overview
- 2 Peripheral Energy Management
- 3 Radio Power Management
- 4 Microcontroller Power Management
- 5 Low Power Sensing Application
- 6 Related Documentation

Overview

Energy management is a critical concern in wireless sensor networks. Without it, the lifetime of a wireless sensor node is limited to just a few short weeks or even days, depending on the type of application it is running and the size of batteries it is using. With proper energy management, the same node, running the same application, can be made to last for months or years on the same set of batteries.

Ideally, one would want all energy management to be handled transparently by the operating system, relieving application developers from having to deal with this burden themselves. While attempts have been made in the past to provide such capabilities, most operating systems today still just provide the necessary primitives for performing energy management -- the logic of when and how to do so is left completely up to the application.

TinyOS provides a novel method of performing energy management directly within the OS. The method it uses is as efficient as it is elegant. Developers no longer have to struggle with code that explicitly manages the power state for any of the peripheral devices that it uses. To get a better idea of the complexity involved in doing something as simple as periodically taking a set of sensor readings and logging them to flash in the most energy efficient manner possible, take a look at the pseudo code found below.

Every Sample Period: Turn on SPI bus Turn on flash chip Turn on voltage reference Turn on I2C bus Log prior readings Start humidity sample Wait 5ms for log Turn off flash chip Turn off SPI bus Wait 12ms for vref Turn on ADC Start total solar sample Wait 2ms for total solar Start photo active sample Wait 2ms for photo active Turn off ADC Turn off vref Wait 34ms for humidity Start temperature sample Wait 220ms for temperature

With the methods provided by TinyOS, hand-tuned application code that looks like that can be transformed into this:

Every Sample Period: Log prior readings Sample photo active

```
Sample total solar
Sample temperature
Sample humidity
```

The pseudo code shown above is for concurrently sampling all of the the onboard sensors found on the latest revision of the tmote sky sensor nodes. Experiments have shown that using the methods provided by TinyOS, this application comes within 1.6% of the energy efficiency of the hand-tuned implementation -- even at sampling rates as fast as 1 sample per second. For more information on these experiments and the method TinyOS uses to actually manage energy so efficiently, please refer to the paper found here. (http://www.klueska.com/pubs/klues07sosp.pdf)

The rest of this tutorial is dedicated to teaching you how to write applications that allow TinyOS to manage energy for you in the most efficient manner possible. As a rule, TinyOS can manage energy more efficiently when I/O requests are submitted by an application in parallel. Submitting them serially may result in energy wasted by unnecessarily turning devices on and off more frequently than required.

Peripheral Energy Management

Compare the following two code snippets:

Parallel Serial

```
event void Boot.booted() {
                                                                 event void Boot.booted() {
  call Timer.startPeriodic(SAMPLE PERIOD);
                                                                   call Timer.startPeriodic(SAMPLE_PERIOD);
event void Timer.fired() {
                                                                 event void Timer.fired() {
  call LogWrite.append(current_entry, sizeof(log_entry_t));
                                                                   call Humidity.read();
  current_entry_num = !current_entry_num;
  current_entry = &(entry[current_entry_num]);
                                                                event void Humidity.readDone(error_t result, uint16_t val) {
  current entry->entry num = ++log entry num;
                                                                  if(result == SUCCESS) {
                                                                     entry->rad = val;
  call Humidity.read();
  call Temperature.read();
                                                                   else current_entry->rad = 0xFFFF;
  call Photo read();
                                                                   call Temperature.read();
  call Radiation.read():
                                                                 event void Temperature.readDone(error_t result, uint16_t val) {
levent void Humidity.readDone(error t result, uint16 t val) {
                                                                   if(result == SUCCESS) {
  if(result == SUCCESS) {
                                                                     entry->rad = val:
   current_entry->hum = val;
                                                                   }
                                                                   else current entry->rad = 0xFFFF:
  else current_entry->hum = 0xFFFF;
                                                                   call Photo.read();
event void Temperature.readDone(error_t result, uint16_t val) { event void Photo.readDone(error_t result, uint16_t val) {
  if(result == SUCCESS) {
                                                                   if(result == SUCCESS) {
    current_entry->temp = val;
                                                                     entry->rad = val;
  else current_entry->temp = 0xFFFF;
                                                                   else current_entry->rad = 0xFFFF;
}
                                                                   call Radiation.read();
event void Photo.readDone(error_t result, uint16_t val) {
  if(result == SUCCESS) {
                                                                 levent void Radiation.readDone(error_t result, uint16_t val) {
    current_entry->photo = val;
                                                                   if(result == SUCCESS) {
                                                                     entry->rad = val;
  else current_entry->photo = 0xFFFF;
                                                                   else current_entry->rad = 0xFFFF;
                                                                   call LogWrite.append(entry, sizeof(log entry t));
event void Radiation.readDone(error_t result, uint16_t val) {
 if(result == SUCCESS) {
                                                                 event void LogWrite.appendDone(void* buf,
    current_entry->rad = val;
                                                                                                 storage_len_t len,
  else current entry->rad = 0xFFFF;
                                                                                                 bool recordsLost,
                                                                                                error_t error) {
                                                                   if (error == SUCCESS)
event void LogWrite.appendDone(void* buf,
                                                                     call Leds.led2Toggle();
                               storage_len_t len,
                               bool recordsLost,
                               error_t error) {
  if (error == SUCCESS)
    call Leds.led2Toggle();
```

In the parallel case, logging to flash and requesting samples from each sensor is all done within the body of the Timer.fired() event. In the serial case, a chain of events is triggered by first calling Humidity.read() in Timer.fired(), sampling each subsequent sensor in the body of the previous readDone() event, and ending with all sensor readings being logged to flash.

By logging to flash and sampling all sensors within the body of a single event, the OS has the opportunity to schedule each operation as it sees fit. Performing each operation after the completion of the previous one gives the OS no such opportunity. The only downside of the parallel approach is that the application must manually manage a double buffer so that the values written to flash are not overwritten before they are logged. To save the most energy, however, the parallel version should always be used. Keep in mind that in both cases, the developer must also make sure that the sampling interval is longer than the time it takes to gather all sensor readings. If it is not, data corruption will inevitably occur.

Radio Power Management

By default, TinyOS provides low power radio operation through a technique known as *Low-Power Listening*. In low-power listening, a node turns on its radio just long enough to detect a carrier on the channel. If it detects a carrier, then it keeps the radio on long enough to detect a packet. Because the LPL check period is much longer than a packet, a transmitter must send its first packet enough times for a receiver to have a chance to hear it. The transmitter stops sending once it receives a link-layer acknowledgment or a timeout. The timeout is a few milliseconds longer than the receiver's check period. When a node receives a packet, it stays awake long enough to receive a second packet. Therefore, a packet burst amortizes the wakeup cost of the first packet over the follow-up packets. It is therefore more energy efficient to send packets in bursts when using low-power listening than sending individual packets at some fixed constant rate. Keep this in mind when developing applications that require low power operation.

Controlling the operation of low-power listening in TinyOS is provided through the use of the LowPowerListening interface. The Interface is supported by the cc1000, the cc2420 and the rf230 radios.

```
interface LowPowerListening {
    Set this this node's radio wakeup interval, in milliseconds. After
    each interval, the node will wakeup and check for radio activity.
    Note: The wakeup interval can be set to 0 to indicate that the radio
    should stay on all the time but in order to get a startDone this
    should only be done when the duty-cycling is off (after a stopDone).
    @param intervalMs the length of this node's Rx check interval, in [ms]
 command void setLocalWakeupInterval(uint16 t intervalMs);
   @return the local node's wakeup interval, in [ms]
 command uint16_t getLocalWakeupInterval();
 st Configure this outgoing message so it can be transmitted to a neighbor mote
    with the specified wakeup interval.
@param 'message_t* ONE msg' Pointer to the message that will be sent
    @param intervalMs The receiving node's wakeup interval, in [ms]
 command void setRemoteWakeupInterval(message_t *msg, uint16_t intervalMs);
    @param 'message_t* ONE msg'
    @return the destination node's wakeup interval configured in this message
 command uint16_t getRemoteWakeupInterval(message_t *msg);
```

This interface is located in tos/interfaces in the standard TinyOS tree. Take a look at the comments for each command to familiarize yourself with how this interface can be used.

Using this interface typically involves first setting a nodes local duty cycle within the Boot.booted() event of the top level application. For each packet the application wishes to send, the duty cycle of its destination is then specified as metadata so that the correct number of preambles can be prepended to it. The code snippet found below demonstrates this usage pattern:

```
event void Boot.booted() {
    call LPL.setLocalSleepInterval(LPL_INTERVAL);
    call AMControl.start();
}

event void AMControl.startDone(error_t e) {
    if(e != SUCCESS)
        call AMControl.start();
}

...

void sendMsg() {
    call LPL.setRxSleepInterval(&msg, LPL_INTERVAL);
    if(call Send.send(dest_addr, &msg, sizeof(my_msg_t)) != SUCCESS)
```

The AMControl interface is provided by ActiveMessageC, and is used, among other things, to enable the operation of low-power listening for the radio. Once AMControl.start() has completed successfully, the radio begins to duty cycle itself as specified by the parameter to the setLocalSleepInterval() command. Calling setRxSleepInterval() with a specific sleep interval then allows the correct number of preambles to be sent for the message specified in its parameter list.

Microcontroller Power Management

Microcontrollers often have several power states, with varying power draws, wakeup latencies, and peripheral support. The microcontroller should always be in the lowest possible power state that can satisfy application requirements. Determining this state accurately requires knowing a great deal about the power state of many subsystems and their peripherals. Additionally, state transitions are common. Every time a microcontroller handles an interrupt, it moves from a low power state to an active state, and whenever the TinyOS scheduler finds the task queue empty it returns the microcontroller to a low power state. TinyOS uses three mechanisms to decide what low power state it puts a microcontroller into: status and control registers, a dirty bit, and a power state override. Please refer to TEP 112 (http://www.tinyos.net/tinyos-2.x/doc/html/tep112.html) for more information.

As a developer, you will not have to worry about MCU power management at all in most situations. TinyOS handles everything for you automatically. At times, however, you may want to use the provided power state override functionality. Take a look at tos/chips/atm128/timer/HplAtm128Timer0AsyncP.nc if you are interested in seeing an example of where this override functionality is used.

Low Power Sensing Application

A fully functional low-power sensing application has been created that combines each of the techniques found in this tutorial. At present, this application is not included in the official TinyOS distribution (<= 2.0.2). If you are using TinyOS from a cvs checkout, you will find it located under apps/tutorials/LowPowerSensing. Otherwise, you can obtain it from cvs by running the following set of commands from a terminal window:

```
cd $TOSROOT/apps/tutorials
cvs -d:pserver:anonymous@tinyos.cvs.sourceforge.net:/cvsroot/tinyos login
cvs -z3 -d:pserver:anonymous@tinyos.cvs.sourceforge.net:/cvsroot/tinyos co -P -D 2007-10-3 -d LowPowerSensing tinyos-2.x/apps/tu

| |
```

Just hit enter when prompted for a CVS password. You do not need to enter one.

This application has been tested on telosb and mica2 platforms, but should be usable on others without modification. Take a look at the README file found in the top level directory for more information.

Related Documentation

- TEP 103: Permanent Data Storage (Flash) (http://www.tinyos.net/tinyos-2.x/doc/html/tep103.html)
- TEP 105: Low Power Listening (http://www.tinyos.net/tinyos-2.x/doc/html/tep105.html)
- TEP 108: Resource Arbitration (http://www.tinyos.net/tinyos-2.x/doc/html/tep108.html)
- TEP 109: Sensors and Sensor Boards (http://www.tinyos.net/tinyos-2.x/doc/html/tep109.html)
- TEP 112: Microcontroller Power Management (http://www.tinyos.net/tinyos-2.x/doc/html/tep112.html)
- TEP 114: SIDs: Source and Sink Independent Drivers (http://www.tinyos.net/tinyos-2.x/doc/html/tep114.html)
- TEP 115: Power Management of Non-Virtualised Devices (http://www.tinyos.net/tinyos-2.x/doc/html/tep115.html)
- Integrating Concurrency Control and Energy Management in Device Drivers (http://www.klueska.com/pubs/klues07sosp.pdf)

< Previous Lesson | Top | Next Lesson >

Retrieved from "http://tinyos.stanford.edu/tinyos-wiki/index.php?title=Writing_Low-Power_Applications&oldid=6493" Category: Tutorials

- This page was last modified on 29 November 2013, at 08:38.
- This page has been accessed 46,313 times.