Bedroom R2: Installation method amendment

November 10, 2026

Tape-fit the pieces on the wall

Once the layout is approved, pencil the rectangle on the wall and align it with the retained trim. Cut and dry-fit the four separate pieces for one frame directly on the wall, holding them with painter’s tape. Check all four miters, the reveals, and alignment. Then fasten each piece in place with adhesive and brads suited to the substrate. The tape is temporary.

This method replaces the bench preassembly and square-jig instructions and the whole-frame mounting steps on R2 pages 9 and 14, including the jig illustrations. R2 geometry remains awaiting review. This change does not release cutting or installation.