

EMERGENCY PROCEDURES CHECKLIST · Aircraft: _____

Cessna T206H | TRAINING USE ONLY | Ref: POH Section 3

FLIGHT INFORMATION

PIC Name		Date / Time	
Aircraft Reg.		Instructor / Examiner	

⚠ จดบันทึก — ยังไม่อนุมัติให้ใช้ในการบิน · ถอดจาก Cessna Pilot’s Checklist Model T206H (Rev 4 · 13 May 2002) ซึ่งภาพถ่ายต้นฉบับถูกตัดท้ายหน้า ทำให้ยังขาดรายการ 7 จุดที่ทำแถบสีแดงไว้ ต้องเดิมจาก POH และให้หัวหน้าครูการบินรับรองก่อนใช้งาน

⚠ **MEMORY ITEMS** — Procedures marked with ⚠ should be memorised by all student pilots. *Engine failure immediately after takeoff, engine fire in flight, and spin recovery are critical memory items.*

AIRSPEEDS — EMERGENCY OPERATION

☐ Engine failure after takeoff — flaps up / down	85 / 75 KIAS
☐ Maneuvering speed — 3,600 / 2,950 / 2,300 lb	125 / 120 / 106 KIAS
☐ Maximum glide — 3,600 / 3,200 / 2,800 lb	80 / 75 / 70 KIAS
☐ Precautionary landing with engine power	75 KIAS
☐ Landing without engine power — flaps up / down	85 / 75 KIAS
☐ Emergency descent — smooth air	182 KIAS
☐ Emergency descent — rough air, 3,600 / 2,950 / 2,300 lb	125 / 120 / 106 KIAS

⚠ ENGINE FAILURE DURING TAKEOFF ROLL

☐ ⚠ Throttle	IDLE
☐ ⚠ Brakes	APPLY
☐ Wing flaps	RETRACT
☐ Mixture	IDLE CUT OFF
☐ Ignition switch	OFF
☐ Master switch	OFF

⚠ ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF

☐ ⚠ Airspeed	85 KIAS FLAPS UP · 75 KIAS FLAPS DOWN
☐ Mixture	IDLE CUT OFF
☐ Fuel selector valve	PUSH DOWN AND ROTATE TO OFF
☐ Ignition switch	OFF
☐ Wing flaps	AS REQUIRED (40° RECOMMENDED)
☐ Master switch	OFF
☐ Cabin door	UNLATCH
☐ Land	STRAIGHT AHEAD

⚠ ENGINE FAILURE DURING FLIGHT (RESTART)

☐ ⚠ Airspeed	80 KIAS
☐ ⚠ Fuel selector valve	BOTH
☐ ⚠ Auxiliary fuel pump switch	ON
☐ Engine power	RESTORED

⚠ ENGINE FIRE IN FLIGHT

⚠ ต้นฉบับขาด — ข้อ 1 ถึง 4 — ท้ายหน้าต้นฉบับถูกตัด	เดิมจาก POH
☐ Cabin heat and air	OFF (EXCEPT OVERHEAD VENTS)
☐ Airspeed	110 KIAS · INCREASE IF FIRE NOT OUT
☐ Forced landing	EXECUTE

⚠ ELECTRICAL FIRE IN FLIGHT

☐ ⚠ Master switch	OFF
☐ ⚠ Vents / cabin air / heat	CLOSED
☐ ⚠ Fire extinguisher	ACTIVATE
☐ ⚠ Avionics master switch	OFF
☐ ⚠ All other switches (except ignition)	OFF
☐ After discharging extinguisher	VENTILATE THE CABIN
☐ Vents / cabin air / heat	OPEN WHEN FIRE IS OUT

⚠ CABIN FIRE

☐ ⚠ Master switch	OFF
☐ ⚠ Vents / cabin air / heat	CLOSED (AVOID DRAFTS)
☐ ⚠ Fire extinguisher	ACTIVATE
☐ Vents / cabin air	OPEN WHEN FIRE IS OUT
☐ Land	AS SOON AS POSSIBLE · INSPECT

⚠ WING FIRE

☐ ⚠ Landing / taxi light switches	OFF
☐ ⚠ Navigation light switch	OFF
☐ ⚠ Strobe light switch	OFF
☐ ⚠ Pitot heat switch	OFF
☐ Sideslip	KEEP FLAMES AWAY FROM FUEL TANK
☐ Land	AS SOON AS POSSIBLE · FLAPS ONLY AS NEEDED

INADVERTENT ICING ENCOUNTER

☐ ⚠ Pitot heat switch	ON
☐ ⚠ Turn back or change altitude	LESS CONDUCTIVE OAT

☐ Mixture	RICH (IF RESTART DOES NOT OCCUR)
☐ Ignition switch	CHECK BOTH (OR START IF PROP STOPPED)
☐ Auxiliary fuel pump switch	OFF
☐ If fuel flow drops to zero	RETURN AUX PUMP SWITCH TO ON
EMERGENCY LANDING WITHOUT ENGINE POWER	
☐ Passenger seats	AS FAR FORWARD AS PRACTICAL
☐ Passenger seat backs	MOST UPRIGHT POSITION
☐ Seats and seat belts	SECURE
☐ Airspeed	85 KIAS FLAPS UP · 75 KIAS FLAPS DOWN
☐ Mixture	IDLE CUT OFF
☐ Fuel selector valve	PUSH DOWN AND ROTATE TO OFF
☐ Ignition switch	OFF
☐ Wing flaps	AS REQUIRED (40° RECOMMENDED)
☐ Master switch	OFF WHEN LANDING IS ASSURED
☐ Doors	UNLATCH PRIOR TO TOUCHDOWN
☐ Touchdown	SLIGHTLY TAIL LOW
☐ Brakes	APPLY HEAVILY
PRECAUTIONARY LANDING WITH ENGINE POWER	
☐ Passenger seats	AS FAR FORWARD AS PRACTICAL
☐ Passenger seat backs	MOST UPRIGHT POSITION
☐ Seats and seat belts	SECURE
☐ Airspeed	85 KIAS
☐ Wing flaps	20°
⚠ ต้นจมน้ำขาด — ข้อ 6 ถึง 8 — ทำยหน้าต้นจมน้ำถูกตัด	เดิมจาก POH
☐ Airspeed	75 KIAS
☐ Master switch	OFF
☐ Doors	UNLATCH PRIOR TO TOUCHDOWN
☐ Touchdown	SLIGHTLY TAIL LOW
☐ Ignition switch	OFF
☐ Mixture	IDLE CUT OFF
☐ Brakes	APPLY HEAVILY

☐ ⚠ Cabin heat and defrost controls	FULL OUT
☐ Engine speed	INCREASE · CYCLE TO 2200 RPM IF VIBRATION
☐ Induction air filter icing	REGAIN MP BY INCREASING THROTTLE
☐ Landing	PLAN FOR NEAREST AIRPORT
⚠ ต้นจมน้ำขาด — ข้อ 7 ถึง 9 — ทำยหน้าต้นจมน้ำถูกตัด	เดิมจาก POH
☐ Approach	95–100 KIAS FLAPS 20° · 110–120 KIAS FLAPS 0–10°
☐ Landing	MAIN WHEELS FIRST · AVOID SLOW HIGH FLARE
☐ Missed approach	AVOID · IF REQUIRED 100 KIAS · FLAPS 10° STEPS
STATIC SOURCE BLOCKAGE	
☐ ⚠ Static pressure alternate source valve	PULL ON
☐ Heat and air valves	PULL ON
☐ Vents	CLOSED
☐ Airspeed	CONSULT POH SECTION 5 CALIBRATION
☐ Altitude	CONSULT POH SECTION 5 CALIBRATION
EXCESSIVE FUEL VAPOR	
☐ ⚠ Auxiliary fuel pump switch	ON
☐ Mixture	RESET AS REQUIRED
☐ Fuel selector valve	SELECT OPPOSITE TANK IF SYMPTOMS CONTINUE
☐ Auxiliary fuel pump switch	OFF AFTER FLOW STABILISES
LANDING WITH A FLAT MAIN TIRE	
☐ Approach	NORMAL
☐ Wing flaps — serials thru T20608361	0–10° <140 KIAS · 10–40° <100 KIAS
☐ Wing flaps — serials T20608362 and on	0–10° <140 · 10–20° <120 · 20–40° <100 KIAS
☐ Touchdown	GOOD MAIN TIRE FIRST · HOLD FLAT TIRE OFF
☐ Directional control	BRAKE ON GOOD WHEEL AS REQUIRED
LANDING WITH A FLAT NOSE TIRE	
⚠ ต้นจมน้ำขาด — ทั้งหัวข้อ — ทำยหน้าต้นจมน้ำถูกตัด ไม่มีข้อความให้ถอด	เดิมจาก POH
ELECTRICAL — AMMETER SHOWS EXCESSIVE RATE OF CHARGE	
☐ Alternator	OFF
☐ Nonessential electrical equipment	OFF
☐ Flight	TERMINATE AS SOON AS PRACTICAL

DITCHING	
☐ Radio	MAYDAY ON 121.5 MHz · SQUAWK 7700
☐ Heavy objects in baggage area	SECURE OR JETTISON
☐ Passenger seats	AS FAR FORWARD AS PRACTICAL
☐ Passenger seat backs	MOST UPRIGHT POSITION
☐ Seats and seat belts	SECURE
☐ Wing flaps	40°
☐ Power	ESTABLISH 300 FT/MIN DESCENT AT 70 KIAS
☐ If no power available	85 KIAS FLAPS UP · 80 KIAS FLAPS 10°
☐ Approach — high wind / heavy seas	INTO THE WIND
☐ Approach — light wind / heavy swells	PARALLEL TO SWELLS
☐ Cabin doors	UNLATCH
☐ Touchdown	LEVEL ATTITUDE AT 300 FT/MIN DESCENT
☐ Face	CUSHION AT TOUCHDOWN WITH FOLDED COAT
⚠ ต้นจบบัซซาด — ข้อ 12 เป็นต้นไป (ELT ฯลฯ) — ทำหน้าที่ต้นจบบัซซาด	เดิมจาก POH
FIRE — DURING START ON GROUND	
☐ ⚠ Ignition switch	START · CONTINUE CRANKING
☐ If engine starts — power	1800 RPM FOR A FEW MINUTES
☐ If engine starts — engine	SHUTDOWN AND INSPECT
☐ ⚠ If engine fails to start — ignition switch	START · CONTINUE CRANKING
☐ ⚠ Throttle	FULL OPEN
☐ ⚠ Mixture	IDLE CUT OFF
☐ ⚠ Fuel selector valve	PUSH DOWN AND ROTATE TO OFF
☐ ⚠ Auxiliary fuel pump switch	OFF
☐ Fire extinguisher	OBTAIN
☐ Engine	SECURE — MASTER OFF · IGNITION OFF
☐ Parking brake	RELEASE
☐ Airplane	EVACUATE
☐ Fire	EXTINGUISH — EXTINGUISHER / BLANKET / DIRT
☐ Fire damage	INSPECT BEFORE FURTHER FLIGHT

☐ Note	COMPASS DEVIATION UP TO 25° WITH ALT OFF
ELECTRICAL — LOW VOLTAGE ANNUNCIATOR (VOLTS) IN FLIGHT	
☐ Avionics master switch	OFF
☐ Alternator circuit breaker (ALT FLD)	CHECK IN
☐ Master switch	OFF (BOTH SIDES)
☐ Master switch	ON
☐ Low voltage annunciator (VOLTS)	CHECK OFF
☐ Avionics master switch	ON
☐ If VOLTS illuminates again — alternator	OFF
☐ Nonessential radio and electrical equipment	OFF
☐ Flight	TERMINATE AS SOON AS PRACTICAL
EMERGENCY DESCENT — SMOOTH AIR	
☐ Seats and seat belts	SECURE
☐ Throttle	IDLE
⚠ ต้นจบบัซซาด — ข้อ 3 เป็นต้นไป — ทำหน้าที่ต้นจบบัซซาด	เดิมจาก POH
EMERGENCY DESCENT — ROUGH AIR	
☐ Seats and seat belts	SECURE
☐ Throttle	IDLE
☐ Propeller	HIGH RPM
☐ Mixture	FULL RICH
☐ Wing flaps	UP
☐ Airspeed — 3,600 / 2,950 / 2,300 lb	125 / 120 / 106 KIAS
VACUUM SYSTEM FAILURE (L VAC or VAC R)	
☐ ⚠ Vacuum gage	CHECK WITHIN NORMAL LIMITS
⚠ ต้นจบบัซซาด — ข้อ 2 เป็นต้นไป — ทำหน้าที่ต้นจบบัซซาด	เดิมจาก POH
☐ If outside limits	PARTIAL PANEL PROCEDURES MAY BE REQUIRED