

NORMAL PROCEDURES CHECKLIST

Aircraft: _____

Cessna T206H | For Training Use Only | Ref: POH Section 4

FLIGHT INFORMATION

PIC Name		Student / SIC Name	
Aircraft Reg.		Date / Time	

⚠ จดบันทึก — ยังไม่อนุมัติให้ใช้ในการบิน · ถอดจาก Cessna Pilot's Checklist Model T206H (Rev 4 · 13 May 2002) ซึ่งภาพถ่ายต้นฉบับถูกตัดท้ายหน้า ทำให้ยังขาดรายการ 3 จุดที่ทำแถบสีแดงไว้ ต้องเดิมจาก POH และให้หัวหน้าครูการบินรับรองก่อนใช้งาน

AIRSPEEDS — NORMAL OPERATION (3,600 LB)	
☐ Normal climb out	75–85 KIAS
☐ Short field takeoff, flaps 20° — speed at 50 ft	74 KIAS
☐ Enroute climb, flaps up — normal	95 KIAS
☐ Best rate of climb, SL to 17,000 ft	89 KIAS
☐ Best rate of climb, 24,000 ft	79 KIAS
☐ Best angle of climb, sea level	69 KIAS
☐ Best angle of climb, 10,000 ft	72 KIAS
☐ Normal approach, flaps up	80–90 KIAS
☐ Normal approach, flaps 40°	70–80 KIAS
☐ Short field approach, flaps 40°	67 KIAS
☐ Balked landing, max power, flaps 20°	85 KIAS
☐ Turbulent air penetration — 3,600 / 2,950 / 2,300 lb	125 / 120 / 106 KIAS
☐ Max demonstrated crosswind, takeoff or landing	20 KNOTS
PREFLIGHT — 1 CABIN	
☐ Pitot tube cover	REMOVE · CHECK FOR BLOCKAGE
☐ Pilot's Operating Handbook	AVAILABLE IN THE AIRPLANE
☐ Airplane weight and balance	CHECKED
☐ Parking brake	SET
☐ Control wheel lock	REMOVE
☐ Ignition switch	OFF
☐ Avionics master switch	OFF
☐ ⚠ Treat propeller as if ignition were ON	STAND CLEAR OF ARC
☐ Master switch	ON
☐ Fuel quantity indicators · L LOW FUEL R annunciators	CHECK QTY · ENSURE EXTINGUISHED
☐ Avionics master switch	ON
☐ Avionics cooling fan	CHECK AUDIBLY
☐ Avionics master switch	OFF
☐ Static pressure alternate source valve	OFF
☐ Annunciator panel switch	HOLD IN TST · ALL ILLUMINATE
☐ Annunciator panel test switch	RELEASE · CHECK
☐ Fuel selector valve	BOTH

BEFORE TAKEOFF	
☐ Parking brake	SET
☐ Passenger seats	AS FAR FORWARD AS PRACTICAL
☐ Passenger seat backs	MOST UPRIGHT POSITION
☐ Seats and seat belts	CHECK SECURE
☐ Cabin doors	CLOSED AND LOCKED
☐ Flight controls	FREE AND CORRECT
☐ Flight instruments	CHECK AND SET
☐ Fuel quantity	CHECK
☐ Auxiliary fuel pump	OFF
☐ Mixture	RICH
☐ Fuel selector valve	RECHECK BOTH
☐ Throttle	1800 RPM
⚠ ต้นฉบับขาด — ข้อ 12.a (ตรวจแมกนีโตและค่า RPM drop ที่ยอมรับได้) — ท้ายหน้าต้นฉบับถูกตัด	
☐ b. Propeller	CYCLE HIGH–LOW–HIGH (FULL IN)
☐ c. Vacuum gage	CHECK
☐ d. Engine instruments and ammeter	CHECK
☐ e. Annunciator panel	NO ANNUNCIATORS ILLUMINATED
☐ Throttle	CHECK IDLE
☐ Throttle	1000 RPM
☐ Throttle friction lock	ADJUST
☐ Strobe lights	AS DESIRED
☐ Electric trim (if installed)	PREFLIGHT TEST
☐ Radios and avionics	SET
☐ NAV/GPS switch (if installed)	SET
☐ Autopilot (if installed)	OFF
☐ Elevator trim and rudder trim	SET FOR TAKEOFF
☐ Cowl flaps	OPEN
☐ Wing flaps	SET FOR TAKEOFF (0° TO 20°)
☐ Brakes	RELEASE
TAKEOFF — NORMAL	
☐ Wing flaps	0° – 20°

☐ Flaps	EXTEND
☐ Pitot heat	ON · WARM WITHIN 30 SEC
☐ Pitot heat	OFF
☐ Master switch	OFF
☐ Trim controls	NEUTRAL
☐ Oxygen supply pressure	CHECK
☐ Oxygen masks	CHECK
PREFLIGHT — 2 EMPENNAGE	
☐ Rudder gust lock (if installed)	REMOVE
☐ Tail tie-down	DISCONNECT
☐ Control surfaces	FREE AND SECURE
☐ Trim tab	CHECK SECURITY
☐ Cargo doors (right side only)	SECURELY LATCHED
☐ Antennas	SECURE · CHECK CONDITION
PREFLIGHT — 3 RIGHT WING TRAILING EDGE	
☐ Flap	SECURE · CHECK CONDITION
☐ Aileron	FREE AND SECURE
PREFLIGHT — 4 RIGHT WING	
☐ Wing tie-down	DISCONNECT
☐ Fuel tank vent opening	CHECK FOR STOPPAGE
☐ Main wheel tire	INFLATION · CONDITION
☐ Fuel tank sump quick drain valves	DRAIN · SAMPLE CLEAR
☐ Fuel quantity	CHECK VISUALLY
☐ Fuel filler cap	SECURE · VENT UNOBSTRUCTED
PREFLIGHT — 5 NOSE	
☐ Static source opening (right side)	CHECK FOR BLOCKAGE
☐ Fuel strainer quick drain valve	DRAIN · SAMPLE CLEAR
☐ Engine oil dipstick / filler cap	CHECK · MIN 6 QT · 11 QT EXTENDED
☐ Engine cooling air inlets · oil cooling inlet	CLEAR OF OBSTRUCTIONS
☐ Propeller and spinner	NO NICKS · SECURE
☐ Engine induction air filter	CHECK FOR RESTRICTION
☐ Nose wheel strut and tire	INFLATION · CONDITION
☐ Static source opening (left side)	CHECK FOR BLOCKAGE
PREFLIGHT — 6 LEFT WING	
☐ Fuel quantity	CHECK VISUALLY

☐ Power	39 IN. HG. AND 2500 RPM
☐ Mixture	ADJUST TO 34 GPH FUEL FLOW
☐ Elevator control	LIFT NOSE WHEEL AT 55 KIAS
☐ Climb speed	75–85 KIAS (FLAPS 20°)
☐ Wing flaps	RETRACT AFTER OBSTACLES CLEARED
TAKEOFF — SHORT FIELD	
☐ Wing flaps	20°
☐ Brakes	APPLY
☐ Power	39 IN. HG. AND 2500 RPM
☐ Mixture	ADJUST TO 34 GPH FUEL FLOW
☐ Brakes	RELEASE
☐ Elevator control	MAINTAIN SLIGHTLY TAIL LOW
☐ Climb speed	74 KIAS UNTIL OBSTACLES CLEARED
☐ Wing flaps	RETRACT SLOWLY AFTER 90 KIAS
☐ Power	DO NOT REDUCE UNTIL FLAPS RETRACTED
ENROUTE CLIMB — NORMAL	
☐ Airspeed	95–105 KIAS
☐ Power	30 IN. HG. AND 2400 RPM
☐ Mixture	LEAN TO 20 GPH FUEL FLOW
☐ Fuel selector valve	BOTH
☐ Cowl flaps	OPEN AS REQUIRED
ENROUTE CLIMB — MAXIMUM PERFORMANCE	
☐ Airspeed	89 KIAS
☐ Power	39 IN. HG. AND 2500 RPM
☐ Mixture	ADJUST TO 34 GPH FUEL FLOW
☐ Fuel selector valve	BOTH
☐ Cowl flaps	OPEN
☐ Above 17,000 ft	SEE MIN FUEL FLOW PLACARD
CRUISE	
☐ Power	15–30 IN. HG. · 2000–2400 RPM (MAX 75%)
☐ Mixture	LEAN
☐ Elevator and rudder trim	ADJUST
☐ Cowl flaps	AS REQUIRED
☐ Auxiliary fuel pump	ON MOMENTARILY WHEN SWITCHING TANKS
DESCENT	

☐ Fuel filler cap	SECURE · VENT UNOBSTRUCTED
☐ Fuel tank sump quick drain valves	DRAIN · SAMPLE CLEAR
☐ Main wheel tire	INFLATION · CONDITION
PREFLIGHT — 7 LEFT WING LEADING EDGE	
☐ Fuel tank vent opening	CHECK FOR BLOCKAGE
☐ Stall warning vane	FREE · HORN SOUNDS
☐ Wing tie-down	DISCONNECT
☐ Landing / taxi light(s)	CONDITION · CLEAN
PREFLIGHT — 8 LEFT WING TRAILING EDGE	
☐ Aileron	FREE AND SECURE
☐ Flap	SECURE · CHECK CONDITION
BEFORE STARTING ENGINE	
☐ Preflight inspection	COMPLETE
☐ Passenger briefing	COMPLETE
☐ Seats and seat belts	ADJUST AND LOCK
⚠️ ต้นฉบับขาด — ข้อ 4 และ 5 — ท้ายหน้าต้นฉบับถูกตัด	เดิมจาก POH
☐ Electrical equipment	OFF
☐ Avionics master switch	OFF — REQUIRED BEFORE START
☐ Cowl flaps	OPEN
☐ Fuel selector valve	BOTH
☐ Avionics circuit breakers	CHECK IN
STARTING ENGINE (WITH BATTERY)	
☐ Throttle	OPEN 1/4 INCH
☐ Propeller	HIGH RPM
☐ Mixture	IDLE CUT OFF
☐ Propeller area	CLEAR
☐ Master switch	ON
☐ Auxiliary fuel pump switch	ON (omit 6–8 if engine warm)
☐ Mixture	FULL RICH UNTIL FLOW RISES · THEN IDLE CUT OFF
☐ Auxiliary fuel pump switch	OFF
☐ Ignition switch	START · RELEASE WHEN RUNNING
☐ Mixture	ADVANCE SMOOTHLY TO RICH
☐ Oil pressure	CHECK
☐ Flashing beacon and navigation lights	ON AS REQUIRED
☐ Avionics master switch	ON
☐ Radios	ON

☐ Power	AS DESIRED
☐ Mixture	ENRICHEN AS REQUIRED
☐ Cowl flaps	CLOSED
☐ Altimeter	SET
☐ NAV/GPS switch	SET
☐ Fuel selector valve	BOTH
☐ Wing flaps — serials thru T20608361	0–10° <140 KIAS · 10–40° <100 KIAS
☐ Wing flaps — serials T20608362 and on	0–10° <140 · 10–20° <120 · 20–40° <100 KIAS
BEFORE LANDING	
☐ Passenger seats	AS FAR FORWARD AS PRACTICAL
☐ Pilot and passenger seat backs	MOST UPRIGHT POSITION
☐ Seats and seat belts	SECURED AND LOCKED
☐ Fuel selector valve	BOTH
☐ Mixture	RICH
☐ Propeller	HIGH RPM
☐ Landing / taxi lights	ON
☐ Autopilot (if installed)	OFF
⚠️ ต้นฉบับขาด — อาจมีข้อถัดจาก 8 — ท้ายหน้าต้นฉบับถูกตัด	เดิมจาก POH
LANDING — NORMAL	
☐ Airspeed	80–90 KIAS (FLAPS UP)
☐ Wing flaps — serials thru T20608361	0–10° <140 KIAS · 10–40° <100 KIAS
☐ Wing flaps — serials T20608362 and on	0–10° <140 · 10–20° <120 · 20–40° <100 KIAS
☐ Airspeed	70–80 KIAS (FLAPS DOWN)
☐ Trim	ADJUST AS DESIRED
☐ Touchdown	MAIN WHEELS FIRST
☐ Landing roll	LOWER NOSE WHEEL GENTLY
☐ Braking	MINIMUM REQUIRED
LANDING — SHORT FIELD	
☐ Airspeed	80–90 KIAS (FLAPS UP)
☐ Wing flaps	FULL (BELOW 100 KIAS)
☐ Airspeed	MAINTAIN 67 KIAS
☐ Power	REDUCE TO IDLE AS OBSTACLE CLEARED
☐ Trim	ADJUST
☐ Touchdown	MAIN WHEELS FIRST
☐ Brakes	APPLY HEAVILY
☐ Wing flaps	RETRACT FOR MAX BRAKING

STARTING ENGINE (WITH EXTERNAL POWER)	
☐ Throttle	OPEN 1/4 INCH
☐ Propeller	HIGH RPM
☐ Mixture	IDLE CUT OFF
☐ Propeller area	CLEAR
☐ External power	CONNECT TO RECEPTACLE
☐ Master switch	ON
☐ Auxiliary fuel pump switch	ON (omit 7–9 if engine warm)
☐ Mixture	FULL RICH UNTIL FLOW RISES · THEN IDLE CUT OFF
☐ Auxiliary fuel pump switch	OFF
☐ Ignition switch	START · RELEASE WHEN RUNNING
☐ Mixture	ADVANCE SMOOTHLY TO RICH
☐ Oil pressure	CHECK
☐ External power	DISCONNECT · SECURE DOOR
☐ Ammeter	CHECK
☐ Flashing beacon and navigation lights	ON AS REQUIRED
☐ Avionics master switch	ON
☐ Radios	ON

BALKED LANDING	
☐ Power	39 IN. HG. AND 2500 RPM
☐ Mixture	ADJUST TO 34 GPH FUEL FLOW
☐ Wing flaps	RETRACT TO 20°
☐ Climb speed	85 KIAS
☐ Wing flaps	RETRACT SLOWLY
☐ Cowl flaps	OPEN
AFTER LANDING	
☐ Wing flaps	RETRACT
☐ Cowl flaps	OPEN
SECURING AIRPLANE	
☐ Parking brake	SET
☐ Throttle	IDLE
☐ Electrical equipment · avionics master · autopilot	OFF
☐ Mixture	IDLE CUT OFF (PULLED FULL OUT)
☐ Ignition switch	OFF
☐ Master switch	OFF
☐ Control lock	INSTALL
☐ Fuel selector valve	LEFT OR RIGHT (PREVENT CROSS FEED)
☐ Cowl flaps	CLOSED