## **Private Pilot Maneuvers Cheat Sheet**

#### **Normal Takeoff Procedure**

Once cleared for takeoff

- Mixture RICH
- Light switches all ON
- Fuel pump ON
- Align with centerline
- Note wind and adjust ailerons as necessary (Ailerons into the wind!)
- Heels on the ground (off the brakes!)
- Apply full power smoothly
- Maintain centerline with rudder
- Rotate at Vr and climb at Vy
- Climb checklist at safe altitude ~1000' AGL

# **Slow Flight**

- Pre-maneuver checklist:
  - o Fuel pump ON
  - o Lights ON
  - o Mixture RICH
  - Clearing turns
- Note altitude/heading and pick an outside reference point
- Reduce power to 1500-1700 RPM
- Maintain altitude by applying INCREASING back pressure
- Extend flaps once in the white arc
- Pitch for airspeed
- Power for altitude
- Maintain 50-55 knots
- Rudder/Power as necessary to maintain heading/altitude
- Turns no more than 10° bank
- Recovery:
  - Power FULL forward
  - o Pitch down to accelerate
  - Flaps retract in increments
- Power-off stall:
  - o Reduce power to 1500-1700 RPM
  - Establish stabilized descent while maintaining airspeed/heading, after 100' descent:
  - o Power IDLE
  - o Induce the stall by pitching up, maintaining coordination and wings level
  - o recover at full stall and call out "stall"
- Recovery:
  - o Reduce angle of attack, pitching forward below the horizon
  - Power FULL forward
  - Flaps retract in increments
  - Climb to original cruise altitude

#### **Power-off Stall**

- Pre-maneuver checklist:
  - Fuel pump ON
  - o Lights ON
  - o Mixture RICH
  - Clearing turns
- Note altitude/heading and pick an outside reference point
- Reduce power to 1500-1700 RPM
- Maintain altitude by applying INCREASING back pressure
- Extend flaps once in the white arc
- Pitch for airspeed
- Power for altitude
- Upon reaching 50-55 knots
- Establish stabilized descent while maintaining airspeed/heading, after 100' descent:
- Power IDLE
- Induce the stall by pitching up, maintaining coordination and wings level
- recover at full stall and call out "stall"
- Recovery:
  - o Reduce angle of attack, pitching forward below the horizon
  - Power FULL forward
  - o Flaps retract in increments
  - Climb to original cruise altitude

## **Power-on Stall**

- Pre-maneuver checklist:
  - Fuel pump ON
  - Lights ON
  - o Mixture RICH
  - Clearing turns
- Note altitude/heading and pick an outside reference point
- Reduce power to 1500-1700 RPM
- Maintain altitude by applying INCREASING back pressure
- Slow to Vr and then:
- Power FULL forward
- Pitch up to induce stall
- Maintain coordination with rudder
- (If turn is requested, no more than 20° bank)
- recover at full stall and call out "stall"
- Recovery:
  - o Reduce angle of attack, pitching forward below the horizon
  - o Return to cruise configuration

## **Engine-out Procedures**

- Pitch and trim for best glide speed (Vg)
- Look for a place to land and stay close to it!
- Troubleshoot if altitude permits:

#### C172:

- Fuel selector BOTH
- o Mixture Rich
- o Carb Heat ON
- Magnetos Both (attempt restart if prop not wind milling)
- Master ON
- Primer IN and LOCKED

#### PA28:

- Mixture Rich
- o Fuel pump ON
- o Carb Heat ON
- o Master ON
- Primer IN and LOCKED
- Magnetos Both (attempt restart if prop not wind milling)
- Fuel selector switch tanks
- Run through emergency checklist
- (If still no start) Declare EMG on 121.5 and squawk 7700
- Before landing, shut fuel sources off
  - o Fuel selector OFF
  - Magnetos OFF
  - o Mixture CUTOFF
- Pop door(s) open
- Brace

# Traffic pattern



