1 | Worksheet

1.1 Friis

The reason why there is a loss through free space, is that the signal density gets lower, as it spread over a larger area, which happens when the distance, that the signal have travel, gets longer.

A example, is when using a isotropic antenna, the signal density is equal all the way around the antenna, forming a sphere around the antenna. As the power of the signal in total always is the same, the density of the signal power is depended on the surface of the sphere. As the signal travels longer away from the antenna, the sphere gets bigger and the surface bigger to, which means that the signal density gets lower. So the free space loss, is the loss of the signal that is not going in the direction of the receiving antenna.

Friis transmission equation is used to calculate the power, that is received at the receiving antenna, out from the gains in the antenna, the power of the transmitted signal and the free space loss.

$$P_r = P_t G_t G_r (\frac{\lambda}{4\pi d})^2 \tag{1.1}$$

Where:

P_r	is the received	l power at the	receiving antenna	W	

 P_r is the transmitted power at the transmitting an- [W]

tenna

 G_t is the gain in the transmitting antenna [1]

 G_r is the gain in the receiving antenna [1]

 λ is the wavelength of the transmitted signal [m]

d is the distance between the transmitting antenna [m]

and the receiving antenna

It is used to calculate the loss through the free space and do not take into account other waves, than the direct wave. The free space loss is equal to $(\frac{\lambda}{4\pi d})^2$ and is multiply by the gains in both antennas and the power transmitted, to get the received power level.

The free space loss comes from the spreading of the signal, which is compared to the spheres, which in the signal spread in, surface, which is calculated by $\frac{1}{4\pi d^2}$. Furthermore, there also comes the loss, when the signal is received at the receiver, where the effective antenna area is equal to $\frac{\lambda^2}{4\pi}$. These two losses give in total the free space loss. (Hans

16 gr 651 1 of 7

Chapter 1. Worksheet

eberts pdf)

This is the simple form of friis formulae and it is only correct, if these conditions is met:

- d is much greater than λ . If d is smaller than λ , there will be gain in power through the transmission between the antennas, which is a violation of the law of conservation of energy.
- The transmission goes through freespace, with no multipath. So no obstacle in the transmission line or around it (See worksheet about Line of sight (LOS)).
- The antennas is aligned and have the same polarization.
- The bandwidth is narrow enough, so that a single wavelength can be specified.
- P_r and P_t is the available power at the antennas, and do not take into account the loss through the cable running from antennas. Furthermore, the power will only be fully delivered and received, if the antennas and transmission lines are conjugate matched.

When the antennas is not aligned and/or not have the same polarization, the simple version of the equation can not be used. Another problem, is if the impedances is mismatched, which give a reflection at the antennas, which is another loss in the system. Also there is loss through the air, where the air absorb some of the power from the signal. With these losses, the equation is expanded to:

$$P_r = P_t G_t(\theta_t, \phi_t) G_r(\theta_r, \phi_r) \left(\frac{\lambda}{4\pi d}\right)^2 (1 - |\Gamma_t|^2) (1 - |\Gamma_r|^2) |a_t \cdot a_r^*|^2 e^{-\alpha d}$$
 (1.2)

Where:

 P_r is the received power at the receiving antenna [W]

 P_r is the transmitted power at the transmitting antenna [W] tenna

 $G_t(\theta_t, \phi_t)$ is the gain in the transmitting antenna [1]

 $G_r(\theta_t, \phi_t)$ is the gain in the receiving antenna [1]

 λ is the wavelength of the transmitted signal [m]

d is the distance between the transmitting antenna [m] and the receiving antenna

 Γ_t is the reflection constant a the transmitting antenna [1]

 Γ_r is the reflection constant a the receiving antenna [1]

2 of 7

a_t	is the polarization vector of the transmitting antenna	[1]
a_r	is the polarization vector of the receiving antenna	[1]
α	is the medium of transportations absorption coefficient	[1]

The new terms comes from different losses in the system, when the system is made ideal.

If the antennas is not aligned correctly, there will come a loss, dependently on the type of antenna and the angle, between the antennas.

16gr651 3 of 7

1.2 Two Ray Plane Earth

$$P_r(d) = \frac{P_t G_t G_r}{L} \frac{h_t^2 h_r^2}{d^4}$$

if
$$d > \frac{20h_t h_r}{\lambda}$$

else will the received power theoretically oscillates between local maxima of 6dB above free space to $-\infty$ dB at local minima.

$$LPE = 40 \log 10(d) - 20 \log 10(ht) - 20 \log 10(hr)$$

4 of 7 16gr651

[Poole, 2016]

16gr651 5 of 7

Bibliography

Poole, I. (2016). What is GMSK Modulation - Gaussian Minimum Shift Keying. http://www.radio-electronics.com/info/rf-technology-design/pm-phase-modulation/what-is-gmsk-gaussian-minimum-shift-keying-tutorial.php. Downloaded 7. March 2016.

6 of 7 16gr651

Appendix

16gr651 7 of 7