## 1 | Friis

The reason why there is a loss through free space, is that the signal density gets lower, as it spread over a larger area, which happens when the distance that the signal has travelled gets longer [Ian Poole, 2016].

For example, when using an isotropic antenna the signal density is equal all the way around the antenna, forming a sphere around the antenna. The power of the signal is in total always the same. Therefore the density of the signal power is only depended on the surface area of the sphere. As the signal travels longer away from the antenna the sphere gets bigger as do the surface, which means that the signal density gets lower. So the free space loss, is the factor describing the signal that is not going in the direction of the receiving antenna.

Friis transmission equation is used to calculate the power, that is received at the receiving antenna, out from the gains in the antenna, the power of the transmitted signal and the free space loss [Prof. Amy Connolly's group, 2013].

$$P_r = P_t G_t G_r \left(\frac{\lambda}{4\pi d}\right)^2 \tag{1.1}$$

Where:

| $P_r$ | is the received | power at the receiving antenna | W |  |
|-------|-----------------|--------------------------------|---|--|
|       |                 |                                |   |  |

 $P_r$  is the transmitted power at the transmitting an- [W]

tenna

 $G_t$  is the gain in the transmitting antenna [1]

 $G_r$  is the gain in the receiving antenna [1]

 $\lambda$  is the wavelength of the transmitted signal [m]

d is the distance between the transmitting antenna [m]

and the receiving antenna

It is used to calculate the loss through the free space and only accounts for the direct wave, the free space loss is equal to  $(\frac{\lambda}{4\pi d})^{-2}$ . To find the power received the power transmitted is multiplied by the gains in both antennas and divided with the free space path loss.

This is the simple form of friis formulae and it is only correct, if these conditions is met [Wikipedia, 2016]:

• d is much greater than  $\lambda$ . If d is smaller than  $\lambda$ , there will be gain in power through the transmission between the antennas, which is a violation of the law of

16 gr 651 1 of 4

## Chapter 1. Friis

conservation of energy.

- The transmission goes through freespace, with no multipath. So no obstacle in the transmission line or around it (See worksheet about Line of sight (LOS)).
- The antennas is aligned and have the same polarization.
- The bandwidth is narrow enough, so that a single wavelength can be specified.
- $P_r$  and  $P_t$  is the available power at the antennas, and do not take into account the loss through the cable running from antennas. Furthermore, the power will only be fully delivered and received, if the antennas and transmission lines are conjugate matched.

When the antennas are not aligned and/or do not have the same polarization, the simple version of the equation cannot be used. Another problem, is if the impedances is mismatched, which gives a reflection at the antennas, which is another loss in the system. Also there is loss through the air, where the air absorb some of the power from the signal. With these losses, the equation is expanded to:

| $P_r = P_t G_t(\theta_t, \phi_t) G_r(\theta_r, \phi_r) (\frac{\lambda}{4\pi d})^2 (1 -  \Gamma_t ^2) (1 -  \Gamma_r ^2)  a_t \cdot a_r^* ^2 e^{-\alpha d}$ |                         |  |     |  |  |
|--|-------------------------|--|-----|--|--|
| Where  | $P_r$                   | is the received power at the receiving antenna                             | [W] |  |  |
|  | $P_r$                   | is the transmitted power at the transmitting antenna                       | [W] |  |  |
|  | $G_t(\theta_t, \phi_t)$ | is the gain in the transmitting antenna                                    | [1] |  |  |
|  | $G_r(\theta_t, \phi_t)$ | is the gain in the receiving antenna                                       | [1] |  |  |
|  | $\lambda$               | is the wavelength of the transmitted signal                                | [m] |  |  |
|  | d                       | is the distance between the transmitting antenna and the receiving antenna | [m] |  |  |
|  | $\Gamma_t$              | is the reflection constant a the transmitting antenna                      | [1] |  |  |
|  | $\Gamma_r$              | is the reflection constant a the receiving antenna                         | [1] |  |  |
|  | $a_t$                   | is the polarization vector of the transmitting antenna                     | [1] |  |  |
|  | $a_r$                   | is the polarization vector of the receiving antenna                        | [1] |  |  |
|  | $\alpha$                | is the medium of transportations absorption co-                            | [1] |  |  |

2 of 4 16gr651

efficient

The new terms comes from different losses in the system, when the system is not ideal Prof. Amy Connolly's group [2013].

16 gr 651 3 of 4

## Bibliography

- Ian Poole (2016). Free Space Path Loss: Details, Formula, Calculator. http://www.radio-electronics.com/info/propagation/path-loss/free-space-formula-equation.php.
- Prof. Amy Connolly's group (2013). Friis Transmission Equation. https://u.osu.edu/connolly/files/2013/12/Friis-1ty893p.pdf.
- Wikipedia (2016). Friis transmission equation. https://en.wikipedia.org/wiki/Friis\_transmission\_equation. Accessed November 19, 2016.

4 of 4