## SCHEMATIC OF THE HEATHKIT® PAPER TAPE READER/PUNCH MODEL H10

## Part of 595-2020

- COMPONENT NUMBERS ARE IN THE FOLLOWING GROUPS.
   1-99 PARTS MOUNTED ON THE CHASSIS AND MAIN CIRCUIT BOARD,
   100-199 PARTS MOUNTED ON THE READER CIRCUIT BOARD.
- ALL RESISTORS ARE 1/2 WATT UNLESS MARKED OTHERWISE. RESISTOR VALUES ARE IN OHMS (K=1,000; M=1,000,000).
- 3. ALL CAPACITORS ARE IN µF UNLESS MARKED OTHERWISE.
- 4. 

  THIS SYMBOL INDICATES CIRCUIT BOARD GROUND.
- 5. 😑 THIS SYMBOL INDICATES CHASSIS GROUND.
- 6. THIS SYMBOL INDICATES WHERE A WIRE IS SOLDERED TO A CIRCUIT BOARD.
- 7. THIS SYMBOL INDICATES A CONNECTOR INSIDE CHASSIS PLUG P3.
- THIS SYMBOL INDICATES A PART THAT APPEARS TO BE ON A CIRCUIT BOARD BUT IS ACTUALLY MOUNTED ON THE CHASSIS.
- 9. THIS SYMBOL INDICATES A DC VOLTAGE TAKEN WITH A HIGH INPUT IMPEDANCE VOLTMETER FROM THE POINT INDICATED TO CHASSIS GROUND. VOLTAGES MAY VARY
- 10. PARTS IN SHADED AREAS ARE CRITICAL FOR CONTINUED SAFETY. REPLACE THEM ONLY WITH PARTS OF THE SAME RATING OR WITH THE PROPER HEATH PARTS.
- 11. COPY SWITCH SW4 IS SHOWN IN THE OUT POSITION.
- \* THESE PARTS ARE FOR POSSIBLE FUTURE APPLICATION.

Copyright © 1977 Heath Company All Rights Reserved Printed in the United States of America

