

EECE 5610 Digital Control Systems

Lecture 6

Milad Siami

Assistant Professor of ECE

Email: m.siami@northeastern.edu



Northeastern University
College of Engineering

Q? Is this the "best" way to proceed? Is this the only way to proceed

Q? Is this the "best" way to proceed? Is this the only way to proceed



A: Not necessarily.

Note that we started out with a second order T.F. Hence we would expect to be able to realize it with just two delays. However our realization uses 4 !



Summary :

Summary :

Analysis of sampling and reconstruction:










reconstruction
= D



$$= \underbrace{e(t)}_{\text{ideal sampler}} - \underbrace{\frac{e^*(t)}{1 - e^{-ST}}}_{\text{ideal ZOH}}$$


Summary :

Analysis of sampling and reconstruction:



Spectrum of $E^*(s)$:

sample
⇒



$$e^*(t) = \sum_{k=0}^{\infty} e(kT) \delta(t - kT) = e(t) \cdot \delta_T(t)$$

$$E^*(s) = \sum_{k=0}^{\infty} e(kT) e^{-kTs} = \sum_{\text{poles}} \text{Res} \left\{ E(\lambda) \frac{1}{(s-\lambda)} \right\}$$

Shannon's Theorem


Shannon's Theorem

Can reconstruct E from E^* if $w_1 \leq \frac{w_s}{2}$

Reconstruction: 1111 — 


Shannon's Theorem

Can reconstruct E from E^* if $\omega_s \leq \frac{\omega_s}{2}$

Reconstruction: 

Polynomial interpolation: $e_n(t) = e(kT) + e'(kT)(t - kT) + \dots$


ZOH: $e_n(t) = e(kT) \quad kT \leq t < (k+1)T$



$$G_{ZOH} = \frac{1 - e^{-sT}}{s}$$

F.O.H.: $e_n(t) = e(kT) + e'(kT)(t - kT)$

$$G_{FOH} = \left(\frac{1 - e^{-sT}}{s} \right)^2 \left(\frac{1+sT}{T} \right)$$



EECE 5610 Digital Control Systems

Lecture 9

Milad Siami

Assistant Professor of ECE

Email: m.siami@northeastern.edu



Northeastern University
College of Engineering

Open Loop Discrete Time Systems (chapter 4)

Open Loop Discrete Time Systems (chapter 4)

So far we have seen how to deal with ideal sampling (via * transform) and ideal data reconstruction.

Open Loop Discrete Time Systems (chapter 4)

So far we have seen how to deal with ideal sampling (via * transform) and ideal data reconstruction.

Now we will finally put these tools together to get discrete-time transfer functions.

Open Loop Discrete Time Systems (chapter 4)

So far we have seen how to deal with ideal sampling (via * transform) and ideal data reconstruction.

Now we will finally put these tools together to get discrete-time transfer functions.

The first step is to examine:

Open Loop Discrete Time Systems

(chapter 4)

So far we have seen how to deal with ideal sampling (via * transform) and ideal data reconstruction.

Now we will finally put these tools together to get discrete-time transfer functions.

The first step is to examine:

- Relationship between $E(z)$ and $E^*(s)$:

- Relationship between $E(z)$ and $E^*(s)$:

- Relationship between $E(z)$ and $E^*(s)$:

As we will see next $E^*(s)$ provides the link between $E(s)$ (continuous time) and $E(z)$ (discrete time). Let's compare definitions:

- Relationship between $E(z)$ and $E^*(s)$:

As we will see next $E^*(s)$ provides the link between $E(s)$ (continuous time) and $E(z)$ (discrete time). Let's compare definitions:

$$\left. \begin{aligned} E^*(s) &= \sum_{k=0}^{\infty} e(kT) e^{-kTs} \\ E(z) &= \sum_{k=0}^{\infty} e(kT) z^{-k} \end{aligned} \right\} \Rightarrow \boxed{E^*(s) = E(z)} \\ z = e^{TsT}$$

- Relationship between $E(z)$ and $E^*(s)$:

As we will see next $E^*(s)$ provides the link between $E(s)$ (continuous time) and $E(z)$ (discrete time). Let's compare definitions:

$$\left. \begin{aligned} E^*(s) &= \sum_{k=0}^{\infty} e(kT) e^{-kTs} \\ E(z) &= \sum_{k=0}^{\infty} e(kT) z^{-k} \end{aligned} \right\} \Rightarrow \boxed{E^*(s) = E(z)} \\ z = e^{sT}$$

(this relationship allows for considering the z-transform as a special case of the Laplace transform)

Suppose we sample a continuous time function and want to get its z-transform:

Suppose we sample a continuous time function and want to get its z-transform:

Old way:

- 1) expand $E(s)$ in partial fractions
- 2) find $e(t) = \mathcal{L}^{-1}[E(s)]$
- 3) find $e(kT)$
- 4) find $E(z) = \sum_0^{\infty} e(kT) z^{-kT}$

Suppose we sample a continuous time function and want to get its z-transform:

Old way:

- 1) expand $E(s)$ in partial fractions
- 2) find $e(t) = \mathcal{L}^{-1}[E(s)]$
- 3) find $e(kT)$
- 4) find $E(z) = \sum_0^{\infty} e(kT) z^{-kT}$

Alternative

- 1) find $E^*(s)$
- 2) $E(z) = E^*(s) \Big|_{z=e^{Ts}}$

Obviously the alternative works better only if we have an efficient way of computing $E^*(s)$ from $E(s)$. Here is where the residues formula becomes useful.

Recall that

$$E^*(s) = \sum_{\substack{\text{poles} \\ E(\lambda)}} \text{Res} \left[E(\lambda) \frac{1}{1 - e^{-T(s-\lambda)}} \right]$$

\Rightarrow

$$E(z) = \sum_{\substack{\text{poles} \\ E(\lambda)}} \left[\text{residues of } E(\lambda) \frac{1}{1 - \frac{1}{z} e^{AT}} \right]$$

Example:

$$E(s) = \frac{1}{(s+1)(s+z)}$$

Example:

$$E(s) = \frac{1}{(s+1)(s+z)}$$

old way:

1) $E(s) = \frac{1}{(s+1)} - \frac{1}{(s+z)}$

Example:

$$E(s) = \frac{1}{(s+1)(s+z)}$$

Old way:

$$1) E(s) = \frac{1}{(s+1)} - \frac{1}{(s+z)}$$

$$2) e(t) = \bar{e}^{-t} - \bar{e}^{-zt}$$

$$3) e(kT) = \bar{e}^{-kT} - \bar{e}^{-2kT}$$

$$4) E(z) = \sum_0^{\infty} \bar{e}^{-kT} \cdot \bar{z}^{-k} - \sum_0^{\infty} \bar{e}^{-2kT} \cdot \bar{z}^{-k}$$

$$= \frac{1}{1 - \frac{\bar{e}^{-T}}{z}} - \frac{1}{1 - \frac{\bar{e}^{-2T}}{z}}$$

Example:

$$E(s) = \frac{1}{(s+1)(s+z)}$$

Example:

$$E(s) = \frac{1}{(s+1)(s+z)}$$

"New" way

$$E(z) = \sum_{\substack{\lambda=-1 \\ \lambda=-2}} \text{Res} \left\{ \frac{1}{(\lambda+1)(\lambda+z)} \cdot \frac{1}{z - e^{\lambda\tau} \cdot \frac{1}{z}} \right\}$$

$$= \frac{1}{1 - \frac{e^{-\tau}}{z}} - \frac{1}{1 - \frac{e^{-2\tau}}{z}}$$

Q: We just stated that we can view the z-transform as a special case of the Laplace Transform (by using the \star transform). So, why do we need it? What's wrong with using E^x ?

Q: We just stated that we can view the z-transform as a special case of the Laplace Transform (by using the * transform). So, why do we need it? What's wrong with using $E^*(s)$?

A: Let's compare $E^*(s)$ versus $E(z)$. For the example above we have:

$$E^*(s) = \frac{e^{sT}(\bar{e}^{-T} - \bar{e}^{-2T})}{(e^{sT} - \bar{e}^{-T})(e^{sT} - \bar{e}^{-2T})}$$

$$E(z) = \frac{z(\bar{e}^{-T} - \bar{e}^{-2T})}{(z - \bar{e}^{-T})(z - \bar{e}^{-2T})}$$

Q: We just stated that we can view the z-transform as a special case of the Laplace Transform (by using the * transform). So, why do we need it? What's wrong with using $E^*(s)$?

A: Let's compare $E^*(s)$ versus $E(z)$. For the example above we have:

$$E^*(s) = \frac{e^{sT}(\bar{e}^{-T} - \bar{e}^{-2T})}{(e^{sT} - \bar{e}^{-T})(e^{sT} - \bar{e}^{-2T})}$$

$$E(z) = \frac{z(\bar{e}^{-T} - \bar{e}^{-2T})}{(z - \bar{e}^{-T})(z - \bar{e}^{-2T})}$$

∞ poles at $s = -1 \pm j\omega_s$

$$s = -2 \pm j\omega_s$$

2 poles: $z = e^{-T}$
 $z = e^{-2T}$

Q: We just stated that we can view the z-transform as a special case of the Laplace Transform (by using the * transform). So, why do we need it? What's wrong with using $E^*(s)$?

A: Let's compare $E^*(s)$ versus $E(z)$. For the example above we have:

$$E^*(s) = \frac{e^{sT}(\bar{e}^{-T} - \bar{e}^{-2T})}{(e^{sT} - \bar{e}^{-T})(e^{sT} - \bar{e}^{-2T})}$$

$$E(z) = \frac{z(\bar{e}^{-T} - \bar{e}^{-2T})}{(z - \bar{e}^{-T})(z - \bar{e}^{-2T})}$$

∞ poles at $s = -1 \pm j\omega_s$

$$s = -2 \pm j\omega_s$$

2 poles: $z = e^{-T}$
 $z = e^{-2T}$

\Rightarrow Any analysis based on pole/zeros will be far easier to carry out in the z-plane. We will see more advantages latter on.


- Pulse Transfer Function:

- Pulse Transfer Function:

Remember that our goal was to get a transfer function representation for


- Pulse Transfer Function:

Remember that our goal was to get a transfer function representation for



- Pulse Transfer Function:

Remember that our goal was to get a transfer function representation for




The idea is to group the plant & ZOH and consider it a single block $G(s)$

$$\Rightarrow \begin{array}{c} E(s) \\ \swarrow \\ E^*(s) \end{array} \quad \boxed{G(s)} \quad \text{and } C(s) = G(s) E^*(s)$$

- Pulse Transfer Function:


Remember that our goal was to get a transfer function representation for



The idea is to group the plant & ZOH and consider it a single block $G(s)$

$$\Rightarrow \begin{array}{c} E(s) \\ \swarrow \\ E^*(s) \end{array} \quad \boxed{G(s)} \quad C(s) \quad \text{and} \quad C(s) = G(s) E^*(s)$$

Assume now that we only look at the output at discrete time instants: kT



We want to find out and expression for $C^*(s)$ (as an intermediate step to finding $c(kT)$)

$$C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} c(s + jn\omega_s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s + jn\omega_s)$$

But E^* is periodic $\Rightarrow E^*(s + jn\omega_s) = E^*(s)$

$$\Rightarrow C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s) = E^*(s) \left[\frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) \right] = E^*(s) G^*(s)$$

We want to find out and expression for $C^*(s)$ (as an intermediate step to finding $c(kT)$)

$$C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} c(s + jn\omega_s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s + jn\omega_s)$$

But E^* is periodic $\Rightarrow E^*(s + jn\omega_s) = E^*(s)$

$$\Rightarrow C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s) = E^*(s) \left[\frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) \right] = E^*(s) G^*(s)$$

\Rightarrow We have just shown that:

$$C^*(s) = [G(s) E^*(s)]^* = G^*(s) E^*(s) \quad \#$$

We want to find out and expression for $C^*(s)$ (as an intermediate step to finding $c(kT)$)

$$C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} c(s + jn\omega_s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s + jn\omega_s)$$

But E^* is periodic $\Rightarrow E^*(s + jn\omega_s) = E^*(s)$

$$\Rightarrow C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s) = E^*(s) \left[\frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) \right] = E^*(s) G^*(s)$$

\Rightarrow We have just shown that:

$$\boxed{C^*(s) = [G(s) E^*(s)]^* = G^*(s) E^*(s)} \quad \#$$

Or, using Z-transforms:

$$\boxed{C(z) = G(z) E(z)}$$

We want to find out and expression for $C^*(s)$ (as an intermediate step to finding $c(kT)$)

$$C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} c(s + jn\omega_s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s + jn\omega_s)$$

But E^* is periodic $\Rightarrow E^*(s + jn\omega_s) = E^*(s)$

$$\Rightarrow C^*(s) = \frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) E^*(s) = E^*(s) \left[\frac{1}{T} \sum_{-\infty}^{+\infty} G(s + jn\omega_s) \right] = E^*(s) G^*(s)$$

\Rightarrow We have just shown that:

$$C^*(s) = [G(s) E^*(s)]^* = G^*(s) E^*(s) \quad \#$$


Or, using Z-transforms:

$$C(z) = G(z) E(z)$$

We will call $G(z)$ the pulse transfer function


(Roughly speaking: TF between sampled input & sampled output at the sampling instants)

Suppose that we want to find the TF of a simple plant:



Brute force approach: $C(s) = \frac{1}{(s+1)} F_s \xrightarrow{\mathcal{Z}^{-1}} \dot{c}(t) + c(t) = f_s(t)$

Suppose that we want to find the TF of a simple plant:



Brute force approach: $C(s) = \frac{1}{(s+1)} F_s \xrightarrow{\mathcal{L}^{-1}} \dot{c}(t) + c(t) = f_s(t)$

Solving this first order differential equation yields:

$$c(t) = A e^{-(t-kT)} + f(kT) \quad (\text{recall that } f_s(t) = f(kT) \quad kT \leq t < (k+1)T)$$

Now we need to impose the initial condition $c(t)|_{t=kT} = c(kT)$ and solve for A:

$$A = c(k\tau) - f(k\tau) \Rightarrow$$

$$c(t) = c(k\tau) e^{-(t-k\tau)} + [1 - e^{-(t-k\tau)}] f(k\tau) \quad k\tau \leq t < (k+1)\tau$$

$$A = c(kT) - f(kT) \Rightarrow$$

$$c(t) = c(kT) e^{-(t-kT)} + [1 - e^{-(t-kT)}] f(kT) \quad kT \leq t < (k+1)T$$

$$\Rightarrow c((k+1)T) = c(kT) e^{-T} + (1 - e^{-T}) f(kT)$$

↓ z transform

$$(z - e^{-T}) C(z) = (1 - e^{-T}) F(z) \Rightarrow \boxed{\frac{C(z)}{F(z)} = \frac{1 - e^{-T}}{z - e^{-T}}}$$

$$A = C(kT) - f(kT) \Rightarrow$$


$$c(t) = C(kT) e^{-(t-kT)} + [1 - e^{-(t-kT)}] f(kT) \quad kT \leq t < (k+1)T$$

$$\Rightarrow C((k+1)T) = C(kT) e^{-T} + (1 - e^{-T}) f(kT)$$

$\Downarrow z$ transform

$$(z - e^{-T}) C(z) = (1 - e^{-T}) F(z) \Rightarrow \boxed{\frac{C(z)}{F(z)} = \frac{1 - e^{-T}}{z - e^{-T}}}$$

Let's of work, even for a very simple plant! Let's try now our tools:



$$G(s) = \frac{1 - e^{-sT}}{s(s+1)} = \frac{C(s)}{F(s)}$$

$$\Rightarrow \frac{C(z)}{F(z)} = Z \left\{ \frac{1 - e^{-sT}}{s(s+1)} \right\} = \left[\frac{1 - e^{-sT}}{s(s+1)} \right]^* \Big|_{z=e^{sT}}$$

Note that we have a delay \Rightarrow (3-10) does not apply. However since the delay is an integer number of periods we can use the alternative formula:

$$\left[e^{-mT_s} G_1(s) \right]^* = e^{-mT_s} [G_1(s)]^* \Leftrightarrow Z \left[e^{-mT_s} G_1(s) \right]^* = \frac{1}{z^m} G_1(z)$$

Note that we have a delay \Rightarrow (3-10) does not apply. However since the delay is an integer number of periods we can use the alternative formula:

$$\left[e^{-mTs} G_1(s) \right]^* = e^{-mTs} [G_1(s)]^* \Leftrightarrow Z \left[e^{-mTs} G_1(s) \right]^* = \frac{1}{z^m} G_1(z)$$

In this case we have: $G_1(s) = \frac{1}{s(s+1)} \Leftrightarrow G_1(z) = \sum_{\lambda=0}^{\infty} \text{Res} \left[\frac{1}{\lambda(\lambda+1)} \cdot \frac{1}{1 - e^{\lambda T}} \right]$

$$= \frac{1}{1 - \frac{1}{z}} - \frac{1}{1 - \bar{e}^T/z} = \frac{z(1 - \bar{e}^T)}{(z-1)(z - \bar{e}^T)}$$

Note that we have a delay \Rightarrow (3-10) does not apply. However since the delay is an integer number of periods we can use the alternative formula:

$$\left[e^{-mTs} G_1(s) \right]^* = e^{-mTs} [G_1(s)]^* \Leftrightarrow Z \left[e^{-mTs} G_1(s) \right]^* = \frac{1}{z^m} G_1(z)$$

In this case we have: $G_1(s) = \frac{1}{s(s+1)} \Leftrightarrow G_1(z) = \sum_{\lambda=0}^{\infty} \text{Res} \left[\frac{1}{\lambda(\lambda+1)} \cdot \frac{1}{1 - e^{\lambda T}} \right]$

$$= \frac{1}{1 - \frac{1}{z}} - \frac{1}{1 - \bar{e}^T/z} = \frac{z(z - \bar{e}^T)}{(z-1)(z - \bar{e}^T)}$$

and $G(z) = G_1(z) - \frac{1}{z} G_1(z) = \left(\frac{z-1}{z} \right) G_1(z) =$

$$\boxed{\frac{1 - \bar{e}^T}{z - \bar{e}^T}}$$

same as
before

(but we did not have to solve a differential eq.)

Assume now that the input is a step: $f(kT) = 1, 1, \dots$

$$F(z) = \frac{z}{z-1}$$

$$\Rightarrow C(z) = G(z) F(z) = \frac{z}{(z-1)} \frac{(1-e^{-T})}{(z-e^{-T})} = \frac{z}{z-1} - \frac{z}{z-e^{-T}}$$

Going back to the time domain we get:

$$c(kT) = \bar{\mathcal{Z}}^{-1}[C(z)] = \bar{\mathcal{Z}}^{-1}\left[\frac{z}{z-1} - \frac{z}{z-e^{-T}}\right] = 1 - e^{-kT} \#$$

Assume now that the input is a step: $f(kT) = 1, 1, \dots$

$$F(z) = \frac{z}{z-1}$$


$$\Rightarrow C(z) = G(z) F(z) = \frac{z}{(z-1)} \frac{(1-e^{-T})}{(z-e^{-T})} = \frac{z}{z-1} - \frac{z}{z-e^{-T}}$$

Going back to the time domain we get:


$$c(kT) = \bar{\mathcal{Z}}^{-1}[C(z)] = \bar{\mathcal{Z}}^{-1}\left[\frac{z}{z-1} - \frac{z}{z-e^{-T}}\right] = 1 - e^{-kT} \#$$

(Note: you can get the same result from residues, without having to do partial fractions:

$$c_k = \sum_{\substack{z=1 \\ z=e^{-T}}} \text{Res} \left\{ z^{k-1} \frac{z(1-e^{-T})}{(z-1)(z-e^{-T})} \right\} = \left(\frac{1-e^{-T}}{1-e^{-T}} \right)^k + e^{-kT} \left(\frac{1-e^{-T}}{e^{-T}-1} \right) = 1 - e^{-kT} \#$$



Sanity check: Physically



Important: You can get $c(kT)$ from $c(t)$ but the converse does not work. You cannot recover $c(t)$ from $c(kT)$.

(Obvious, since $c(kT)$ does not contain information about what happens in between samples)

• Definition:

DC gain:

$$\frac{\lim_{k \rightarrow \infty} c_k}{\lim_{k \rightarrow \infty} F_k} = \frac{c_{ss}}{F_{ss}} = \lim_{z \rightarrow 1} \frac{(z-1) C(z)}{F_{ss}}$$

$$= \lim_{z \rightarrow 1} (z-1) \frac{G(z) F(z)}{F_{ss}} = \lim_{z \rightarrow 1} \frac{(z-1) G(z) F_{ss}}{F_{ss} z (z-1)}$$
$$= G(1)$$

⇒

DC gain: $G(1)$

• Definition:

DC gain:

$$\frac{\lim_{k \rightarrow \infty} c_k}{\lim_{k \rightarrow \infty} F_k} = \frac{c_{ss}}{F_{ss}} = \lim_{z \rightarrow 1} \frac{(z-1) G(z)}{F_{ss}}$$

$$= \lim_{z \rightarrow 1} \frac{(z-1) G(z) F(z)}{F_{ss}} = \lim_{z \rightarrow 1} \frac{(z-1) \cancel{G(z)} \cancel{F(z)}}{\cancel{F_{ss}} \frac{z}{(z-1)}} = G(1)$$


\Rightarrow

DC gain: $G(1)$

(compare with continuous time: DC gain = $G(s)|_{s=0}$)

but then again: $z = e^{Ts} \Rightarrow s=0$ gets mapped to $z=1$

- Other configurations:




$$C(s) = G_2(s) A^*(s) \quad A(s) = G_1(s) E^*(s) \Rightarrow A^* = (G_1 E^*)^* = G_1^* E^*$$

$$C^*(s) = G_2^* A^* = G_2^*(s) G_1^*(s) E^*(s)$$



$C(z) = G_2(z) G_1(z) E(z)$	or	$G(z) = G_1(z) \cdot G_2(z)$
-----------------------------	----	------------------------------


Key feature: we have an ideal sampler between G_1 & G_2



$$C(s) = G_2(s) G_1(s) E^*(s) \Rightarrow C^*(s) = [G_1 \cdot G_2]^* E^*(s) \quad \text{or}$$

$$C(z) = Z \{ G_1 \cdot G_2 \} \cdot E(z) \Rightarrow \boxed{G(z) = Z [G_1 \cdot G_2]}$$


Note : $Z [G_1 G_2] \neq G_1(z) G_2(z)$!!



$$C^* = [G_2 \ A^*]^*$$


$$A = G_1 E \Rightarrow A^* = [G_1 \ E]^*$$

$$C^* = G_2^* [G_1 E]^*$$



$$C = G_2 A^* \Rightarrow C^* = G_2^* [G_1 E]^*$$

For this system a transfer function cannot be written!
 The reason is that you can't factor $E(z)$ out of $[G_1 E](z)$



$$C = G_2 A^* \Rightarrow C^* = G_2^* [G_1 E]^*$$


For this system a transfer function cannot be written!
 The reason is that you can't factor $E(z)$ out of $[G_1 E](z)$

Physical reason:

When you have $\overset{E}{\overbrace{\quad}} \overset{E^*}{\overbrace{\quad}} \boxed{G} \overset{C}{\overbrace{\quad}}$, E^* contains information about E

only at the sampling instants. \Rightarrow When you compute C^* you can factor E^* out.

On the other hand, if you have something like this:



$$A(s) = G(s) E(s)$$

$$a(t) = \int_0^t g(t-z) e(z) dz \Rightarrow$$


to compute A^* (and latter C^*) you need information about $e(t)$ at all times, not just the sampling instants.

Important consequence : If you want to have a discrete T.F you have to select as your unknowns the inputs to the sampler

This variables will always "come free" after the equation sampling process and give a set of starred variables for which we can solve.

Important consequence: If you want to have a discrete T.F. you have to select as your unknowns the inputs to the sampler

This variables will always "come free" after the equation sampling process and give a set of starred variables for which we can solve.



$$E(s) = R - G_2 M^*$$

$$E^* = R^* - [G_2 M]^* = R^* - G_2^* M^*$$

$$M = (G_3 H) E^* \Rightarrow M^* = (G_3 H)^* E^*$$

$$E^* = R^* G_2^* [G_3 H]^* E^*$$

$$\Rightarrow E^* = \frac{R^*}{1 + (G_3 H)^* G_2^*}$$

Or:

$$\frac{E(z)}{R(z)} = \frac{1}{1 + [G_3 H](z) G_2(z)}$$

To obtain Y we can use the equation: $Y(s) = H E^* \Rightarrow Y^* = H^* E^*$

$$\Rightarrow \frac{Y^*}{R^*} = \frac{H^*}{1 + (G_1 H)^* G_2^*} \Leftrightarrow$$

$$\boxed{\frac{Y(z)}{R(z)} = \frac{H(z)}{1 + (H G_1)(z) G_2(z)}}$$

Note that in this case we have a TF. This is because R goes right through a sampler before entering other blocks.

To obtain Y we can use the equation: $Y(s) = H E^* \Rightarrow Y^* = H^* E^*$

$$\Rightarrow \frac{Y^*}{R^*} = \frac{H^*}{1 + (G_1 H)^* G_2^*} \Leftrightarrow$$

$$\boxed{\frac{Y(z)}{R(z)} = \frac{H(z)}{1 + (HG_1)(z)G_2(z)}}$$

Note that in this case we have a TF. This is because R goes right through a sampler before entering other blocks.

- Open-loop Systems with Digital Filters

To obtain Y we can use the equation: $Y(s) = H E^* \Rightarrow Y^* = H^* E^*$


$$\Rightarrow \frac{Y^*}{R^*} = \frac{H^*}{1 + (G_1 H)^* G_2^*} \Leftrightarrow$$

$$\boxed{\frac{Y(z)}{R(z)} = \frac{H(z)}{1 + (HG_1)(z)G_2(z)}}$$

Note that in this case we have a TF. This is because R goes right through a sampler before entering other blocks.

- Open-loop Systems with Digital Filters

We consider now the case where the sampled-data system contains a digital filter




$$M(z) = D(z)E(z)$$

$$M^*(s) = D^*(s)E^*(s)$$

- Open-loop Systems with Digital Filters


We consider now the case where the sampled-data system contains a digital filter




$$M(z) = D(z)E(z)$$

$$M^*(s) = D^*(s)E^*(s)$$


Physically:



We will assume that the D/A can be represented as a zero order hold




(Recall that $G_{h_0} = \frac{1 - e^{-sT}}{s}$)



$$C(s) = \underbrace{G_{h_0}(s) \cdot G_p(s)}_{G(s)} M^*(s) \Rightarrow C(z) = G(z) M(z) = G(z) D(z) \bar{E}(z)$$

(Recall that $G_{h_0} = \frac{1 - e^{-sT}}{s}$)



$$C(s) = \underbrace{G_{h_0}(s) \cdot G_p(s)}_{G(s)} M^*(s) \Rightarrow C(z) = G(z) M(z) = G(z) D(z) \bar{E}(z)$$

Example: Suppose that the digital filter is given by the following diff. eq.


$$m(kT) = 2e(kT) - e[(k-1)T]$$

$$M(z) = 2E(z) - \frac{E(z)}{z} = \frac{2z-1}{z} E(z)$$

$$\Rightarrow D(z) = \frac{M}{E} = \boxed{\frac{2z-1}{z}}$$


$$G_p(s) = \frac{1}{(s+1)} \Rightarrow G(s) = G_{h_0} G_p = \frac{1-e^{-sT}}{s(s+1)}$$

$$\begin{aligned} G(z) &= \left(1 - \frac{1}{z}\right) \mathcal{Z} \left[\frac{1}{s(s+1)} \right] = \left(1 - \frac{1}{z}\right) \left[\frac{1}{z-1/z} - \frac{1}{z-e^{-T}/z} \right] \\ &= \frac{1-e^{-T}}{z-e^{-T}} \end{aligned}$$



$$G_p(s) = \frac{1}{(s+1)} \Rightarrow G(s) = G_{h_0} G_p = \frac{1-e^{-sT}}{s(s+1)}$$

$$\begin{aligned} G(z) &= \left(1 - \frac{1}{z}\right) Z\left[\frac{1}{s(s+1)}\right] = \left(1 - \frac{1}{z}\right) \left[\frac{1}{z-1/z} - \frac{1}{z-e^{-T}/z} \right] \\ &= \frac{1-e^{-T}}{z-e^{-T}} \end{aligned}$$



Assume that $E(z)$ is a step: $E(z) = \frac{z}{z-1} \Rightarrow$

$$C(z) = \left(\frac{1-e^{-T}}{z-e^{-T}}\right) \left(\frac{2z-1}{z}\right) \left(\frac{z}{z-1}\right)$$

From here we can get $c(kT)$ either by doing partial fraction expansion or using the residues formula.

Effect of T_s

Recall they $C^*(s)$ or $C(z)$ gives you information only on what happens at the sampling instants, but not in-between.

Effect of T_s

Recall they $C^*(s)$ or $C(z)$ gives you information only on what happens at the sampling instants, but not in-between.

Q: Is this a problem?

Effect of T_s

Recall that $C^*(s)$ or $C(z)$ gives you information only on what happens at the sampling instants, but not in-between.

Q: Is this a problem?

A: Depends on how fast the dynamics of your plant are, compared to the sampling rate

- Slow Plant = Large Sample Rate
- Fast Plant = Small Sample Rate

Example :

$$G_p(s) = \frac{25}{s^2 + 2s + 25}$$

$$\Rightarrow \omega_n^2 = 25 \quad (\omega_n = 5)$$

$$\gamma = 0.2 \quad (\text{under damped})$$

Example : $G_p(s) = \frac{25}{s^2 + 2s + 25} \Rightarrow \omega_n^2 = 25 \quad (\omega_n = 5)$

$\gamma = 0.2 \quad (\text{under damped})$

Analyze step response of original plant

It can be shown that if we sample at $T=0.1$ and $T=1$ we get the following discrete time equivalents:

$$G(z) = Z \left\{ \left(\frac{1 - e^{-sT}}{s} \right) \cdot G_p(s) \right\} = \left(1 - \frac{1}{z} \right) Z \left[\frac{25}{s(s^2 + 2s + 25)} \right]$$

$$G_{T=1} = \frac{Z - 0.007}{z^2 - 0.1365z + 0.1353}$$

$$G_{T=0.1} = \frac{0.115z - 0.107}{z^2 - 1.6z + 0.82}$$

To see differences between these Plants, look at the step response to see how different sample rate affect them