File SFTOC.DOC contains the following bookmarks. Select the topic you are trying to find from the list and double click the highlighted text.

CustomDictionaryForWord DocumentationFileList
GettingStarted MarginRecommendation
NavigationTips PrintingTheDocumentation

PrintingHighlightedMaterial PrintingOnA4Paper
PrintingRangeOfPages PrintingTheEntireDocument TemplateFileForWord
UsingTheEditGoToMenu UsingTheHypertextLinks

UpdatingTheTableOfContents WordSettings

WordViewerSettings

Quick links to other files:

<u>SFINTRO.DOC</u> Introduction, problem variables, SF.INI settings, technical support

<u>SFFILES.DOC</u> Descriptions of input and output files

SFCODES.DOC Autofish, Automesh, Fish, CFish, Poisson, Pandira

SFPOSTP.DOC WSFplot, SFO, SF7, Force

SFCODES2.DOC Cavity tuning programs XXXfish (CCLfish, DTLfish, etc.)
Plotting programs Quikplot, Tablplot, and utility programs

<u>SFEXMPL1.DOC</u> Example files for Fish, CFish, and Autofish <u>SFEXMPL2.DOC</u> Example files for Poisson and Pandira

SFEXMPL3.DOC Example files for tuning programs

<u>SFPHYS1.DOC</u> Theory of electrostatics and magnetostatics <u>SFPHYS2.DOC</u> Properties of static magnetic and electric fields

SFPHYS3.DOC Boundary conditions and symmetries

SFPHYS4.DOC Numerical methods in Poisson and Pandira

SFPHYS5.DOC RF cavity theory

Poisson Superfish

James H. Billen and Lloyd M. Young

Documentation by James H. Billen

Los Alamos National Laboratory

Poisson Superfish LA-UR-96-1834

Copyright and disclaimer

Copyright, 1985-2006, The Regents of the University of California.

This software was produced under U.S. Government contract W-7405-ENG-36 by Los Alamos National Laboratory, which is operated by the University of California for the U.S. Department of Energy. Neither the Government nor the University makes any warranty, express or implied, or assumes any liability or responsibility for the use of this software.

Acknowledgments

The authors of this version of Poisson Superfish wish to acknowledge the extremely important contributions of Ronald Holsinger and Klaus Halbach, who wrote the original version of these codes in the late 1960s and early 1970s. In addition, the authors have benefited from the work of several LAACG members who have since retired from Los Alamos National Laboratory, including Richard K. Cooper (former Code Group leader), Mary T. Menzel, Grenfell Boicourt, Therese Barts, Jean Merson, Gary Rodenz, and John L. Warren. John Warren led the earlier documentation effort that resulted in two volumes published in 1987. Several chapters related to the physics in the codes from John Warren's treatment have been reproduced in this document. The authors thank the many users of these codes who have pointed out bugs and made suggestions for additional features in this version. The authors are especially grateful to Richard K. Cooper for his very careful proofreading of this documentation.

This documentation was produced by the Los Alamos Accelerator Code Group (LAACG) at Los Alamos National Laboratory. The activities of the LAACG are supported by the US Department of Energy, Office of Energy Research, through the Division of High Energy Physics, Division of Nuclear Physics, and Division of Mathematics, Information, and Computational Sciences.

Original release: January 10, 1996 Revision date (version 7.17): January 13, 2006

Table of Contents

I. How To Use This Document	1
A. Getting started	1
B. List of the documentation files	1
C. Suggestions for viewing the documentation	2
1. Microsoft Word template and dictionary files	3
2. Settings in Microsoft Word	3
3. Settings in Microsoft Word Viewer	3
4. Using the table of contents	
5. Using the hypertext links	
6. Using the Edit, Go To menu	4
D. Printing sections of this documentation	5
1. Printing the entire document	
a. Margin settings	
b. Printing on A4 paper	
3. Printing a range of pages	
4. Printing highlighted material	6
E. Updating the table of contents	
II. Poisson Superfish software installation	
A. Machine requirements	
1. Performance issues	9
B. Installation directory and subdirectories	10
1. Subdirectory LANL\Docs, documentation files	10
2. Subdirectory LANL\Examples, sample input files	
3. Subdirectory LANL\DeveloperFiles, files for code developers	11
C. Other files in the LANL directory	11
D. The Lahey/Fujitsu Fortran compiler and Winteracter library	12
E. Technical support and code updates	12
1. Electronic mail support address: Superfish@lanl.gov	
2. Email discussion group	13
3. Obtaining updated installation files	13
4. Email notification of new features and bug fixes	14
F. Files provided for program developers	14
1. Using the dynamic link library	
a. Function INTERP	
b. Functions I_Variable and R_Variable	
c. Function GetTitled. Multiple DLLs	
e. Example files	
2. Calling Fortran LF95 library routines	
a Batch files for running the sample programs	20

b. LF95.Fig, configuration file	
c. INCLUDE file T35ARRAY.INC	
d. Fortran modules	21
e. RDTape35 and RDRECORD1, subroutines for reading solution files	
f. Interpolate, subroutine for interpolating fields	36
III. Introduction to Poisson Superfish	44
A. History of the development of Poisson Superfish	
1. Code development under LAACG	
2. Features added in version 5	
a. User interface improvements	
b. Automesh improvements	
c. RF solver improvements	49
d. New field interpolator	51
e. Memory management and program limits	
f. Postprocessor improvements g. New programs	
3. Features added in version 6	
a. Source code organization b. Installation program	55
c. Program WSFplot	
d. Programs Quikplot and Tablplot	56 56
e. Unlimited number of material tables and error checking of material data	
f. Force code improvements	
g. Field interpolator improvements	57
h. Program MK_SFINI	
i. Tuning-code companion programs	
4. Features added in version 7	
a. Conversion of binary solution files to version 7 format	
b. Automesh improvements	58
c. Larger problems supported	59
d. Numbered warning messagese. Dynamic link library containing the field interpolator	59
	=0
B. References	
1. Published references to Poisson Superfish	
2. Other references	60
C. Terminology	61
1. Superfish codes	61
2. Solver program	61
3. Tuning program	61
4. Superfish problem or Poisson problem	61
5. Postprocessor	62
6. Plotting program	62
7. SOR	62
8. Binary solution file	
9. Configuration file or initialization file	
10. Boundary conditions	
11. Beta, the symbol β	
12. Beta-lambda, the product βλ	
13. Cavity	
14. CCDTL	
15. CCI	63

16. Cell	63
17. Coupling	64
18. Coupling cell or coupling cavity	64
19. DTL	64
20. Gamma, the symbol γ	64
21. Gap	
22. Geometric β	
23. Graded β	
24. Kilpatrick field	
25. Modes	
a. Cavity modes	
b. Structure modes	66
26. Post coupler	
27. Quality factor Q	
28. RFQ	
29. Shunt impedance	
30. Skin depth	
31. Transit-time factor	67
D. Summary of the Poisson Superfish codes	68
1. Autofish	69
2. Automesh	69
3. Lattice	69
4. Fish	
5. CFish	69
6. Poisson	70
7. Pandira	
8. WSFplot	
9. SFO	
10. SF7	
11. Force	
12. DTLfish	71
13. DTLCells	72
14. CCLfish	72
15. CCLCells	
16. CDTfish	72
17. ELLfish	72
18. ELLCAV	73
19. MDTfish	73
20. MDTCells	73
21. RFQfish	73
22. SCCfish	
23. Quikplot	
24. Tablplot	
25. List35	74
26. SFOtable	74
27. SegField	74
28. Beta	74
29. Kilpat	
30. ConvertF	74
31 FScale	74

32. SF8	75
33. MK_SFINI	75
E. Problem variables	76
1. Problem variables for Fish and CFish	7 <i>6</i>
2. Problem variables for Poisson and Pandira	79
F. Configuring Poisson Superfish features: SF.INI	83
1. Internal Arrays setting	 86
2. Saving file TAPE36	86
3. Drives for scratch files and storing scratch data in memory	86
4. Limiting memory available to certain programs	
5. Forcing programs to always browse for an input file	88
6. Setting the binary solution file extension	
7. Turning on and off selected warning messages	
8. Setting the hardcopy graphics type	92
9. Setting initial display preferences for WSFplot	93
10. Setting the interval between contour lines in WSFplot	
11. Saving the WSFplot field contours	
12. Choosing the plotting code preference file	
13. Configuring program Quikplot and Tablplot	
14. Setting the filename length for SF7 output files	96
15. Setting precision of field data printed in output text files	96
16. Including field-interpolator fitting data with SF7 results	97
17. Configuring SF7 to write real and imaginary CFish fields	97
18. Setting default values for the SF7 dialog window	97
19. Controlling field normalization in SF7 when generating Parmela data	98
20. Controlling some behavior of the field interpolator	
22. Writing the file FishScan.TBL in Fish or CFish	
23. Create file CircleFit.QKP during CFish resonance	
24. Writing Poisson or Pandira field data for program Parmela	
25. Writing permeability tables in Poisson and Pandira	
26. Calculating stored energy in Poisson and Pandira	
27. Configuring particle velocity settings for SFO and tuning programs	
28. Calculating fields on Dirichlet boundaries in SFO	
29. Writing transit-time data for Parmila in SFO	
30. Saving the binary solution files during tuning program sessions	
31. Setting the preferred normalization method in tuning codes	
32. Making CDTfish compute transit-time factors at the geometric center	
33. Setting a maximum tuning-ring thickness in CCLfish and CDTfish	105
34. Deleting or saving no-ring Superfish files in CCLfish and CDTfish	106
35. Controlling line regions through the drift tube in DTLfish and MDTfish	106
36. Computing Slater-Perturbation Frequency Shifts in WSFplot and SF7	106
G. Precision of variables in Poisson Superfish	107
H. Field interpolation from the solution arrays	108
1. Problems with Cartesian (XY) coordinates use functions 17 to 25	 111
a. Function 17: general function for interior non-boundary points	
b. Function 18: vertical Neumann boundary	111
c. Function 19: horizontal Neumann boundary	111
d. Function 20: vertical Neumann and horizontal Neumann boundaries	111

e. Function 21: vertical Dirichlet and horizontal Dirichlet boundaries	
f. Function 22: vertical Dirichlet boundary	
g. Function 23: horizontal Dirichlet boundary	112
h. Function 24: vertical Neumann and horizontal Dirichlet boundaries	
i. Function 25: vertical Dirichlet and horizontal Neumann boundaries	
2. Electrostatic problems with cylindrical symmetry use functions 27 to 29	112
a. Function 27: general function for interior non-boundary points	113
b. Function 28: horizontal Dirichlet boundary	113
c. Function 29: horizontal Neumann boundary	113
3. Magnetostatic problems with cylindrical coordinates use functions 37 to 39	
a. Function 37: interior non-boundary points	114
b. Function 38: horizontal Dirichlet boundary	114
c. Function 39: horizontal Neumann boundary	
4. RF problems with cylindrical coordinates use functions 57 to 68	114
a. Function 57: general function for interior non-boundary points	114
b. Function 58: horizontal Neumann boundary	115
c. Function 59: vertical Neumann boundary	115
d. Function 60: horizontal Neumann and vertical Neumann boundaries	115
e. Function 61: horizontal Dirichlet and vertical Dirichlet boundaries	
f. Function 62: horizontal Dirichlet boundary at nonzero R	
g. Function 63: vertical Dirichlet boundary	
h. Function 64: horizontal Neumann and vertical Dirichlet boundaries	115
i. Function 65: horizontal Dirichlet and vertical Neumann boundaries	
j. Function 66: near R = 0 and no other boundaries	116
k. Function 67: near R = 0 and a vertical Neumann boundary	116
1. Function 68: near R = 0 and a vertical Dirichlet boundary	116
I. Poisson Superfish program limits	116
J. Temporary data arrays used by Fish, CFish, and Pandira	117
1. Using a correct file	110
 Using a scratch file Forcing the codes to use a scratch file instead of memory 	110
3. Deleting unerased scratch files	118
I. Files and Filename Conventions	121
A. Introduction	
	121
1. Summary of the input and output files	121
 Summary of the input and output files Naming files 	121 122
 Summary of the input and output files Naming files Registered file types and right-button menus 	121 122 123
Summary of the input and output files Naming files Registered file types and right-button menus Opening input files on startup	121 122 123 124
1. Summary of the input and output files	121 122 123 124 125
1. Summary of the input and output files	121 122 123 124 125 125
1. Summary of the input and output files	121 122 123 124 125 125 125
1. Summary of the input and output files	121 122 123 124 125 125 126 128
1. Summary of the input and output files	121 122 123 124 125 125 126 128
1. Summary of the input and output files	121 122 123 124 125 125 126 128 128
1. Summary of the input and output files	121 122 123 124 125 125 126 128 128 128
1. Summary of the input and output files 2. Naming files 3. Registered file types and right-button menus 4. Opening input files on startup a. Starting with an input filename b. Starting with more than one input filename c. Starting without an input filename 5. Using comments to document input files 6. A word about text editors and output-file fonts B. Automesh input file C. Other input files 1. T36 file, modifying the Automesh-generated boundaries	121 122 123 124 125 125 126 128 128 128 129
1. Summary of the input and output files 2. Naming files 3. Registered file types and right-button menus 4. Opening input files on startup a. Starting with an input filename b. Starting with more than one input filename c. Starting without an input filename 5. Using comments to document input files 6. A word about text editors and output-file fonts B. Automesh input file C. Other input files 1. T36 file, modifying the Automesh-generated boundaries 2. SEG file, input file for program SFO	121 122 123 124 125 125 126 128 128 128 129 130
1. Summary of the input and output files 2. Naming files 3. Registered file types and right-button menus 4. Opening input files on startup a. Starting with an input filename b. Starting with more than one input filename c. Starting without an input filename 5. Using comments to document input files 6. A word about text editors and output-file fonts B. Automesh input file C. Other input files 1. T36 file, modifying the Automesh-generated boundaries 2. SEG file, input file for program SFO 3. IN7, input file for program SF7	121 122 123 124 125 125 126 128 128 128 129 130 130
1. Summary of the input and output files 2. Naming files 3. Registered file types and right-button menus 4. Opening input files on startup a. Starting with an input filename b. Starting with more than one input filename c. Starting without an input filename 5. Using comments to document input files 6. A word about text editors and output-file fonts B. Automesh input file C. Other input files 1. T36 file, modifying the Automesh-generated boundaries 2. SEG file, input file for program SFO	121 122 123 124 125 125 126 128 128 128 129 130 130 130

D. Files for sharing data among codes	131
1. The Poisson Superfish binary solution file	
2. TAPE36, boundary-point data file	
3. TAPE37, temporary Automesh file	
E. Poisson Superfish output text files	133
1. OUTAUT.TXT, the Automesh output file	
2. OUTFIS.TXT, the Fish and CFish output file	
3. OUTPOLTXT and OUTPAN.TXT, Poisson and Pandira output files	133
4. OUTFOR.TXT, the Force output file	
	134
6. OUTSF7.TXT, the SF7 output file	
F. Hard copy graphics files	
G. Input files for plotting programs	135
1. OUTPOI.TBL and OUTPAN.TBL, Tablplot files of interpolated fields	
2. FishScan.TBL, Fish and CFish frequency-scan output file	
3. Transit.TBL, transit-time data versus longitudinal position	
4. TBeta.TBL, transit-time data versus particle velocity	
5. Plot files created by SF7	138
6. Files that store current screen settings	139
H. Files for other programs	139
1. Data files for program Parmela	
a. SF7-interpolated fields for Parmela	
b. Poisson- and Pandira-interpolated fields for Parmela	141
2. Input file for the electron-gun code EGUN	
3. PMI file, transit-time data for program Parmila	142
a. Example PMI file for a DTL half cell	
b. Example PMI file for a 3-gap CCDTL	
I. Sample batch command files	145
V. Autofish: Combined Automesh, Fish, and SFO	147
VI. Automesh: the Poisson Superfish Mesh Generator	148
•	1 40
A. Starting program Automesh	
B. Automesh files and filename conventions	
C. Input file of namelist variables	149
1. REG namelist: Input of region data and problem parameters	
a. Variables that can only appear in the first REG namelist	
b. Entry of line-region array variables	153
c. Default values for the mesh increments DX and DY	
d. Variables that can appear in the first and any other REG namelist	155
e. Material numbers	155
PO namelist: Input of boundary-point data in Automesh	
a. Problem boundaries, requirements for region 1	130 157
b. Straight line segments	
c. Circular and elliptical arc segments	

d. Hyperbolic segments	158
	158
3. MT namelist: Input of material data in Automesh	
a. Material data for rf problems	161
b. Material data for electrostatic problems	
c. Isotropic magnetic materialsd. Anisotropic and permanent-magnet materials	163
e. Anisotropic material with variable easy axis direction	
f. Permanent magnets and real currents	167
4. POA namelist: Input of single-point boundary values	168
D. Sample Automesh input files	
1. Superfish pillbox cavity	169
2. Example with an elliptical segment	170
3. Poisson and Pandira H-shaped magnet	170
E. Solving for rf and electrostatic fields in the same geometry	171
F. Entering coordinate data in units other than centimeters	172
G. Specifying boundary conditions and fixed potentials	174
Boundary conditions at the edges of the problem geometry	174
2. Using IBOUND to indicate boundary conditions	
3. Using IBOUND to indicate fixed-potential values	175
4. Using the POA namelist to indicate a single-point fixed-potential	
5. Simulating a floating electrode	175
H. Specifying rectangular or cylindrical coordinate systems	175
I. Complementary solutions for rf cavities	175
J. SF.INI settings for Automesh	178
K. Mesh optimization considerations	
Using line regions to control the mesh size in Automesh	
2. Choosing the mesh size	
3. Other tips related to meshing the problem	
4. Mesh modification option	
L. Drive points for Superfish problems	
1. Specifying a single drive point	
2. Line drives for CFish problems	183
3. Wavelength and starting phase for a sinusoidal drive line	
M. Overlapping and adjacent regions	184
N. Indicating the triangle type used to fill the mesh	185
1. Bad triangles: overlapping, zero-area, and near zero-area triangles	
a. Fatal errors, overlapping triangles or zero-area triangles b. Nonfatal errors, near zero-area triangles	
O. Indicating the cavity type for program Parmila	
P. Controlling the relaxation order for the mesh points	
Q. How Automesh initializes the potential	
D. Variables calculated by Automosh	

1. NREG and MAXPPR, number of regions and maximum points per region	190
2. XMING, XMAXG, YMING, and YMAXG, the problem boundaries	
3. KMAX and LMAX, the number of mesh intervals along each coordinate	190
4. ITOT, the total number of mesh points in the problem	191
5. DX1, the X mesh interval in the first region	191
6. DXMIN and DYMIN, the smallest mesh intervals	191
7. XDRI, YDRI, the drive-point location for Superfish problems	
8. XBZERO, YBZERO, physical point where B = BDES in Poisson	
9. KBZERO,LBZERO, logical point where B = BDES in Poisson	
10. IPERM, indicates if a Pandira problem includes real currents	192
11. NSEG, the number of boundary segments	192
12. NPBOUND, the number of points along all boundary segments	
13. NAIR, the number of mesh points in empty space	192
14. NFE, the number of mesh points in iron	192
15. NINTER, the number of mesh points on an interface	
16. NBND, the number of mesh points on Dirichlet boundaries	192
17. NSPL, the number of mesh points with user-defined fixed-potential	
18. NPINP, the number of mesh points in the problem	193
19. NWMAX, the number of points for recalculating couplings	
20. NGMAX and NGSAM, coupling array counters	
21. NPONTS, the number of unknown relaxation points	
22. LCYCLE, the number of relaxation iterations	
23. CLIGHT and PI, the speed of light and the number π	
24. EPS0 and FMU0, permittivity and permeability of free space	
25. SPOSG, SNEGG, STOTG, currents at generation for magnet problems	
26. XYAREA and VOLUME, area and volume in the problem geometry	
27. TRIMIN, TRIMAX, and TRIAVG, size of mesh triangles	194
S. Automesh error messages	194
VII. Fish and CFish, Radio-Frequency Field Solvers	200
A. Starting and stopping Fish and CFish	200
1. Using the Esc key to stop Fish or CFish early	
B. Fish and CFish files and filename conventions	
C. Data entries for Fish and CFish	201
1. Controlling pivoting in matrix inversion routines	
2. Setting up a frequency scan	
D. The Superfish root finder	
1. Root finder in program Fish	
2. Root finder in tuning programs	204
3. Root finder in program CFish	205
E. Convergence criteria in the Fish and CFish solvers	206
F. Variables calculated by Fish and CFish	207
1. DSLOPE, the slope of the D(k²) function	
2. FREQ, the resonant frequency	208
3. XK0 and XKSQ, the wave number k and its square k ²	208
4. DKSQ, the proposed change in k ² at the last iteration	208
5. ERG, the Fish and CFish stored-energy integral	

7. RESIK, the ratio $ D(k^2) /k^2$ at the end of the last iteration	
8. ICYCLE, the number of the last completed iteration	
9. Q2I, the ratio 1/2Q calculated by CFish for lossy materials	209
G. Fish and CFish exit error codes	209
VIII. Poisson and Pandira, Static Field Solvers	211
A. Starting and stopping Poisson and Pandira	211
1. Using the Esc key to stop Poisson or Pandira early	211
B. Files and filename conventions	211
C. Data entries for Poisson and Pandira	212
D. Input options for Poisson and Pandira	213
1. Permeability tables	214
2. Listing the fast-interpolation material tables	216
3. Using the stacking-factor correction	216
4. Adjusting fields for a particular value on a mesh point	218
5. Computing a series of solutions for a range of current multipliers	
6. Some properties of permanent-magnet materials	220
7. Initialization for permanent-magnet problems	
8. Controlling pivoting in Pandira matrix inversion routines	
9. Mesh-point initialization in coil regions	
10. H·dl integrals during the Poisson calculation	
11. Electrostatic fields	223
E. Output options in Poisson and Pandira	224
Defining boundaries for computing the field and gradient	224
2. Harmonic analysis of the field's multipole content	
a. Mathematical theory of harmonic analysis	226
b. Implementing the harmonic analysis	229
3. Conformal transformations	231
4. Stored energy calculations in Poisson and Pandira	232
F. Convergence in the Poisson and Pandira solvers	233
G. Quantities calculated by Poisson and Pandira	237
1. SPOSA, SNEGA, and STOTA, currents after completing the solution	
2. XJFACT, factor by which currents have been scaled	237
3. RATIO, the quantity BZERO /XJFACT	238
4. SNOLDA and SNOLDI, old values of the summed squares of the residuals	
5. RHOAIR, optimized over-relaxation parameter	238
6. ENERGY, computed stored energy	238
7. RESIDA and RESIDI, the residuals for air and iron points	
8. ICYCLE, the number of the last completed iteration	
9. ETAAIR and ETAFE, rates of convergence parameters	239
H. Poisson and Pandira error messages	240
IX. WSFplot: the Poisson Superfish Plotting Code	241
A Starting program WSFplot	2/1

B. WSFplot display windows	242
1. Main display window	242
a. Zoom levels	243
b. Plot title, file ID footer, and numbered axes	243
c. Boundary segments	244
d. Mesh triangles	244
e. Contour lines	244
f. Field arrows	246
g. Field circles	246
h. Display orientation	246
i. Color settings	247
j. Line widths	247
2. Field-display window	248
a. Field components for magnetic-field problems	
b. Field components for electric-field problems	
c. Field components for rf problems with real fields	249 249
d. Field components and power losses for rf problems with complex fields	
C. Output from WSFplot	250
Writing contour coordinates to OUTWSF.TXT	
2. Hardcopy of graphics screens	251
a. BMP (Windows Bitmap Format)	
b. CGM (Computer Graphics Metafile)	
c. DXF (AutoCAD Drawing Exchange Format)	
d. PS (PostScript) and EPS (Encapsulated PostScript)	
e. HP-GL and HP-GL/2 (Hewlett Packard Graphics Language)	
f. PCX (ZSoft PC Paintbrush Format)	253
g. PNG (Portable Network Graphics)h. SVG (Scalable Vector Graphics)	253 253
i. WMF (Windows Metafile) and EMF (Enhanced Windows Metafile)	
3. WSFplot preference file	
D. WSFplot error messages	 255
X. SFO: Poisson Superfish Postprocessor	
A. Starting program SFO	
B. SFO files and filename conventions	
C. Problem variables for SFO	 257
1. Static-field solvers Poisson and Pandira use the FieldSegments table	
2. Running SFO more than once on the same problem	259
D. Field normalization in SFO	260
1. Using the NORM=0 option: normalize to E ₀	261
2. Using the NORM=1 option: normalize to E ₀ T	261
3. Using the NORM=2 option: normalize to a value of H _{\phi}	261
4. Using the NORM=3 option: use default or user-supplied ASCALE	
5. Using the NORM=4 option: normalize to a field integral between points	
6. Off-axis integration of E _z	
E. Options for calculating surface resistance	
1. Surface resistance for normal conductors	
Surface resistance for superconductors 2. Surface resistance for superconductors	263 264
3. Entering a known surface resistance	261 264

4. Entering a known value for the bulk resistivity	
5. Entering surface resistance data for individual segments	265
6. Resistivity of common metals and brazing alloys	266
F. Power calculations in SFO	268
1. Power calculations on boundary segments	268
a. Segment numbering b. Power and rf fields on Dirichlet boundaries	268
b. Power and rf fields on Dirichlet boundaries	268
c. Complementary solutions	269
2. Power estimates on stems	269
a. Negative segment numbers indicate a stem	269
b. Stems in multiple-cell problems	270 270
c. Stem proximity effect	270 271
4. Coupling slot offsets	271 271
4. Coupling-slot effects a. Average field at the coupling slot	271 271
b. Estimating coupling-slot power losses	272
5. Power losses in dielectric and magnetic materials for CFish problems	
G. Field-interpolation algorithm in SFO	274
H. Transit-time-factor integrals	274
Variables used with whole-cavity transit-time integrals	
SFDATA line for older versions of Parmila	278
I. Multicell calculations in SFO	
1. Multicell transit-time-factor integrals	
2. Transit-time-factor data versus β	
a. Tablplot files of T versus β	
b. PMI files for Parmila for each β	
3. Stems and post couplers in a multicell tank	
J. The SFO output summary	
1. Particle rest mass, velocity, and kinetic energy	
2. Accelerator figures of merit	285
3. Peak magnetic and electric fields and the Kilpatrick factor	286
4. Power and frequency-shift tables	
K. SFO error messages	289
XI. SF7: Poisson Superfish Postprocessor for Field Interpolation	291
A. Starting program SF7	291
1. Input using the dialog window	
2. Input using the command file	292 292
a. Line keyword for interpolation along a line	293
b. Arc keyword for interpolation along a circular arc	
c. Curve keyword for interpolation along a user-supplied curve	
d. Grid keyword for interpolation on a rectangular grid	294
e. Parmela keyword to create input for program Parmela	
f. EGUN keyword to create input for program EGUN	295
B. SF7 files and filename conventions	295
C. SF7 output text file	296
D. Creating Tablplot files of the interpolated fields	296

1. Plotting Slater-Perturbation Frequency Shifts	297
E. Power and stored energy integrals in SF7	298
F. Field-interpolation algorithm in SF7	299
G. Writing real and imaginary CFish fields	301
H. SF7 error messages	302
XII. Force: Poisson Postprocessor for Calculating Magnetic Forces	
A. Starting program Force	303
B. Force files and filename conventions	304
C. Output from Force	304
1. Output for Cartesian coordinates	304
2. Output for cylindrical coordinates	304
D. Iron or coil region on which to calculate the force	305
E. Other considerations when using Force	
1. Force does not make use of symmetry planes	
2. Meshing the problem geometry	
3. Possible sign errors in the force components	
8 —————————————————————————————————————	306
XIII. Automated Tuning Programs	307
A. The tuning programs and their cavity shapes	
1. DTLfish: a tuning program for drift-tube linacs	
a. DTLfish cavity shape	307
b. DTLCells, companion program for generating each Parmila cell	
CCLfish: a tuning program for coupled-cavity linacs a. Shape 0, standard coupled-cavity linac cell	
b. Optional tuning surfaces for standard coupled-cavity linac cell	
c. Shape 1, disk-loaded waveguide cell	316
d. Shape 2, special end-wall shape	317
e. CCLCells, companion program for generating each Parmila cell	317
3. ELLfish: a tuning program for elliptical cavities	318
a. Symmetric half cavity	318
b. Full cavity with attached bore tube	320
c. ELLCAV, companion program for generating the multicell-cavity file	
4. MDTfish: a tuning program for multiple-cell drift-tube linacs	
a. MDTfish cavity shape b. MDTCells, companion program, converts DTLfish input to MDTfish input	322
5. CDTfish: a tuning program for coupled-cavity drift-tube linacs	
a. Coupled-cavity drift-tube linac cavity shapes	
6. RFQfish: a tuning program for radio-frequency quadrupoles	
a. RFQfish cavity shape	
7. SCCfish: a tuning program for side coupling cavities	330
B. Starting and stopping the tuning programs	330
Using the Esc key to stop a tuning code or a Superfish run	
C. Session, problem, and run; tuning program terminology	331

D. Files used in the tuning codes	332
1. The control file and tuned-data file	332
2. The tuning program LOG file	334
3. Automesh input file for a Superfish run	
4. SFO file, SFO output file	334
5. SEG file, Input file for program SFO	334
E. Control file keywords common to all tuning programs	335
1. TITLE and ENDTitle, Defining the problem description	
2. Control-file comment-line indicators	
3. ENDFile, The last line in the control file	
4. PARTICLE and REST_mass, Particle type for kinetic energy calculation	337
5. Keywords specifying the surface resistance	
6. Filenames for each problem in the control file	
7. Setting the target frequency and tolerance	
8. Setting the mesh size in the problem geometry	
a. Controlling line regions through the drift tube in DTLfish and MDTfish	
9. Linking parameters to previously calculated values	
10. Setting the preferred normalization method	
11. Saving binary solution files for each completed problem	
F. Control-file keywords specific to each tuning code	
1. DTLfish control-file keywords	
CCLfish control-file keywords a. Selecting either Neumann or Dirichlet boundary conditions in CCLfish	3 11
3. ELLfish control-file keywords	
4. MDTfish control-file keywords	
a. Entering the cell data in MDTfish	
b. Stem and post-coupler data in MDTfish	348
c. Example stem configurations	348
d. Example post-coupler configurations	350
5. CDTfish control-file keywords	350
a. Full-cavity or half-cavity problems and the number of gaps	350
b. Gap-shift parameters in the CDTfish control file	351
c. Using unequal face angles on drift tubes	353
6. RFQfish control-file keywords	354
a. Defining the RFQfish tuning parameters	354
b. Field normalization in RFQfish	356
7. SCCfish control-file keywords	356
G. Drift-tube nose shape in cylindrically symmetric cavities	357
1. CCLfish cavities with no nose	358
H. Cell lengths and gap lengths in tuning codes	358
I. Using the START code to tune a cavity	359
1. START codes for DTLfish	359
2. START codes for CCLfish	360
3. START codes for ELLfish	
4. START codes for MDTfish	
5. START codes for CDTfish	
6. START codes for RFQfish	
7 START codes for SCCfish	362 362

J. Drift-tube stems in DTLfish, MDTfish, and CDTfish	363
K. Converting old DATA/ENDDATA sections to the new format	363
1. Converting an old DTLfish file to the new format	
2. Converting an old CCLfish file to the new format	364
XIV. Plotting Programs Quikplot and Tablplot	367
A. Starting a plotting code	367
1. Opening files	
2. Editing files	368
3. Stopping the program	
B. Input data files	368
1. Quikplot data format	
a. Curve labels	
b. Mathematical operations	369
2. Tablplot data format	
a. Column titles	372
b. Axis labels	372
c. Curve labels	372
d. Option to skip lines	372
e. Mathematical operations	372
C. Main display window	373
1. Display features	376
a. Abscissa and ordinate axes	376
b. X and Y scales, zoom levels	
c. Plot title and coordinate axes	377
d. Marker size and type	377
e. Curve labels	377
f. Line widths	378
2. Arithmetic operations in Quikplot and Tablplot	
3. Interchanging the X and Y axes in Quikplot	379
4. Sorting and point labeling in Tablplot	379
5. Constructing a new data column in Tablplot	380
6. Selecting data to display	
a. Locking the Y-axis scale in Tablplot	
7. Fitted curves	381
a. Interpolating a value from the fitted curve	381
b. Plotting the residuals of the fit	
c. Integrating the fitted curve or the data	381
D. Output from the plotting codes	
1. Log file	
2. Hardcopy of graphics screens	382
3. Quikplot and Tablplot preference files	383
4. Tab-delimited text files	383
5. New Quikplot and Tablplot files	384
E. Sample input files	384
1. Example data file for Quikplot	384
2. Example data file for Tablplot	385
VV Utility Programs	399

A. List35: lists the contents of the binary solution file	388
1. LAST35, indicates the last program to update the binary solution file	390
B. SFOtable: make Tablplot file from families of SFO files	391
1. Starting program SFOtable	
2. Files used in SFOtable	392
3. The SFOtable control file	392
a. OUTPUT file, name of the Tablplot file	
b. Filenames for SFO filesc. Field normalization options in SFOtable	393 202
d. Including tuning-code setup parameters in the Tablplot file	393393 394
e. EndFile, the last line in the file	395
4. SFOtable sample control file and output file	395
C. SegField: make plot files of fields on boundary segments	398
D. Beta: lists particle β as a function of kinetic energy	400
E. Kilpat: calculate the Kilpatrick field for a given frequency	401
F. ConvertF: convert frequencies between different conditions	402
G. FScale: Scale dimensions in tuning-code control files	406
H. SF8: Coupling slot effects	407
1. Starting program SF8	407
2. Files used in SF8	
3. The SF8 control file	
a. Cavity keywords	
b. FREQuency keyword	
I. MK_SFINI: Create or update file SF.INI	
XVI. RF Field Examples (Autofish, Fish, CFish)	
A. The PillboxCavities directory	
1. PILL1.AF, a short pillbox cavity	
2. MODPILL.AF, a pillbox cavity with bore tube	
B. The CFish directory	421
a. Coaxial waveguide example	421
b. Pillbox with dielectric rod	424
c. Power losses in dielectricsd. Waveguide power splitter	
C. The FrequencyScan directory	
a. The on-axis coupled cavity and resonance searches	
b. Frequency scans	428
c. Plotting fields along segments	429
D. The SphericalCavity directory	430
E. The RFQCavity directory	
a. One-eighth of an RFQ cavity	432
b. One-fourth of an RFQ cavity	435
F The Quarter Waya Resonator directory	138

G. The FerriteCavity directory	438
H. The Waveguides directory	442
1. Rectangular waveguide TE modes	
2. Hexagonal waveguide TE modes	444
XVII. Magnetostatic Examples (Poisson, Pandira)	447
A. The H-Magnet directory	
1. The H-shaped magnet example HTEST1	
2. The H-shaped magnet example HTEST2.AM	
 Full-geometry example HFULL.AM for the H-shaped magnet Force calculation for problem HFULL.AM 	
B. The Dipoles directory	
C. The Quadrupoles directory	
D. The ForceTest and ForceOnWires directories	
1. Force between current loops	401 462
E. The PMCylinders directory	
F. The PMDipoles directory	464
Dipole magnet made from blocks of permanent-magnet material	
2. Permanent-magnet dipole with variable easy axis direction	468
G. The PMQuads directory	470
1. Full geometry permanent-magnet quadrupole	471
2. Permanent-magnet quadrupole with variable easy axis direction	
3. Quarter geometry permanent-magnet quadrupole	
H. The POAsample directory	
I. The Septum directory	483
J. The Solenoids directory	484
K. The Shielding directory	484
L. The StoredEnergy directory	487
XVIII. Electrostatic Examples (Poisson, Pandira)	488
A. The ChargeDensity directory	488
B. The CoaxCapacitor directory	491
C. The CoaxCylinder directory	491
D. The Dielectrics directory	491
E. The IonSource directory	492
F. The Plates directory	492
G. The QuadLens directory	492
H. The StoredEnergy directory	493
XIX. Tuning Program Examples	495

A. The CCL directory	495
1. A conventional CCL cell	495
2. Special shape option for the cavity wall	
B. The CCDTL directory	
Full-cavity 1-drift-tube example Half-cavity 2-drift-tube cavity	
C. The DTL directory 1. Using different tuning surfaces	504 505
2. Computing the fields for a specific design without tuning	506
D. The EllipticalCavity directory	510
1. Symmetric half cell	512
2. Full cell at the end of a multicell cavity	
3. ELLCAV, generation of the multicell cavity4. SegField, displaying fields along the cell boundary	516 516
E. The MulticellDTL directory	
F. The RFQ directory 1. Soverel tuning entions for RFQ assisting	519 519
Several tuning options for RFQ cavities LANSCE RFQ design examples	525
G. The SideCouplingCell directory	
XX. Theory of Electrostatics and Magnetostatics	
A. Maxwell's equations	531
B. Isotropic magnetostatics in Cartesian coordinates	532
C. Isotropic electrostatics in Cartesian coordinates	534
D. Isotropic magnetostatics in cylindrical coordinates	536
E. Isotropic electrostatics in cylindrical coordinates	537
F. Anisotropic magnetostatics in Cartesian coordinates	
1. Easy axis in a fixed direction	
2. Easy axis on an off-center circle	
G. Anisotropic electrostatics in Cartesian coordinates	
H. Anisotropic magnetostatics in cylindrical coordinates	
I. Anisotropic electrostatics in cylindrical coordinates	548
XXI. Properties of Static Magnetic and Electric Fields	549
A. Energy stored in the field	549
B. Fields and their derivatives	553
C. Forces and torques	565
XXII. Boundary Conditions and Symmetries	573
A. Boundary conditions	573
1. Magnetic field near Dirichlet boundary	575

2. Electric field near Dirichlet boundary	575
3. Magnetic field near Neumann boundary	575
4. Electric field near Neumann boundary	576
B. Symmetry considerations	576
1. Reflection symmetry	
2. Rotational symmetry	
XXIII. Numerical Methods in Poisson and Pandira	579
A. Mesh formulation	579
B. Calculation of the vector potential at a mesh point	580
C. Application of boundary conditions	594
D. Calculation of fields	596
E. Computer algorithm using the SOR method	597
F. Computer algorithm using the direct method	598
XXIV. RF Cavity Theory	599
A. Introduction to rf cavity theory for Superfish	599
TM and TE modes in cylindrical coordinates	600
2. TE modes in Cartesian coordinates	
3. Formulas for auxiliary quantities in cylindrical coordinates	603
a. Energy per unit volume	603
b. Power losses on walls	603
c. Power losses on stems	604
d. Average accelerating field	
e. Shunt impedance	
f. Quality factor	
g. Maximum electric field	
h. Frequency perturbations	
4. Units	605
5. Method of solution using a drive point	605
B. Detailed development of the RF cavity theory	
1. Maxwell's equations in cylindrical coordinates	
2. Application of Poynting's theorem	
3. The D(k ²) function	
4 Solving problems in Cartesian coordinates	614

List of Tables

Table II-1. Disk directories.	10
Table II-2. Subdirectories directly under LANL\Examples.	10
Table II-3. Miscellaneous files in the LANL directory.	11
Table II-4. Files listing code changes.	14
Table II-5. Contents of DeveloperFiles\PoissonSuperfish subdirectories	15
Table II-6. Function INTERP return values.	17
Table II-7. Files for use with LF95 main programs.	20
Table II-8. Fortran modules	22
Table II-9. Variables module SF_CTRL.	23
Table II-10. Arrays in ComplexTape35Arrays and RealTape35Arrays	25
Table II-11. Variables in ComplexTape35Arrays and RealTape35Arrays.	26
Table II-12. Variables in module PoissonSuperfishData.	
Table II-13. Variables in module InterpolatedFields	27
Table II-14. Material arrays indexed by material ID number.	29
Table II-15. Shape of arrays in Table II-14.	29
Table II-16. Meaning of the line-parser calling parameters.	31
Table II-17. Line-parser variables available to the calling program.	32
Table II-18. Meaning negative values of NCHR.	32
Table II-19. Settings for array verification.	33
Table III-1. Topics from the 1987 Reference Manual	44
Table III-2. The tuning programs.	55
Table III-3. Superfish variables.	76
Table III-4. Poisson variables.	80
Table III-5. Alphabetical list of SF.INI settings.	83
Table III-6. Poisson Superfish warning messages.	90
Table III-7. Filename extensions for hardcopy graphics types.	92
Table III-8. WSFplot display parameters in SF.INI.	
Table III-9. Power-law settings for WSFplot contour lines.	94
Table III-10. Quikplot and Tablplot parameters in SF.INI.	96
Table III-11. SF7 expanded data-table columns.	97
Table III-12. SF7 parameters in SF.INI.	98
Table III-13. Beta display parameters in SF.INI.	100
Table III-14. SF.INI variable SlaterTerm for WSFplot and SF7.	107
Table III-15. Electromagnetic theory sections.	110
Table III-16. Memory requirements of the codes.	117
Table III-17. Lengths of some allocated arrays.	118
Table I-1. Files used in Poisson Superfish.	122
Table I-2. Registered file types.	
Table I-3. Right mouse button menu for T35 files.	124
Table I-4. Frequency scan data written by Fish.	
Table I-5. Frequency scan data written by CFish.	
Table I-6. Transit-time data in file Transit.TBL.	137
Table I-7. Transit-time data in file TBeta.TBL.	
Table I-8. Automesh namelist parameters that indicate the cavity type	144
Table VI-1. REG namelist variables.	149
Table VI-2. REG variables that affect the default value of DY.	
Table VI-3. Material numbers.	
Table VI-4. PO namelist variables.	156
Table VI-5 MT namelist variables	150

Table VI-6. REG namelist material arrays in the binary solution file.	160
Table VI-7. The three possible values for MODE	163
Table VI-8. Values of MSHAPE when MODE = 0.	164
Table VI-9. MT namelist variables for anisotropic materials.	166
Table VI-10. The meaning of IPERM.	168
Table VI-11. POA namelist variables.	168
Table VI-12. Variables affected by the choice for CONV.	173
Table VI-13. Length units.	173
Table VI-14. Default boundary conditions at the edges of the geometry.	174
Table VI-15. Default boundary conditions for region boundaries.	
Table VI-16. REG namelist variables for the first 8 line regions.	
Table VI-17. Formats for displaced nodes.	
Table VI-18. The three possible values for triangle type ITRI.	185
Table VI-19. REG namelist variables that specify a cavity type.	
Table VI-20. The C-array parameters that determine the initial potential.	
Table VI-21. Automesh error messages.	195
Table VII-1. Variables used by Fish and CFish.	201
Table VII-2. Frequency-scan variables.	202
Table VII-3. Methods for estimating the frequency at the next iteration.	204
Table VII-4. Relaxed convergence parameters used by the tuning programs.	
Table VII-5. Parameters that affect convergence in Superfish.	208
Table VII-6. Fish and CFish error messages.	210
Table VIII-1. Variables used by Poisson and Pandira.	212
Table VIII-2. Variables related to permeability in Poisson and Pandira.	214
Table VIII-3. Variables for scaling the Poisson fields.	219
Table VIII-4. Variables defining the field-interpolation region.	
Table VIII-5. Variables that control the harmonic analysis.	
Table VIII-6. Symmetry options for the harmonic analysis.	
Table VIII-7. Meaning of median-plane symmetry in Table VIII-6.	
Table VIII-8. Variables that control conformal mapping.	232
Table VIII-9. Variables related to Poisson and Pandira convergence tests.	
Table VIII-10. Parameters that affect convergence in Poisson or Pandira.	
Table VIII-11. Number of cycles to converge versus RHOAIR.	237
Table VIII-12. Error messages for Poisson and Pandira.	240
Table IX-1. WSFplot menu items.	242
Table IX-2. Contour settings in SF.INI	244
Table IX-3. Power-law settings for WSFplot contour lines.	
Table IX-4. Plot orientation menu items. Table IX-5. The WSFplot color parameters in SF.INI.	247
Table IX-6. The WSFplot line-width parameters in SF.INI.	248
Table IX-7. Options for calculating material power losses.	
Table IX-8. HP-GL Color Translation.	
Table IX-9. WSFplot error messages.	
Table X-1. Problem variables used by SFO.	
Table X-2. Table headings in the SFO input file.	
Table X-3. Variables that affect the Superfish field normalization.	
Table X-4. The field normalization methods.	260 260
Table X-5. Methods for computing surface resistance.	264
Table X-6. Variables that affect the surface resistance.	
Table X-7. Variables for each method of computing surface resistance.	
Table X-8 Properties of common metals	260 267

Table X-9. Brazing alloy resistivities.	267
Table X-10. Field enhancement factor λ versus c/b.	270
Table X-11. Variables for the average field near the coupling slot.	272
Table X-12. Variables affecting coupling slot power estimates.	273
Table X-13. Variables used with whole-cavity transit-time integrals.	
Table X-14. SFDATA parameters for old versions of Parmila.	
Table X-15. Variables used with multiple-cell transit-time integrals.	 279
Table X-16. CellData columns for multicell transit-time integrals.	 279
Table X-17. Variables for plotting transit-time data versus β	281
Table X-18. IBETA settings for SFO.	281
Table X-19. Stem and post-coupler parameters.	284
Table X-20. Code numbers and rest masses for some charged particles.	
Table X-21. Data columns in the table of wall segments.	288
Table X-22. Data columns for multicell stems and post couplers	288
Table X-23. SFO error messages.	289
Table XI-1. SF7 command keywords and data entry lines.	293
Table XI-2. SF7 optional keywords.	293
Table XI-3. Shape factors for settings of variable SlaterTerm.	298
Table XI-4. SF7 expanded data-table columns.	300
Table XI-5. SF7 error messages.	302
Table XII-1. Force error messages.	
Table XIII-1. Column headings in drift-tube geometry table.	
Table XIII-2. Cavity types in CCLfish.	
Table XIII-3. Tuning ring options in CCLfish.	
Table XIII-4. Equator tuning ring effects in three cavities.	
Table XIII-5. Tuning ring options in CDTfish.	327
Table XIII-6. Tuning program terminology.	331
Table XIII-7. Tuning program files.	332
Table XIII-8. Control file keywords common to all the tuning programs.	
Table XIII-9. Symbols for some common ions.	
Table XIII-10. Control file keywords for specifying the surface resistance.	
Table XIII-11. Normal-conductor parameters used with the TEMPerature keyword.	
Table XIII-12. Parameters used with the SUPERConductor keyword.	
Table XIII-13. Files created by the tuning program.	339
Table XIII-14. DTLfish control-file keywords	
Table XIII-15. CCLfish control-file keywords.	
Table XIII-16. ELLfish control-file keywords.	
Table XIII-17. MDTfish control-file keywords.	
Table XIII-18. Data columns after the CELL_data keyword.	
Table XIII-19. CDTfish control-file keywords.	
Table XIII-20. RFQfish control-file keywords.	
Table XIII-21. Data columns after the DATA keyword in the RFQfish control file.	
Table XIII-22. SCCfish control-file keywords.	
Table XIII-23. START codes for DTLfish.	360
Table XIII-24. START codes for CCLfish.	
Table XIII-25. START codes for ELLfish	
Table XIII-26. START codes for MDTfish	
Table XIII-20. START codes for CDTfish.	
Table XIII-28. START codes for RFQfish.	
Table XIII-29. START codes for SCCfish.	
Table XIV-1 Ouikplot input-file keywords	303 370

Table XIV-2. Tablplot input-file keywords	371
Table XIV-3. Mathematical operations upon starting Tablplot.	373
Table XIV-4. Quikplot menu items.	374
Table XIV-5. Tablplot menu items.	375
Table XIV-6. Arithmetic operations.	379
Table XIV-7. Tablplot algebraic operations.	380
Table XIV-8. Fit menu items for selecting a fitted curve.	381
Table XV-1. Column headings for the region material table.	389
Table XV-2. Column headings for the mesh-point data table.	
Table XV-3. LAST35 code numbers.	390
Table XV-4. SFOtable control-file keywords.	393
Table XV-5. SegField control-file keywords.	
Table XV-6. Columns in the SegField output file.	
Table XV-7. Thermal expansion data.	403
Table XV-8. Dielectric constants of gases.	404
Table XV-9. SF8 control-file keywords.	408
Table XVI-1. Files in directory Examples\RadioFrequency.	415
Table XVI-2. Files in directory RadioFrequency\PillboxCavities.	
Table XVI-3. Files in directory RadioFrequency\CFish.	
Table XVI-4. Files in directory RadioFrequency\FrequencyScan.	
Table XVI-5. Files in directory RadioFrequency\SphericalCavity.	430
Table XVI-6. Files in directory RadioFrequency\RFQCavity.	
Table XVI-7. Files in directory RadioFrequency\QuarterWaveResonator.	
Table XVI-8. Files in directory RadioFrequency\FerriteCavity.	
Table XVI-9. Files in directory RadioFrequency\Waveguides.	
Table XVII-1. Files in directory Examples\Magnetostatic.	
Table XVII-1. Files in directory Magnetostatic\H-Magnet.	
Table XVII-2. Files in directory Magnetostatic\Dipoles.	460
Table XVII-3. Files in directory Magnetostatic\Quadrupoles	
Table XVII-4. Files in directory Magnetostatic\ForceTest.	
Table XVII-5. Files in directory Magnetostatic\ForceOnWires.	
Table XVII-6. Files in directory Magnetostatic\PMCylinders.	
Table XVII-7. Files in directory Magnetostatic\PMDipoles.	
Table XVII-8. Files in directory Magnetostatic\PMQuads.	
Table XVII-9. Files in directory Magnetostatic\POAsample.	
Table XVII-10. Files in directory Magnetostatic\Septum.	
Table XVII-11. Files in directory Magnetostatic\Solenoids.	
Table XVII-12. Files in directory Magnetostatic\Shielding.	
Table XVII-13. Files in directory Magnetostatic\StoredEnergy.	
Table XVIII-1. Files in directory Examples\Electrostatic.	
Table XVIII-2. Files in directory Electrostatic\ChargeDensity	
Table XVIII-3. Files in directory Electrostatic\CoaxCapacitor	
Table XVIII-4. Files in directory Electrostatic\CoaxCylinder.	
Table XVIII-5. Files in directory Electrostatic\Dielectrics.	
Table XVIII-6. Files in directory Electrostatic\IonSource.	
Table XVIII-7. Files in directory Electrostatic\Plates	
Table XVIII-8. Files in directory Electrostatic\QuadLens.	
Table XVIII-9. Files in directory Electrostatic\StoredEnergy	
Table XIX-1. Files in directory CavityTuning\CCL.	
Table XIX-2. Files in directory CavityTuning\CCDTL.	500
Table XIX-3. Files in directory CavityTuning\DTL.	
	501

Table XIX-4. Files in directory CavityTuning\EllipticalCavity.	511
Table XIX-5. Files in directory CavityTuning\MulticellDTL	517
Table XIX-6. Files in directory CavityTuning\RFQ.	519
Table XIX-7. RFQ vane parameters for three problems.	520
Table XIX-8. Files in directory CavityTuning\SideCouplingCell.	528
Table XXI-1. The first 10 harmonic polynomials.	556
Table XXI-2. Harmonic polynomials for cylindrical coordinates.	564
Table XXII-1. Boundary condition terminology.	574
Table XXII-2. Field directions near Dirichlet and Neumann boundaries.	575

List of Figures

Figure II-1. Fortran 90 declarations for DLL functions.	16
Figure II-2. Example LF95.Fig file.	21
Figure II-3. The six triangles surrounding a mesh point.	34
Figure III-1. Square-wave electric field distribution.	68
Figure III-2. Triangular mesh showing reference point and neighboring points.	109
Figure I-1. SFO input file written by DTLfish.	130
Figure I-1. A sample PMI file for a single-gap problem.	144
Figure I-2. A sample PMI file for a multicell problem.	
Figure VI-1. Sample input file illustrating the use of MAT.	161
Figure VI-1. A sample MT namelist with a (B,γ) material table.	
Figure VI-2. B-H relationships for an anisotropic permanent-magnet material.	
Figure VI-3. Sample input file defining permanent magnet materials	1.00
Figure VI-4. Automesh input file for a pillbox cavity.	
Figure VI-5 Automesh input file for a cavity with an elliptical segment.	
Figure VI-6. Automesh input file for an H-shaped magnet.	
Figure VIII-1 B-H curves (linear scale) for the internal permeability tables.	
Figure VIII-2. B-H curves (log scale) from Figure VIII-1.	
Figure VIII-3. Flux density B versus field strength H.	
Figure VIII-4. One quarter of a symmetric H-shaped magnet	227
Figure X-1. SFO input file for first code run.	259
Figure X-2. SFO input file for second code run.	260
Figure X-3. SFO input file containing surface resistance data.	265
Figure X-4. Coupling slots in a CCDTL.	272
Figure X-5. Coupling-slot data in the SFO output file.	273
Figure X-6. Half of a six-cell cavity.	282
Figure X-7. SFO input file created by ELLCAV	283
Figure XI-1. Sample SF7 input for interpolation along a line	
Figure XI-2. Sample SF7 input for interpolation along an arc.	
Figure XI-3. Sample SF7 input for interpolation along a user-supplied curve.	
Figure XI-4. Sample SF7 input for interpolation on a rectangular grid.	
Figure XI-5. Sample SF7 input containing several commands.	
Figure XI-6. Interpolation path between mesh rows.	300
Figure XIII-1. The DTL half cell set up by the code DTLfish.	308
Figure XIII-2. Detail near the drift-tube nose.	309
Figure XIII-3. The CCL half cell set up by the code CCLfish.	312
Figure XIII-4. Detail near the nose in a CCL cell.	
Figure XIII-5. Optional equator tuning ring in CCL cavities.	313
Figure XIII-6. Optional wall tuning rings in CCL and CCDTL cavities.	314
Figure XIII-7. A section of a disk-loaded waveguide.	
Figure XIII-8. A CCLfish cavity with special shape parameters.	
Figure XIII-9. The right half of an elliptical cavity.	
Figure XIII-10. Full-cell elliptic cavity.	
Figure XIII-11. Right half of an 8-cell cavity.	
Figure XIII-12. Three full cells of a drift-tube linac setup by MDTfish.	
Figure XIII-13. Full cavity of a one-drift-tube, 2-gap CCDTL.	324
Figure XIII-14. Half of a two-drift-tube, 3-gap CCDTL cavity.	
Figure XIII-15. Details near the drift tube in a CCDTL cavity.	326
Figure XIII-16. Ontional equator tuning ring in a CCDTL cavity	

Figure XIII-17. Cross section of one quadrant of an RFQ cavity.	329
Figure XIII-18. Details near the vane tips for the RFQ quadrant.	329
Figure XIII-19. Side coupling cavities.	330
Figure XIII-20. Typical input file for program Automesh.	333
Figure XIII-21. Typical SEG file for program SFO	
Figure XV-1. Sample XFREQ.TXT output from ConvertF.	405
Figure XV-2. Coupling slot location in a CCL cavity.	409
Figure XV-3. Sample SF8 control file.	411
Figure XVI-1. The batch file RUNPILL.BAT.	417
	417
Figure XVI-3. Triangular mesh and field contours for the PILL1.AF example.	
Figure XVI-4. Input file PILL1.SEG for SFO	
Figure XVI-5. Input file PILL1B.SEG for SFO.	418
Figure XVI-6. Input file PILL1C.SEG for SFO.	419
Figure XVI-7. Input file PILL1D.SEG for SFO.	419
Figure XVI-8. Input file PILL1E.SEG for SFO.	420
Figure XVI-9. Field distribution for the modified pillbox cavity.	
Figure XVI-10. The MODPILL.AF input file for Autofish.	421
Figure XVI-11. The COAXWG.AM input file for Automesh.	
Figure XVI-12. Field contours for the coaxial line problem.	423
Figure XVI-13. SFO input file COAXWG.SEG.	423
Figure XVI-14. Tablplot display of fields.	
Figure XVI-15. Field contours for the waveguide power splitter.	425
Figure XVI-16. The batch file RUNSCAN.BAT	426
Figure XVI-17. The input file MODE763.AF	427
Figure XVI-18. The first few lines of input file SCAN.AM.	427
Figure XVI-19. Modes in the on-axis coupled cavity.	
Figure XVI-20. Tablplot screen showing data in FishScan.TBL.	429
Figure XVI-21. Input file MODE763.SGF for program SegField.	
Figure XVI-22. Tablplot screen showing data in SEGS.TBL.	
Figure XVI-23. The two-line batch file RUNSPHER.BAT.	
Figure XVI-24. The Automesh input file SPHERE.AF.	
Figure XVI-25. Field contours for the spherical cavity mode at 130 MHz.	431
Figure XVI-26. The batch file RUNRFQ.BAT	432
Figure XVI-27. The input file 8THRFQ.AF.	433
Figure XVI-28. Triangular mesh for file 8THRFQ.AF.	434
Figure XVI-29. Field contours for the half-quadrant RFQ.	
Figure XVI-30. Mesh and field contours near an RFQ vane tip.	
Figure XVI-31. Title and REG namelist in Autofish input file 4THRFQ.AF	436
Figure XVI-32. PO NAMLIST entries in Autofish input file 4THRFQ.AF.	437
Figure XVI-33. Field contours for a dipole mode in an RFQ quadrant.	437
Figure XVI-34. Outline of regions in the ferrite-tuned cavity.	
Figure XVI-35. The batch file RUNFTEST.BAT	439
Figure XVI-36. Contours of rH_{ϕ} in the ferrite cavity.	
Figure XVI-37. Equally spaced field contours in the ferrite-tuned cavity.	
Figure XVI-38. First part of Automesh input file FTEST.AM.	440
Figure XVI-39. Second part of Automesh input file FTEST.AM.	
Figure XVI-40. Last part of Automesh input file FTEST.AM.	442
Figure XVI-41. The batch file RUNWG.BAT.	442
Figure XVI-42. Automesh input file WR2300.AM.	443
Figure XVI-43. Several waveguide TE modes.	444

Figure XVI-44. Automesh input file WR2300.AM.	445
Figure XVI-45. Waveguide modes in the hexagonal guide.	446
Figure XVII-1. The batch file RUNHTEST.BAT.	448
Figure XVII-2. Title and REG namelist from input file HTEST1.AM.	449
Figure XVII-3. Air points and iron and coil regions HTEST1.AM and HTEST2.AM	450
Figure XVII-4. One quadrant of the H magnet geometry.	451
Figure XVII-5. Triangular mesh for the HTEST1 and HTEST2 examples.	451
Figure XVII-6. Field contours for the HTEST1.AM and HTEST2.AM examples.	452
Figure XVII-7. List of points used for HTEST1.AM harmonic analysis.	452
Figure XVII-8. Coefficients computed by the harmonic analysis for HTEST1.	453
Figure XVII-9. Title and REG namelist from input file HTEST2.AM.	454
Figure XVII-10. Automesh input file HFULL.AM	455
Figure XVII-11. Last region in Automesh input file HFULL.AM.	456
Figure XVII-12. Triangular mesh for the HFULL.AM example.	457
Figure XVII-13 Field contours for the HFULL.AM example.	457
Figure XVII-14 List of points used for the HFULL.AM harmonic analysis	458
Figure XVII-15 Coefficients computed by the harmonic analysis for HTEST1.AM.	459
Figure XVII-16. Force input file HFULL.FCE.	459
Figure XVII-17. The batch file RUNPMDIP.BAT.	465
Figure XVII-18. Geometry of the permanent magnet dipole.	466
Figure XVII-19. The Automesh input file PMDIPOLE.AM.	467
Figure XVII-20. Field contours for problem PMDIPOLE.AM.	468
Figure XVII-21 The Automesh input file PMDVAR.AM.	469
Figure XVII-22. Field contours for the PMDVAR.AM example.	470
Figure XVII-23. The batch file RUNPMQ.BAT.	471
Figure XVII-24a. Start of Automesh input file PMQUAD1.AM.	472
Figure XVII-25. Field contours for problem PMQUAD1.AM.	475
Figure XVII-26. The Automesh input file PMQUAD2.AM.	477
Figure XVII-27 Field contours for the PMQUAD2.AM example.	478
Figure XVII-28a. Start of Automesh input file PMQUAD1.AM.	 479
Figure XVII-29. Field contours for the PMQUAD3.AM example.	 479
Figure XVII-30. Solution of dipole problem from file POA2.AM.	481
Figure XVII-31. Region 1 mesh-point list from file OUTAUT.TXT.	482
Figure XVII-32. POA namelist sections in file POA2.AM.	483
Figure XVII-33. The batch file RUNVECP.BAT	484
Figure XVII-34. Lines of constant A _z for the VECP.AM problem.	485
Figure XVII-35. Automesh input file VECP.AM.	
Figure XVII-36. Two expanded displays of the VECP mesh.	487
Figure XVIII-1. WSFplot display for problem C1Q.AM.	490
Figure XVIII-2. Interpolated fields for problem C1Q.AM.	490
Figure XIX-1. CCLfish control file 805CCL.CCL.	
Figure XIX-2. Mesh and field contours for input file 805CCL2.AM.	497
Figure XIX-3. CCLfish control file 425 EW.CCL.	
Figure XIX-4 Mesh and field contours for input file 425EW1.AM.	
Figure XIX-5. CDTfish control file 1DTFC.CDT.	
Figure XIX-6. Mesh and field contours for a 1-drift-tube CCDTL cavity.	
Figure XIX-7. CDTfish control file 2DTHC.CDT.	
Figure XIX-8. Mesh and field contours for a 2-drift-tube CCDTL cavity.	
Figure XIX-9a. First part of DTLfish control file DTLTEST.DTL.	
Figure XIX-10a. First part of DTLfish control file RGFISH.DTL.	
Figure XIX-11 Mesh and field contours for two RGFISH DTL examples	

Figure XIX-12. Tablplot display of cavity parameters in file RGDTL.TBL.	510
Figure XIX-13. The file Run_ELL.BAT	511
Figure XIX-14. ELLfish control file 82B.ELL.	512
Figure XIX-15. Mesh and field contours for input file 82B1.AM.	513
Figure XIX-16. Field contours for input file 82BE1.AM.	
Figure XIX-17. ELLfish control file 82BE.ELL.	515
Figure XIX-18. Half of the full 8-cell cavity.	516
Figure XIX-19. Tablplot screen showing the fields and radiation pressure.	
Figure XIX-20. Control file MDTTEST.MDT for program MDTfish.	
Figure XIX-21. Mesh and field contours for the 3-cell DTL problem.	
Figure XIX-22a. First part of file RFQTEST.RFQ for program RFQfish.	
Figure XIX-23. Mesh generated for input file RFQ_A1.AM.	
Figure XIX-24. Field contours for file RFQ_A1.	
Figure XIX-25. Cavity shapes for the eight RFQTEST.RFQ problems.	
Figure XIX-26. RFQfish control file LANSCE.RFQ.	
Figure XIX-27. Cavity shapes for the four LANSCE.RFQ problems	
Figure XIX-28 SCCfish control file 805CC.SCC.	528
Figure XIX-29. Mesh for problems 805CC1.AM and 805CC2.AM	
Figure XIX-30. WSFplot field contours for problems 805CC1.AM and 805CC2.AM.	
Figure XX-1. The geometry of the line and area integrals.	
	535
Figure XX-3. Area and contour path in cylindrical coordinates.	
Figure XX-4. Volume in cylindrical coordinates.	538
Figure XX-5. B-H relationships for an anisotropic material.	
Figure XX-6. Unit vectors for anisotropic materials.	540
Figure XX-7. Permanent-magnet quadrupole.	542
Figure XX-8. Definitions of parameters in off-center anisotropic materials.	
Figure XXI-1. An arbitrary volume with 2-D Cartesian symmetry.	550
Figure XXI-2. Contour C for an H-shaped magnet.	552
Figure XXI-3. A general volume in cylindrical symmetry.	 552
Figure XXI-4. First, second, and third neighbors of point 1.	 557
Figure XXI-5. Four types of magnet symmetry.	 559
Figure XXI-6. Conductor of constant cross section.	
Figure XXI-7. Cylindrically symmetric conductor.	568
Figure XXII-1. Magnetic field lines for two type of reflection symmetry.	576
Figure XXII-2. Rotational symmetry.	577
Figure XXII-3. Using a separatrix to choose an approximate boundary condition.	
Figure XXIII-1. Surface and contour elements in Equation XXIII-1.	
Figure XXIII-2. Physical parameters in the mesh geometry.	
Figure XXIII-3. Path of contour integration for Ampere's Law.	
Figure XXIII-4. Contour integration details.	
Figure XXIII-5. The vector potential is a linear function over a triangle.	588
Figure XXIII-6. Integration paths in adjacent triangles.	
Figure XXIII-7. Cancellation of interior contours.	
Figure XXIII-8. Path of contour integration on a Neumann boundary.	
Figure XXIV-1 Field lines for the TM mode in a cylindrically symmetric rf cavity.	
Figure XXIV-2. Waveguide geometry Figure XXIV-3 Six nearest neighbors of point 0 in a triangular mesh	607
Figure XXIV-4 Demonstration that D(k²) has a "false" zero.	614



I. How To Use This Document

This section provides some tips on navigating this documentation when viewing it on-line and on printing either the entire document or sections of it.

This document was produced using Microsoft Word, Version 7.0 (Word 95) and the Internet Assistant for Microsoft Word. You can read and print it with Word 6, Word 7, Word 97, Word 2000, and Microsoft Word Viewer. There are several ways to move from place to place without scrolling through entire files. Some navigation features will be unavailable unless you use Microsoft Word. This chapter contains some recommended settings and procedures.

We have attempted at times to convert the documentation to more recent versions of Microsoft Word (Word 97, Word 2000). These attempts have been unsuccessful, so the DOC files remain in the older format. Users of Word 97 or Word 2000 may experience problems with pictures and equations in the document. If this is a problem, try using Word Viewer. We have also attempted to create Adobe PDF files, but have found that some fonts used in equations do not translate properly to PDF files.

A. Getting started

We realize that reading through several hundred pages of documentation can be a formidable task. We hope to make this document as comprehensive a reference as possible, but this in turn leads to a rather long work.

A good way to learn about the Poisson Superfish codes is to read the brief summary of the codes in section II.G. (in file SFINTO.DOC) and then run the sample problems described near the end of this documentation in the file SFEXMPL1.DOC.

If you are switching from the UNIX (or VAX) version of Poisson Superfish, the Automesh program should read your input files with little or no modification. A few variables from the UNIX version are no longer used in this version of the codes. Automesh will give you warning or error messages as appropriate with suggestions on how to modify your input file. Automesh recognizes either the ampersand (&) or the dollar sign (\$) as the namelist delimiter. The first REG namelist contains all problems variables for the rf and static field solvers.

It is helpful to have a list of the problem variables handy in printed form. For quick reference, print the <u>Poisson variables</u> table and the <u>Superfish variables</u> tables found in file SFINTRO.DOC.

B. List of the documentation files

Different parts of the Poisson Superfish documentation can be found in the following Microsoft Word files in the <u>LANL\Docs</u> directory.

SFTOC.DOC This file, containing the table of contents and suggestions for viewing and printing.

	てください。
SFINTRO.DOC	General information about the software installation, features in the codes, references, history, SF.INI configuration, and technical support.
SFFILES.DOC	Brief descriptions of all the input and output files used in the Poisson Superfish codes.
SFCODES.DOC	Information about the main programs Autofish, Automesh, Fish, CFish, Poisson, and Pandira.
SFPOSTP.DOC	Information about the postprocessor programs WSFplot, SFO, SF7, and Force.
SFCODES2.DOC	The automated tuning programs CCLfish, CDTfish, DTLfish, MDTfish, ELLfish, and RFQfish.
SFCODES3.DOC	General purpose plotting programs Quikplot and Tablplot, and utility programs Beta, Kilpat, List35, ConvertF, SF8, FScale, SegField, and SFOtable.
SFEXMPL1.DOC	Discussion of rf-field example files for Fish, CFish, and Autofish contained in the Examples\RadioFrequency subdirectories.
SFEXMPL2.DOC	Discussion of the static-field example files for Poisson and Pandira contained in the Examples\Magnetostatic and Examples\Electrostatic subdirectories.
SFEXMPL3.DOC	Discussion of the tuning-program example files contained in the Examples\CavityTuning subdirectories.
SFPHYS1.DOC	Theory of electrostatics and magnetostatics from John Warren's treatment in the 1987 Reference Manual
SFPHYS2.DOC	Properties of static magnetic and electric fields from John Warren's treatment in the 1987 Reference Manual
SFPHYS3.DOC	Boundary conditions and symmetries from John Warren's treatment in the 1987 Reference Manual
SFPHYS4.DOC	Numerical methods in Poisson and Pandira from John Warren's treatment in the 1987 Reference Manual
SFPHYS5.DOC	RF cavity theory from John Warren's treatment in the 1987

エラー! [ホーム] タブを使用して、ここに表示する文字列に Heading 2 を適用し

てください

C. Suggestions for viewing the documentation

Reference Manual

For viewing on your computer screen, we recommend using Normal view with the window maximized to fill the screen. Using Normal view (rather than Page Layout view) speeds up most operations in a large document. This is <u>not</u> a recommendation to use the Full Screen setting in the View menu since you will most likely want the use of the scroll bars. To switch to Normal View, check Normal in the View menu or click the leftmost button next to the bottom scroll bar.

エラー! [ホーム] タブを使用して、ここに表示する文字列に Heading 2 を適用して、ここに表示する文字列に Heading 2 を適用してください。

Use the Zoom command in the View menu to make the text comfortable to read on your monitor. In Word, you also can use the Percent box on the Standard toolbar. Type a number between 10 and 200 in the Percent box to choose a size other than the standard selections. Using the Wrap to Window setting described below in combination with a size a little larger than 100% makes fairly readable text.

Microsoft Word template and dictionary files

When displaying Poisson Superfish documentation and other Los Alamos software documentation, Microsoft Word uses two files in the LANL directory. The file LANLHELP.DOT is a Word template file containing styles, macros, and other settings. We use macros in LANLHELP.DOT when editing the documentation, but users reading the documentation do not need them.

The file LANLHELP.DIC is a custom dictionary file containing a list of terms that Word would ordinarily flag as misspelled words. This file contains proper names, accelerator jargon, program keywords, SF.INI settings, and mathematical variable names used in the Los Alamos documentation. If in Word 7 you see a large number of words underlined in red, then Word is probably not using the custom dictionary LANLHELP.DIC. You can add this file to the list of custom dictionary files in the Tools, Options, Spelling tab. We also recommend checking the boxes to ignore words in upper case and words with numbers.

2. Settings in Microsoft Word

You need only the Standard toolbar when viewing this document. To remove the other toolbars, leaving more room for text, click View, Toolbars... and remove the check marks on all but Standard, then click OK.

Click Tools, Options... and check the following settings. There are several items to inspect on the View tab. Under Nonprinting Characters, deselect all of the options (that is, remove the check marks). Under Show, select Wrap to Window, but deselect Draft Font, Picture Placeholders, Field Codes, and Bookmarks. Choose Never in the Field Shading box. On the Print tab, under Include with Document, be sure there is a check mark next to Drawing Objects, otherwise figures will not print. On the Save tab, you may wish to deselect Allow Fast Saves and Automatic Save Every xx Minutes.

You can toggle the table grid lines on and off by checking or unchecking Gridlines in the Table menu. This setting has no effect on printing. Tables in this document do not contain cell borders.

3. Settings in Microsoft Word Viewer

Click View, Options... and check the following settings. There are several items to inspect on the View tab. Under Nonprinting Characters, deselect all of the options (that is, remove the check marks). Under Show, select Wrap to Window, but deselect Draft Font, Picture Placeholders, Field Codes, and Bookmarks. Choose Never in the Field Shading box. Checking Table Gridlines displays a grid in tables, but has no effect on printing. Tables in this document do not contain cell borders.

On the Print tab, under Include with Document, be sure there is a check mark next to Drawing Objects, otherwise figures will not print.

4. Using the table of contents

This file, SFTOC.DOC, contains the master table of contents for the Poisson Superfish documentation. Each individual document file contains its own table of contents pertaining to the material in the file. Within each file, you can double click a page number in the table of contents to jump to that page in the file. In Word Viewer, use a single click. This feature is not available in SFTOC.DOC because of the method used to create the master table of contents.

If you print the entire document, you may wish to discard the separate tables of contents at the beginning of the other files. All the information is included in the master table of contents contained in this file.

Using the hypertext links

As you read this document on line, you will notice that some text is highlighted in blue. This highlighted text is a hypertext link (or hyperlink) to a location in this documentation that contains more detailed information of the subject. There are two type of links. The links within the same file use a GOTOBUTTON field and are not underlined. A link to another file uses a hyperlink inserted with the Internet Assistant for Microsoft Word. The links that refer to another file are underlined. Links to other files may not work in some older version of Word Viewer. They work in Microsoft Word if you have installed the Internet Assistant, which is available free from Microsoft.

Double-click in Word, or single-click in Word Viewer, in the blue text area to jump to that location. If the section you are jumping to is later in the same document, then the cursor will usually appear at the bottom of the screen. You will need to scroll up a few lines to see the material you are interested in. When jumping to a location earlier in the document, the cursor appears at the top of the screen.

We have included at the start of each file a list of all the bookmarks within the file. You can get to this list by pressing Ctrl-Home to move to the top of the file. Select the topic you are trying to find and click in the highlighted text. The sections on example files often include a link to another file that discusses a feature used in the example. That destination file usually includes a return link to the example. For example, the link in this sentence goes to the rf-field examples, in file SFEXMPL1.DOC, which includes a link to return here.

6. Using the Edit, Go To... menu

You can use Go To... in the Edit menu to jump to a specific page number or move forward or backward by some number of pages. Use this method when viewing the table of contents. Bring up the Go To... menu and select Page in the Go To What list on the left. Enter the page number in the text window, then press Go To button on the right.

Another way to use the Go To... dialog box is to jump to a bookmark in the text. The bookmarks correspond to the hypertext links. For convenience, the bookmarks have long, descriptive names. Scroll through the list, which is sorted alphabetically and when the

エラー! [ホーム] タブを使用して、ここに表示する文字列に Heading 2 を適用して、ここに表示する文字列に Heading 2 を適用して、ここに表示する文字列に Heading 2 を適用して、ここに表示する文字列に Heading 2 を適用して、ここに表示する文字列に Meading 2 を適用している Meading 2 を可能になる Meading

desired topic appears in the Enter Bookmark Name window, press the Go To button. You can also type in the name of a bookmark if you remember it from past use. Here are some shortcut methods for bringing up the Go To... dialog box:

- Hold down the Ctrl key and then press G, or
- Press the F5 key.

D. Printing sections of this documentation

You can print directly from Word or Word Viewer, but the pagination may change depending upon the default printer selected on your computer. (Page numbering in this document corresponds to a Hewlett Packard 5Si laser printer.)

Even if you do not print the entire document, we recommend that you print selected sections of the documentation for quick reference. For example, you may wish to print a portion of the Automesh documentation, since this code is the starting point for all Poisson Superfish problems. Most of your data entry will be <u>REG namelist</u>, <u>PO namelist</u>, and <u>MT namelist</u> variables in Automesh. You may find it helpful to have a list of the problem variables handy in printed form. There are separate alphabetically sorted lists of the <u>Poisson variables</u> and the <u>Superfish variables</u>.

There are several ways to print material from this document. You can print the entire document, the current page, a range of pages, or material that you highlight by holding down the mouse button and dragging over the text.

1. Printing the entire document

If three-hole paper is available, we recommend using it to save time punching holes in several hundred pages of paper. To print the entire document, open in turn each of the files listed above, Select Print in the File menu, then in the Page range section check the All setting, and click OK.

The first page of each file lists all the bookmarks within the file. Following the bookmarks is a table of contents for the file. The master table of contents in SFTOC.DOC includes all the information from each file's table of contents. These pages may not be useful as part of the printed document and may be discarded.

Page numbers appear centered at the bottom of the page. The first numbered page in each file starts after the file's table of contents. The first page will always be an odd number to accommodate printing on both sides of the page. As a result, the last page of some files may be blank.

a. Margin settings

We recommend using the default margin settings for US letter size paper of 1.00 inch top and bottom and 1.25 inches left and right. To change or check the margin settings, click File, Page Setup... and go to the Margins tab. We also recommend, if available, using a Hewlett Packard or compatible laser-jet printer. If this is not possible, then before printing anything, you may want to update the table of contents.

b. Printing on A4 paper

If you will be printing on A4 paper, you may want to use the margin settings 1.135 inches (28.8 mm) left and right, 1.00 inch (25.4 mm) top, and 1.69 inches (42.9 mm) bottom. These settings use the same "footprint" as the default settings for US letter paper. The pagination in the document should agree with the table of contents as distributed for most printers with 600-dot-per-inch resolution. Furthermore, tables that span more than one page should print correctly with new headings and titles at the top of continuation pages. Tables and figures that use nearly all of the 6-inch width between left and right margins should not generate error messages about margins from the printer.

2. Printing the current page

To print just the page you are viewing, click anywhere in the text to be sure the cursor is in the page you are viewing. Select Print in the File menu, then in the Page range section check the Current setting, and click OK.

Printing a range of pages

To print a range of pages, use the status bar at the bottom of the screen to identify the page numbers of the starting and ending page you want to print. Also note the section that the pages are in. For example, this paragraph should be in Sec 3. In other files, everything after the table of contents should be in Sec 2. Select Print in the File menu, then in the Page range section click in the data entry window next to Pages. Type "p" and the beginning page number followed immediately by "s" and the section number, then a dash and the ending page and section numbers (for example, p26s2-29s2). Click OK. The Pages selection will be chosen as soon as you start typing the page numbers.

4. Printing highlighted material

In the Print dialog box, printing a Selection refers to printing highlighted material. First, while holding down the left mouse button, drag the mouse over the material you wish to print. Release the mouse button. Select Print in the File menu, then in the Page range section check the Selection setting, and click OK.

E. Updating the table of contents

Your printer driver and default printer setup affects the pagination in a document. We recommend using the page layout settings discussed above and a Hewlett Packard or compatible LaserJet printer. If you notice that page numbers in the table of contents do not agree with page numbers printed from the other files, you can update the table of contents in this file. However, this is a somewhat involved process and it requires Microsoft Word. You cannot edit the document using Word Viewer.

Make sure that your default printer is set to the one you will use to print the documentation files. When the default printer is set properly, open each document in turn and note the page number of the last page in the file. As you open the next file in the sequence, place your cursor anywhere in the body of the text <u>after the table of contents</u>, then select Page Numbers... in the Insert menu. (The first few pages of each file are not numbered pages. The list of bookmarks and the table of contents are actually in a separate

section in the file. This section is for on-line viewing and is not intended to be part of the printed documentation.) In the Page Numbers dialog box, select Format... and add one to the last page in the previous file and type that number in the Start At box. (If you plan to print doubled-sided pages, add one or two as necessary to start each new file on an odd-numbered page.) Click OK twice. Continue this procedure until all the starting page numbers have been updated.

Finally, place the cursor anywhere in the table of contents in this file, press the right mouse button and select Update Field. In the dialog window that appears select Update Entire Table. The update may take several minutes on slower machines. Repeat the Update Field operation for the lists of tables and figures that follow the table of contents. If the dialog window appears for these two updates, select Update Entire Table.

エラー! [ホーム] タブを使用して、ここに表示する文字列に **Heading 2** を適用してください。