

USS Hornet Assembly Order

- ☐ Unbolt from temporary stand
- ☐ Final Dry Fit of Flight Deck
 - ☐ Align starting with Elevator 3 opening, then Elevator 2, then Elevator 1, then fwd port/stbd superstructure
 - ☐ Adjust bow overhang to be flush with hull, address gap between hull piece and flight deck:
 - ☐ Potentially trim flight deck ramp
 - ☐ Potentially slightly extend bow piece of hull with 3D printed piece
 - ☐ Fill gap where hull dips down slightly at bow
- ☐ Remove UNREP sponsons from stbd side
 - ☐ Remove all UNREP sponsons and sand/fill as needed
 - ☐ Design replacement deck extensions, print, install
- ☐ Paint upper hull Light Ghost Gray
 - ☐ Gloss Coat
 - ☐ Small "12" decals, draft mark decals applied
 - ☐ Washes for details on the hull
 - ☐ Flat coat
 - ☐ Running rust details
 - ☐ Install props, shafts and rudder
- ☐ Paint Superstructure Light Ghost Gray
 - ☐ Fit out as much of the superstructure as possible at this point: ladders, railings, walkways etc. before paint
 - ☐ Paint Coat
 - ☐ Gloss Coat
 - ☐ Washes for details on the hull
 - ☐ Flat coat
- ☐ Finish Internal Superstructure (Hangar Deck Interior Bulkheads)
 - ☐ Try subtle washes on painted parts; if not working, gloss coat
 - ☐ Subtle wash
 - ☐ Possible semi gloss top coat
 - ☐ Decals/Hornet Scoreboard installed
- ☐ Paint Hangar Deck Deck Gray
 - ☐ Mainly touch up where work was done on the deck
- ☐ Mount to final base
 - ☐ Install plaque and squadron logos on base

- ☐ Run wiring from switch to inside hull up through hangar deck
- ☐ Bolt hull to base
- ☐ Apply masking to protect base while fitting out
- ☐ Install Hangar Deck
 - ☐ Secure deck to hull, wiring exposed for overhead
- ☐ Install Superstructure
 - ☐ Install external sections first
 - ☐ Pay attention to straightness of each section, especially Elevator 2 Superstructure aft, which has a tendency to sag. Perhaps put flight deck on temporarily and secure this section to the deck with tape
 - ☐ Install internal bulkheads next
 - ☐ Install Elevator 2 and Elevator 3 in lowered positions at hangar deck level
 - ☐ Fit out the superstructure
- ☐ Complete Hangar Deck
 - ☐ Complete aircraft: prime, paint decals, position and secure to deck
 - ☐ Complete personnel: prime, paint, position and secure to deck
 - ☐ Consider adding small details where noticeable: ladders, stencils, etc.
- ☐ Design Hangar Deck Overhead
 - ☐ Need all interior bulkheads in place first
 - ☐ Measure and build in sections
 - ☐ Account for LED holes and wiring runs above
 - ☐ Print and fit each section at a time
 - ☐ Prime, paint, install LEDs and dry fit each section
 - ☐ Connect all wiring to the LED hookup wires
 - ☐ Test LEDs working
 - ☐ Solder connections
 - ☐ Test again
 - ☐ With all LEDs verified functional, secure the overheads
- ☐ Paint Flight Deck
 - ☐ Apply overall primer coat
 - ☐ Apply base coat of lightened deck gray
 - ☐ Apply tiedown paint stencils
 - ☐ Cut into 3 sections
 - ☐ Spray darker gray for the tiedowns
 - ☐ Remove tiedown stencils
 - ☐ Apply the cricut stencil masks:
 - ☐ Cut into 3 sections
 - ☐ Apply each section individually
 - ☐ Spray very light coat of the lightened deck gray to seal the masks

- ☐ Spray the markings (flat white with very slight gray weathering to the mix)
- ☐ Consider subtle weathering coats to the whole deck, especially at wear areas (landing area, #3 wire, catapults, etc)
- ☐ Touch up/evaluate gloss coat for wash
- ☐ If gloss coated, wash and then flat final coat
- ☐ Install Flight Deck
 - ☐ Use a slow cure epoxy, but be sure we have good proportioning and mixing!
 - ☐ Align starting with Elevator 3 opening, then Elevator 2, then Elevator 1, then fwd port/stbd superstructure
 - ☐ Set aside to dry with light weights holding the deck down
- ☐ Assemble Island
 - ☐ Finish cleanup work
 - ☐ Clean resin
 - ☐ Prime resin
 - ☐ Paint island light ghost gray
 - ☐ Gloss coat
 - ☐ Decals
 - ☐ Washes
 - ☐ Flat coat
 - ☐ Railings, ladders, hatches, etc
 - ☐ Build each radar, prime then paint
 - ☐ Install to mast if practicable; otherwise install mast to island then install radars
 - ☐ Ideally, island is installed as a completed subassembly with all railings, ladders, rigging, masts, radars, etc in place
 - ☐ Mast is flat black, as are radars, other than URN-3, which is gray
- ☐ Install Island
 - ☐ Slow cure epoxy, ensure coat is thin to avoid ooze out
- ☐ Outfit Island
 - ☐ Arrange aircraft, crews, tractors and tow bars, etc