

# PARTS CATALOGUE

#### STOKER

MODELS S-30, S-35 and S-45
(Parts listed are used on all models except where noted)

As used with the AP-700-AP-900-AP-1300


Parts ordered in error and then returned for credit will be subject to a 10% handling charge and applied at the discretion of the company.

Minimum acceptable parts order One Dollar.

All prices are net F.O.B. factory and subject to change without notice.


ELECTRIC FURNACE-MAN, INC. EMMAUS, PA.

## STOKER ASSEMBLY REAR VIEW OF FAN AND BURNER MODELS S-30, S-35, S-45




STOKER MODELS \$30, \$35, \$45


### STOKER - TRANSFER AND DRIVE ASSEMBLY MODELS S-30, S-35, S-45



PLAN & SECTIONAL VIEW
STOKER MODELS S30, S35,S45



### ND SECTION OF FAN AND BURNER ASSEMBLY MODELS S-30 S-35, S-45



SIDE VIEW & SECTION OF FAN & BURNER ASSEMBLY

STOKER MODELS \$30,835,845

# ELECTRIC FURNACE-MAN, INC. EMMAUS, PA.

#### STOKER PARTS LIST MODELS S-30, S-35, S-45

### (Parts listed are used on all models except where noted)

PART NO.	DESCRIPTION	NUMBER REQUIRED
S20-110	Motor coupling complete	1
S20-120	Reducing unit	1
S30-128	Feed control thumb screw	1
S30-130	Connecting rod (\$30 & \$35)	1
S45-130	Connecting rod (S45 only)	
S20-132	Crank Assembly with set screws (S30)	1
S22-132	Crank assembly with set screws (\$35)	1
S45-132	Crank assembly with set screws (S45)	1
S20-133	Crank pin	
137	Washer for connecting rod pin	
S20-138	Retaining clip for connecting rod pin	
UF- 142	One pint can, reducing unit oil	
142 Qt.	Quart can of reducing unit oil	
142 Ga.	One gallon can of reducing unit oil	
S20-151	Ratchet drum	
S30-152	Feed lever assy., with conn. rod stud	
S30-153	Bin worm bearing w/ bushing	
S30-154	Drive sprocket (14 teeth)	
S20-156	Clutch retaining ring	
S30-157	Drive pawl (w/ stud head not recessed)	
S30-157-N	Drive pawl (w/ stud head recessed)	
S30-159	Oil wiper pad	1
S30-161	Check pawl	1
н- 164	Shear collar	
н- 165	Shear pin	1
S20-168	Clutch washer	1
S30-168	Spacer for feed control collar	
S30-169-N	Oil reservoir	1
S30-171	Drive pawl stud & nut (head not recessed in drive	_
	paw1)	1
S30-171-N	Drive pawl stud & nut Head recessed in drive	1
170	paw1)	
H- 172	One pint can of oil (oil reservoir)	• • • • • 1
S30-174	Drive gear (30 tooth)	1
S30-208	Spacer for driven sprocket	1
S30-209-1/2	Oil drip washer	1
S30-209-5/8	Oil drip washer	
H2R-256	Retaining slip	
S30-269-2	Bin feed drive worm & shaft assy. (2 ft)	
S30-269-4	Bin feed drive worm & shaft assy. (4 ft)	1
S30-270-2	Bin feed worm & shaft assy. (2 ft)As	req'd
S30-270-4	Bin feed worm & shaft assy. (4 ft)As	req'd
S30-271	Bin feed worm shaft couplingAs	req'd
S30-273	2-1/2" pipe support w/ 2 set screws	1
S30-276	Coal pipe coupling assy	1
S30-285-N	Idler shaft	$\dots$ 1
S30-286	Driven sprocket (21 teeth)	$\dots$ 1
S30-287	Drive chain (31 links)	1
S30-295-N	Driven gear (24 Teeth)	1
296	Bronze thrust washer (used behind driven	1

	KEQOINE
16A-301-R	Air chamber complete (including cleanout
	rollers, links, & 16A-1394) S30 only1
S35-301-R	Air chamber complete (including cleanout
	rollers, links & S35-1394) S35, S451
16A-302/6N	Burner plate holder & burner plates compl.
	(including 16A-303, 16A-304/6N & 16A-312)
	S30 only1
20A-302/6N	Burner plate holder & burner plates compl.
	(including 20A-303. 20A-304/6N & 20A-312)
	S35, S451
16A-303	Burner plate holder (S30 only)1
20A - 303	Burner plate holder (s35, S45)1
16A-304-N	Burner plate Section only, incl bolt, \$306
20A-304-N	Burner plate section only, incl bolt, S35, S45
16A-304/6N	Burner plate assy. (incl. bolts & 6 of 16A-304-N)
204 207 /CM	\$30 only
20A-304/6N	Burner plate assy. (incl. bolts & 6 of 20A-304-N)
UFR-306	\$35, \$45
UFR-306 UFR-307	Plain roller link assy. (used on air chamb)9
16A-307	Slotted roller link assy. (used on air chamb)
UFR-308	Roller (used on air chamber)10
311- 18	Extension ring (S30)
20A-311	Extension ring complete (S35)
20B-311	Extension ring complete (S45)
16A-312	Burner plate packing (S30)
20A-312	Burner plate packing (S35, S45)
16A-313	Burner clip only
16A-315-S	Cleanout rotor sleeve w/ plug only
16A-315-L	Cleanout rotor only1
S30-330	Coal pipe (2 1/2" O.D. x 14-7/32" 1g) S30
S35-330	Coal pipe (2 1/2" O.D. x 15-1/32" 1g) S30, S45
S30-330-42 1/2	Bin Feed pipe (2 1/2" Pipe x 42 1/2" lg)
S30-331	Tie rod compl. (3/8" Dia. x 12" lg) S30
S35-331	Tie rod compl. (3/8" Dia. x 12-13/16" lg) S35, S452
S30-332	Coal worm & shaft assy. (burner) \$301
S35-332	Coal worm & shaft assy. (burner) S35, S451
S30-339	Air pipe1
S30-346	Check pawl spring1
S30-350	Transfer housing (old style)1
S30-350-N	Transfer housing (new style)1
S30-351	Feed control collar assy. (S30)1
S35-351	Feed control collar assy. (\$35, \$45)1
\$30 <b>-</b> 354	Check pawl stud1
S30-356	Cover plate (Transfer Housing)
S30-371	Coal worm bearing w/ part HR-372 & groov pin
HR- 372	Bronze bushing only (must be drilled after
020 270	assembly for grease hole)
S30-372	Bronze bushing only (must be drilled after
161 205	assembly for grease hole)
16A-385 16A-391	Burner gear box assy. complete
16A <b>-</b> 391	Gear shaft pinion
S30-401	Fan assembly (S30)
\$35-401	Fan assembly (S35)
S45-401	Fan assembly (S45)
S30-408	Fan cover plate
S30-409-N	Fan housing
· · · · ·	

PART NO.	DESCRIPTION	NUMBER Required
S30-410	Mounting bracket (w/ air indicator plate, old style)	1
S30-410-N	Mounting bracket (w/ air indicator plate, new style)	
S20-441	Coal worm crank	
UFR-483	Air pipe adapter S30 only	1
S35-483	Air pipe adapter, S35, S45	
S30-484	Coal pipe adapter	1
L- 939	One pound can of alemite grease	1
16A-1394	Burner gooseneck assembly (S30)	1
S35-1394	Burner gooseneck assembly (S35, S45)	
OB- 4042	Motor, 110V, 60 Cycle A.C., 1/6 H.P	1
6570	Alemite gun	1

PRODUCTS OF ELECTRIC FURNACE-MAN INC., EMMAUS, PA.

EFM ELECTRIC BASEBOARD, WALL AND FLOOR INSERT HEATING UNITS

EFM OIL BURNERS BOILER AND FURNACE BURNER UNITS

EFM GAS FIRED BOILER AND FURNACE BURNER UNITS

EFM ANTHRACITE STOKERS, BOILER AND FURNACE STOKER UNITS