


Eagle 1003 Parts List



1. Charging

Connect the lithium battery to a 5V USB charger (prepared by yourself) through the Type-C cable in this kit.



2. Pairing



3. Remote Control

Unlock Pull the sticks simultaneously inward as shown in the figure. When the propellers spin at a low speed, the drone is unlocked.





Note: After the drone is unlocked, please keep a safe distance from the propellers.

Takeoff Press the "●" button, and the drone will take off. **Landing** Press the "●" button, and the drone will land.



Flying Use sticks to remote control your drone.




4. Coding

① Use your laptop or computer to visit the WhalesBot official website (<https://www.whalesbot.ai/resources/educators>). Download and install the "Drone" software.



② Double-click the "🔧" icon on the desktop to run the software.


③ Select the drone type (EG 103).




④ Pair the remote control with your drone. Then, use the Type-C cable to connect the remote control to your laptop or computer.



⑤ Click the "🔧" icon in the top toolbar of the software.




⑦ Click the "Run" icon to run the program.



⑥ Build a program. Then, click the "Download" icon to download the program to the drone's controller.



⑧ To stop the drone when it is flying, click the "🛑" icon for a quick landing or the "STOP" icon for an emergency landing.



Eagle 1003

Quick Start



Programmable


QR code camera

Add-ons available


Safety cover



Buttons and Sticks



Drone



Warnings

1. Keep away from the high-speed rotating propellers to avoid injury.
2. The bottom of the drone contains heating components. Do not touch them to avoid burns.
3. To comply with electromagnetic environment requirements for aviation radio stations, you cannot use any type of remote controls within a 5000-meter radius centered on the airport runway. Also, during periods and in areas where national authorities issue radio control orders, you cannot use remote controls.
4. Use only the provided standard batteries. Do not short-circuit the battery terminals.
5. Retain the packaging and manual as they contain important information.
6. Use only USB chargers that comply with FCC/CE regulations, with an output of 5V/1A or higher.
7. To charge the lithium battery, remove it from the drone and charge it separately using a USB charger. The battery cannot be charged while the drone is powered on.
8. After flight, the battery temperature may be high. Before charging, wait for the battery to cool to room temperature.
9. The battery should be charged within a temperature range of 5°C to 40°C. Charging in an ideal environment temperature (22°C to 28°C) can significantly extend the battery's lifespan.
10. If the battery power is significantly low after a flight, charge it to 30%-60% before storing it for a prolonged period. Otherwise, the battery may get broken.
11. If the battery will not be used for more than 10 days, discharge it to 40%-65% before storage to extend its lifespan.

Flight Restrictions

* By using this drone, you acknowledge and agree that you are responsible for all consequences arising from its operation.

1. The drone is suitable for indoor flight, with a maximum altitude of 3 meters. The drone will automatically maintain an altitude of no more than 3 meters.
2. The visual positioning system may be affected by light intensity and surface texture, potentially causing it to fail. When operating the drone, please take these factors into consideration.

Laws and Regulations

1. Do not operate the drone near manned aircraft. Land the drone immediately if necessary.
2. Do not use the drone in densely populated or building-intensive areas, including cities, sports stadiums, exhibitions, and concerts.
3. Make sure that the drone does not interfere with manned aircraft on their flight path. Stay alert to avoid other aircraft.
4. Do not operate the drone in legally defined no-fly zones, including airports, border lines, power stations, hydroelectric stations, prisons, major traffic hubs, government buildings, military facilities, and major cities.
5. Do not fly the drone above the highest allowed altitude.
6. Make sure that the drone stays within your sight during flight. If necessary, ask an observer to help monitor the drone's position.
7. Do not use the drone to carry any illegal or hazardous items.
8. Make sure that you fully understand the purpose of your flight (e.g., entertainment, public service, or commercial use). Before flying, obtain the necessary permits from the relevant authorities. If needed, consult local legal professionals for detailed explanations on the classification of flight purposes. Please note that in some countries or regions, drone flight for commercial use is prohibited.
9. When using the drone for photography, always respect the privacy rights of others. Do not use this product for unauthorized surveillance of hotels, individuals, groups, activities, performances, exhibitions, or buildings.
10. Please note that in some countries or regions, non-commercial use of a drone or camera to record or photograph individuals, groups, hotels, performances, or exhibitions may infringe on copyright, privacy rights, or other legal rights. In some countries or regions, small aircraft are also prohibited from any commercial activities.



Scan code for details and user manual
<https://www.whalesbot.ai/products/drone>

Shanghai WhalesBot Technology Co., Ltd.
No.188, Zixu Road, Minhang District, Shanghai
+008621-33585660
www.whalesbot.ai