UNIVERSITY OF ABERDEEN

SESSION 2018-19

EM40JN

Degree Examination in EM40JN Heat and Momentum Transfer 7th December 2018 9 am – 11 am

PLEASE NOTE THE FOLLOWING

- (i) You **must not** have in your possession any material other than that expressly permitted in the rules appropriate to this examination. Where this is permitted, such material **must not** be amended, annotated or modified in any way.
- (ii) You **must not** have in your possession any material that could be determined as giving you an advantage in the examination.
- (iii) You **must not** attempt to communicate with any candidate during the exam, either orally or by passing written material, or by showing material to another candidate, nor must you attempt to view another candidate's work.
- (iv) You **must not** take to your examination desk any electronic devices such as mobile phones or other "smart" devices. The only exception to this rule is an approved calculator.

Failure to comply with the above will be regarded as cheating and may lead to disciplinary action as indicated in the Academic Quality Handbook.

Notes:

- (i) Candidates ARE permitted to use an approved calculator.
- (ii) Candidates ARE NOT permitted to use the Engineering Mathematics Handbook.
- (iii) Candidates ARE NOT permitted to use GREEN or RED pen in their exam booklet.
- (iv) Data sheets are attached to the paper.

Candidates must attempt *ALL* questions. Question 1 and 3 are worth 33 marks. Question 2 is worth 34 marks.

Question 1

In a plate heat-exchanger (see Fig. 1), water is heated by forcing it between alternating plates and heat is exchanged through the walls with a hot process stream. In order to design such an exchanger, we need to know what the relationship is between pressure drop, flow velocity, and volumetric flow-rate.




Figure 1: A plate heat exchanger (left) and the simplification to steady state, pressure driven flow between two horizontal plates (right).

You may neglect the effect of heat transfer on the flow. Water is incompressible and Newtonian to a good approximation. For simplicity, you can also assume that the flow is laminar.

a) Simplify the continuity equation for this system:

$$\frac{\partial \rho}{\partial t} = -\nabla \cdot \rho \, \mathbf{v}$$

What does your result state about the flow velocity in the *x*-direction? [7 marks]

b) Simplify the *x*-component of the Cauchy momentum equation:

$$\rho \frac{\partial \mathbf{v}}{\partial t} = -\rho \, \mathbf{v} \cdot \nabla \mathbf{v} - \nabla \cdot \boldsymbol{\tau} - \nabla \, \boldsymbol{\rho} + \rho \, \boldsymbol{g}$$

Derive the following balance expression for the flow velocity v_x as a function of the pressure drop and position y: [10 marks]

$$\mu \frac{\partial^2 V_x}{\partial y^2} = \frac{\partial p}{\partial x}$$

c) Derive the following expression for the velocity v_x as a function of y using the no-slip boundary condition at the plate surfaces ($v_x = 0$ at y = 0 and y = H). [10 marks]

$$V_{x} = \frac{p_{out} - p_{in}}{2 \mu L} (y^2 - H y)$$

d) Integrate the velocity over the plate height and width to prove the following expression for the volumetric flow of liquid through the gap as a function of pressure drop:
 [6 marks]

$$\dot{V}_{x} = \frac{ZH^{3}}{12\,\mu} \frac{\Delta P}{L}$$

[Question total: 33 marks]

Question 2

The temperature profile inside a nuclear fuel rod is needed as part of the design calculations for a reactor. The rod is a cylinder with a radius, R, and is assumed to be composed of a homogeneous fuel which is producing heat with the following profile:

$$\sigma_{heat} = \sigma^0 \left(1 + b \left(\frac{r}{R} \right)^2 \right)$$

a) What assumption has been made to derive the energy balance equation below?

$$\rho \, C_p \frac{\partial T}{\partial t} = -\rho \, C_p \, \mathbf{v} \cdot \nabla \, T - \nabla \cdot \mathbf{q} - \tau : \nabla \, \mathbf{v} - p \, \nabla \cdot \mathbf{v} + \sigma_{energy}$$

[3 marks]

b) Simplify the energy balance equation to the following expression:

$$\frac{1}{r}\frac{\partial}{\partial r}(r\,q_r) = \sigma_{energy}$$

Clearly state any assumptions you use.

[14 marks]

c) Derive the expression below for the heat flux from the simplified energy balance.

$$q_r = \sigma^0 \left(\frac{r}{2} + b \frac{r^3}{4 R^2} \right)$$

Clearly state any assumptions you use.

[8 marks]

d) Derive the following expression for the temperature profile.

$$T - T_0 = \frac{\sigma^0}{k} \left(\frac{R^2 - r^2}{4} + b \frac{R^4 - r^4}{16 R^2} \right)$$

You will need to select an appropriate boundary condition and give the meaning of the constant T_0 . [9 marks]

[Question total: 34 marks]

Question 3

- a) In a manufacturing facility, 10 cm diameter brass balls initially at 121°C are quenched in a water bath at 49°C for a period of 2 min and at a rate of 120 balls per minute. If the average convective heat transfer coefficient is 238 W m⁻²° C⁻¹, determine:
 - i) Temperature of the balls after quenching, and;

[10 marks]

ii) Rate (in kW) at which heat needs to be removed from the water in order to keep its temperature constant at 49°C. [4 marks]

Given properties of brass: $k = 111 \text{ W m}^{-1} \cdot \text{K}^{-1}$, $\rho = 8552 \text{ kg m}^{-3}$ and $C_p = 285 \text{ J kg}^{-1} \cdot \text{K}^{-1}$

- b) Consider an oil-to-oil double-pipe heat exchanger whose flow arrangement is not known. The temperature measurements indicate that the cold oil enters at 20°C and leaves at 55°C, while the hot oil enters at 80°C and leaves at 45°C.
 - i) Is this parallel-flow or counter-flow heat exchanger? Why? [5 marks]
 - ii) Assuming the mass flow rates of both fluids to be identical, determine the effectiveness of this heat exchanger. [5 marks]
- c) A cross-flow air-to-water heat exchanger with effectiveness of 0.65 is used to heat water with hot air. Water enters the heat exchanger at 20° C at a rate of 5 kg s⁻¹, while air enters at 100° C at a rate of 12 kg s⁻¹. If the overall heat transfer coefficient based on the water side is $200 \text{ W m}^{-2\circ}\text{C}^{-1}$, determine the heat transfer surface area of the heat exchanger on the water side. Given $C_{p,\text{water}} = 4180 \text{ J kg}^{-1\circ}\text{C}^{-1}$ and $C_{p,\text{air}} = 1010 \text{ J kg}^{-1\circ}\text{C}^{-1}$. [9 marks]

[Question total: 33 marks]

END OF PAPER

DATASHEET

General balance equations:

$$\frac{\partial \rho}{\partial t} = -\nabla \cdot \rho \, \mathbf{v} \qquad \qquad \text{(Mass/Continuity)} \quad (1)$$

$$\frac{\partial C_A}{\partial t} = -\nabla \cdot \mathbf{N}_A + \sigma_A \qquad \qquad \text{(Species)} \quad (2)$$

$$\rho \frac{\partial \mathbf{v}}{\partial t} = -\rho \, \mathbf{v} \cdot \nabla \mathbf{v} - \nabla \cdot \boldsymbol{\tau} - \nabla \rho + \rho \, \mathbf{g} \qquad \qquad \text{(Momentum)} \quad (3)$$

$$\rho \, C_\rho \frac{\partial T}{\partial t} = -\rho \, C_\rho \, \mathbf{v} \cdot \nabla \, T - \nabla \cdot \mathbf{q} - \boldsymbol{\tau} : \nabla \, \mathbf{v} - \rho \, \nabla \cdot \mathbf{v} + \sigma_{energy} \qquad \text{(Heat/Energy)} \quad (4)$$

In Cartesian coordinate systems, ∇ can be treated as a vector of derivatives. In curve-linear coordinate systems, the directions \hat{r} , $\hat{\theta}$, and $\hat{\phi}$ depend on the position. For convenience in these systems, look-up tables are provided for common terms involving ∇ .

Cartesian coordinates (with index notation examples) where s is a scalar, v is a vector, and τ is a tensor.

$$\nabla \mathbf{s} = \nabla_{i} \mathbf{s} = \left[\frac{\partial \mathbf{s}}{\partial \mathbf{x}}, \frac{\partial \mathbf{s}}{\partial \mathbf{y}}, \frac{\partial \mathbf{s}}{\partial \mathbf{z}} \right]$$

$$\nabla^{2} \mathbf{s} = \nabla_{i} \nabla_{i} \mathbf{s} = \frac{\partial^{2} \mathbf{s}}{\partial \mathbf{x}^{2}} + \frac{\partial^{2} \mathbf{s}}{\partial \mathbf{y}^{2}} + \frac{\partial^{2} \mathbf{s}}{\partial \mathbf{z}^{2}}$$

$$\nabla \cdot \mathbf{v} = \nabla_{i} v_{i} = \frac{\partial v_{x}}{\partial \mathbf{x}} + \frac{\partial v_{y}}{\partial \mathbf{y}} + \frac{\partial v_{z}}{\partial \mathbf{z}}$$

$$\nabla \cdot \boldsymbol{\tau} = \nabla_{i} \tau_{ij}$$

$$\left[\nabla \cdot \boldsymbol{\tau} \right]_{x} = \frac{\partial \tau_{xx}}{\partial \mathbf{x}} + \frac{\partial \tau_{yx}}{\partial \mathbf{y}} + \frac{\partial \tau_{zx}}{\partial \mathbf{z}}$$

$$\left[\nabla \cdot \boldsymbol{\tau} \right]_{y} = \frac{\partial \tau_{xy}}{\partial \mathbf{x}} + \frac{\partial \tau_{yy}}{\partial \mathbf{y}} + \frac{\partial \tau_{zy}}{\partial \mathbf{z}}$$

$$\left[\nabla \cdot \boldsymbol{\tau} \right]_{z} = \frac{\partial \tau_{xz}}{\partial \mathbf{x}} + \frac{\partial \tau_{yz}}{\partial \mathbf{y}} + \frac{\partial \tau_{zz}}{\partial \mathbf{z}}$$

$$\mathbf{v} \cdot \nabla \mathbf{v} = \mathbf{v}_{i} \nabla_{i} \mathbf{v}_{j}$$

$$\left[\mathbf{v} \cdot \nabla \mathbf{v} \right]_{x} = \mathbf{v}_{x} \frac{\partial v_{x}}{\partial \mathbf{x}} + \mathbf{v}_{y} \frac{\partial v_{x}}{\partial \mathbf{y}} + \mathbf{v}_{z} \frac{\partial v_{x}}{\partial \mathbf{z}}$$

$$\left[\mathbf{v} \cdot \nabla \mathbf{v} \right]_{y} = \mathbf{v}_{x} \frac{\partial v_{y}}{\partial \mathbf{x}} + \mathbf{v}_{y} \frac{\partial v_{y}}{\partial \mathbf{y}} + \mathbf{v}_{z} \frac{\partial v_{y}}{\partial \mathbf{z}}$$

$$\left[\mathbf{v} \cdot \nabla \mathbf{v} \right]_{z} = \mathbf{v}_{x} \frac{\partial v_{z}}{\partial \mathbf{x}} + \mathbf{v}_{y} \frac{\partial v_{z}}{\partial \mathbf{y}} + \mathbf{v}_{z} \frac{\partial v_{z}}{\partial \mathbf{z}} \right]$$

Cylindrical coordinates

where s is a scalar, \mathbf{v} is a vector, and τ is a tensor. All expressions involving τ are for symmetrical τ only.

$$\nabla s = \left[\frac{\partial s}{\partial r}, \frac{1}{r} \frac{\partial s}{\partial \theta}, \frac{\partial s}{\partial z} \right]$$

$$\nabla^2 s = \frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial s}{\partial r} \right) + \frac{1}{r^2} \frac{\partial^2 s}{\partial \theta^2} + \frac{\partial^2 s}{\partial z^2}$$

$$\nabla \cdot \mathbf{v} = \frac{1}{r} \frac{\partial}{\partial r} (r \, v_r) + \frac{1}{r} \frac{\partial v_\theta}{\partial \theta} + \frac{\partial v_z}{\partial z}$$

$$[\nabla \cdot \boldsymbol{\tau}]_r = \frac{1}{r} \frac{\partial}{\partial r} (r \, \tau_{rr}) + \frac{1}{r} \frac{\partial \tau_{r\theta}}{\partial \theta} - \frac{1}{r} \tau_{\theta\theta} + \frac{\partial \tau_{rz}}{\partial z}$$

$$[\nabla \cdot \boldsymbol{\tau}]_\theta = \frac{1}{r} \frac{\partial \tau_{\theta\theta}}{\partial \theta} + \frac{\partial \tau_{r\theta}}{\partial r} + \frac{2}{r} \tau_{r\theta} + \frac{\partial \tau_{\thetaz}}{\partial z}$$

$$[\nabla \cdot \boldsymbol{\tau}]_z = \frac{1}{r} \frac{\partial}{\partial r} (r \, \tau_{rz}) + \frac{1}{r} \frac{\partial \tau_{\thetaz}}{\partial \theta} + \frac{\partial \tau_{zz}}{\partial z}$$

$$[\mathbf{v} \cdot \nabla \mathbf{v}]_r = \mathbf{v}_r \frac{\partial \mathbf{v}_r}{\partial r} + \frac{\mathbf{v}_\theta}{r} \frac{\partial \mathbf{v}_r}{\partial \theta} - \frac{\mathbf{v}_\theta^2}{r} + \mathbf{v}_z \frac{\partial \mathbf{v}_r}{\partial z}$$

$$[\mathbf{v} \cdot \nabla \mathbf{v}]_\theta = \mathbf{v}_r \frac{\partial \mathbf{v}_\theta}{\partial r} + \frac{\mathbf{v}_\theta}{r} \frac{\partial \mathbf{v}_\theta}{\partial \theta} + \frac{\mathbf{v}_r \, \mathbf{v}_\theta}{r} + \mathbf{v}_z \frac{\partial \mathbf{v}_\theta}{\partial z}$$

$$[\mathbf{v} \cdot \nabla \mathbf{v}]_z = \mathbf{v}_r \frac{\partial \mathbf{v}_z}{\partial r} + \frac{\mathbf{v}_\theta}{r} \frac{\partial \mathbf{v}_z}{\partial \theta} + \mathbf{v}_z \frac{\partial \mathbf{v}_z}{\partial z}$$

Spherical coordinates

where s is a scalar, \mathbf{v} is a vector, and τ is a tensor. All expressions involving τ are for symmetrical τ only.

$$\nabla S = \left[\frac{\partial S}{\partial r}, \frac{1}{r} \frac{\partial S}{\partial \theta}, \frac{1}{r \sin \theta} \frac{\partial S}{\partial \phi} \right]$$

$$\nabla^{2}S = \frac{1}{r^{2}} \frac{\partial}{\partial r} \left(r^{2} \frac{\partial S}{\partial r} \right) + \frac{1}{r^{2} \sin \theta} \frac{\partial}{\partial \theta} \left(\sin \theta \frac{\partial S}{\partial \theta} \right) + \frac{1}{r^{2} \sin^{2} \theta} \frac{\partial^{2} S}{\partial \phi^{2}}$$

$$\nabla \cdot \mathbf{v} = \frac{1}{r^{2}} \frac{\partial}{\partial r} \left(r^{2} v_{r} \right) + \frac{1}{r \sin \theta} \frac{\partial}{\partial \theta} \left(v_{\theta} \sin \theta \right) + \frac{1}{r \sin \theta} \frac{\partial v_{\phi}}{\partial \phi}$$

$$\left[\nabla \cdot \boldsymbol{\tau} \right]_{r} = \frac{1}{r^{2}} \frac{\partial}{\partial r} \left(r^{2} \tau_{rr} \right) + \frac{1}{r \sin \theta} \frac{\partial}{\partial \theta} \left(\tau_{r\theta} \sin \theta \right) + \frac{1}{r \sin \theta} \frac{\partial \tau_{r\phi}}{\partial \phi} - \frac{\tau_{\theta\theta} + \tau_{\phi\phi}}{r}$$

$$\left[\nabla \cdot \boldsymbol{\tau} \right]_{\theta} = \frac{1}{r^{2}} \frac{\partial}{\partial r} \left(r^{2} \tau_{r\theta} \right) + \frac{1}{r \sin \theta} \frac{\partial}{\partial \theta} \left(\tau_{\theta\theta} \sin \theta \right) + \frac{1}{r \sin \theta} \frac{\partial \tau_{\phi\phi}}{\partial \phi} + \frac{\tau_{r\theta}}{r} - \frac{\cot \theta}{r} \tau_{\phi\phi}$$

$$\left[\nabla \cdot \boldsymbol{\tau} \right]_{\phi} = \frac{1}{r^{2}} \frac{\partial}{\partial r} \left(r^{2} \tau_{r\phi} \right) + \frac{1}{r} \frac{\partial \tau_{\theta\phi}}{\partial \theta} + \frac{1}{r \sin \theta} \frac{\partial \tau_{\phi\phi}}{\partial \phi} + \frac{\tau_{r\theta}}{r} + \frac{2 \cot \theta}{r} \tau_{\theta\phi}$$

$$\left[\mathbf{v} \cdot \nabla \mathbf{v} \right]_{r} = v_{r} \frac{\partial v_{r}}{\partial r} + \frac{v_{\theta}}{r} \frac{\partial v_{r}}{\partial \theta} + \frac{v_{\phi}}{r \sin \theta} \frac{\partial v_{\theta}}{\partial \phi} + \frac{v_{r}}{v_{\theta}} - v_{\phi}^{2} \cot \theta}{r}$$

$$\left[\mathbf{v} \cdot \nabla \mathbf{v} \right]_{\theta} = v_{r} \frac{\partial v_{\theta}}{\partial r} + \frac{v_{\theta}}{r} \frac{\partial v_{\theta}}{\partial \theta} + \frac{v_{\phi}}{r \sin \theta} \frac{\partial v_{\theta}}{\partial \phi} + \frac{v_{r}}{v_{\theta}} \frac{v_{\theta} + v_{\phi}}{v_{\phi} \cot \theta}}$$

$$\left[\mathbf{v} \cdot \nabla \mathbf{v} \right]_{\phi} = v_{r} \frac{\partial v_{\phi}}{\partial r} + \frac{v_{\theta}}{r} \frac{\partial v_{\phi}}{\partial \theta} + \frac{v_{\phi}}{r \sin \theta} \frac{\partial v_{\phi}}{\partial \phi} + \frac{v_{r}}{v_{\theta}} \frac{v_{\phi} + v_{\phi}}{v_{\phi} \cot \theta}}$$

Rectangular		Cylindrical			Spherical			
q_x	$-k\frac{\partial T}{\partial x}$ q_r		$-k\frac{\partial T}{\partial r}$		$-k\frac{\partial T}{\partial r}$			
q_y	$-k\frac{\partial T}{\partial y}$	q_{θ}	$-k\frac{1}{r}\frac{\partial T}{\partial \theta}$	$q_{ heta}$	$-k\frac{1}{r}\frac{\partial T}{\partial \theta}$			
q_z	$-k\frac{\partial T}{\partial z}$	q_z	$-k rac{\partial T}{\partial z}$	$oldsymbol{q}_{\phi}$	$-k\frac{1}{r\sin\theta}\frac{\partial T}{\partial\phi}$			
$ au_{ extit{XX}}$	$-2\mu\frac{\partial v_x}{\partial x} + \mu^B\nabla\cdot\boldsymbol{v}$	$ au_{ extit{rr}}$	$-2\mu \tfrac{\partial \textit{V}_r}{\partial r} + \mu^{\textit{B}}\nabla\cdot\pmb{v}$	$ au_{ extit{rr}}$	$-2\mu\frac{\partial v_r}{\partial r} + \mu^B\nabla\cdot\boldsymbol{v}$			
$ au_{yy}$	$-2\mu\frac{\partial v_y}{\partial y} + \mu^B\nabla\cdot\boldsymbol{v}$	$ au_{ heta heta}$	$-2\mu\left(\frac{1}{r}\frac{\partial v_{\theta}}{\partial \theta}+\frac{v_{r}}{r}\right)+\mu^{B}\nabla\cdot\boldsymbol{v}$	$ au_{ heta heta}$	$-2\mu\left(\frac{1}{r}\frac{\partial v_{\theta}}{\partial \theta} + \frac{v_{r}}{r}\right) + \mu^{B}\nabla\cdot\boldsymbol{v}$			
$ au_{zz}$	$-2\mu\frac{\partial v_z}{\partial z} + \mu^B\nabla\cdot\boldsymbol{v}$	$ au_{ZZ}$	$-2\mu\frac{\partial v_z}{\partial z} + \mu^B\nabla\cdot\boldsymbol{v}$	$ au_{\phi\phi}$	$-2\mu\left(\frac{1}{r\sin\theta}\frac{\partial v_{\phi}}{\partial \phi} + \frac{v_{r} + v_{\theta}\cot\theta}{r}\right) + \mu^{B}\nabla\cdot\boldsymbol{v}$			
$ au_{xy}$	$-\mu \left(\frac{\partial v_x}{\partial y} + \frac{\partial v_y}{\partial x} \right)$	$ au_{r heta}$	$-\mu \left(r \frac{\partial}{\partial r} \left(\frac{v_{\theta}}{r} \right) + \frac{1}{r} \frac{\partial v_{r}}{\partial \theta} \right)$	$ au_{r heta}$	$-\mu \left(r \frac{\partial}{\partial r} \left(\frac{v_{\theta}}{r}\right) + \frac{1}{r} \frac{\partial v_{r}}{\partial \theta}\right)$			
$ au_{yz}$	$-\mu \left(\frac{\partial v_y}{\partial z} + \frac{\partial v_z}{\partial y} \right)$	$ au_{ heta z}$	$-\mu \left(\frac{1}{r} \frac{\partial v_z}{\partial \theta} + \frac{\partial v_\theta}{\partial z} \right)$	$ au_{ heta\phi}$	$-\mu \left(\frac{\sin \theta}{r} \frac{\partial}{\partial \theta} \left(\frac{v_{\phi}}{\sin \theta} \right) + \frac{1}{r \sin \theta} \frac{\partial v_{\theta}}{\partial \phi} \right)$			
$ au_{\it XZ}$	$-\mu \left(\frac{\partial v_x}{\partial z} + \frac{\partial v_z}{\partial x} \right)$	$ au_{\mathit{zr}}$	$-\mu \left(\frac{\partial v_r}{\partial z} + \frac{\partial v_z}{\partial r} \right)$	$ au_{\phi r}$	$-\mu \left(\frac{1}{r \sin \theta} \frac{\partial v_r}{\partial \phi} + r \frac{\partial}{\partial r} \left(\frac{v_\phi}{r} \right) \right)$			

Table 1: Fourier's law for the heat flux and Newton's law for the stress in several coordinate systems. Please remember that the stress is symmetric, so $\tau_{ii} = \tau_{ii}$.

Viscous models:

Power-Law Fluid:

$$|\tau_{xy}| = k \left| \frac{\partial V_x}{\partial y} \right|^n \tag{5}$$

Bingham-Plastic Fluid:

$$\frac{\partial \mathbf{v}_{x}}{\partial \mathbf{y}} = \begin{cases} -\mu^{-1} \left(\tau_{xy} - \tau_{0} \right) & \text{if } \tau_{xy} > \tau_{0} \\ 0 & \text{if } \tau_{xy} \leq \tau_{0} \end{cases}$$

Dimensionless Numbers

$$Re = \frac{\rho \langle v \rangle D}{\mu} \qquad Re_H = \frac{\rho \langle v \rangle D_H}{\mu} \qquad Re_{MR} = -\frac{16 L \rho \langle v \rangle^2}{R \Delta \rho} \qquad (6)$$

The hydraulic diameter is defined as $D_H = 4 A/P_w$.

Single phase pressure drop calculations in pipes:


Darcy-Weisbach equation:

$$\frac{\Delta p}{L} = -\frac{C_f \rho \langle v \rangle^2}{R} \tag{7}$$

where $C_f = 16/Re$ for laminar Newtonian flow. For turbulent flow of Newtonian fluids in smooth pipes, we have the Blasius correlation:

$$C_f = 0.079 \, \mathrm{Re}^{-1/4}$$
 for $2.5 \times 10^3 < \mathrm{Re} < 10^5$ and smooth pipes.

Otherwise, you may refer to the Moody diagram.



Laminar Power-Law fluid:

$$\dot{V} = \frac{n\pi R^3}{3n+1} \left(\frac{R}{2k}\right)^{\frac{1}{n}} \left(-\frac{\Delta p}{L}\right)^{\frac{1}{n}}$$

Two-Phase Flow:

Lockhart-Martinelli parameter:

$$X^2 = \frac{\Delta p_{liq.-only}}{\Delta p_{qas-only}}$$

Pressure drop calculation:

$$\Delta p_{two-phase} = \Phi_{liq.}^2 \, \Delta p_{liq.-only} = \Phi_{gas}^2 \, \Delta p_{gas-only}$$

Chisholm's relation:

$$\Phi_{gas}^2=1+c\,X+X^2$$

$$\Phi_{liq.}^2 = 1 + \frac{c}{X} + \frac{1}{X^2}$$

$$c = \begin{cases} 20 & \text{turbulent liquid \& turbulent gas} \\ 12 & \text{laminar liquid \& laminar gas} \\ 10 & \text{turbulent liquid \& laminar gas} \\ 5 & \text{laminar liquid \& laminar gas} \end{cases}$$

Farooqi and Richardson expression for liquid hold-up in co-current flows of Newtonian fluids and air in horizontal pipes:

$$h = \begin{cases} 0.186 + 0.0191 \, X & 1 < X < 5 \\ 0.143 \, X^{0.42} & 5 < X < 50 \\ 1/\left(0.97 + 19/X\right) & 50 < X < 500 \end{cases}$$

Heat Transfer Dimensionless numbers:

Nu =
$$\frac{hL}{k}$$
 Pr = $\frac{\mu C_p}{k}$ Gr = $\frac{g \beta (T_w - T_\infty) L^3}{\nu^2}$

where $\beta = V^{-1}(\partial V/\partial T)$.

Heat transfer: Resistances

$$Q = U_T A_T \Delta T = R_T^{-1} \Delta T$$

	С	onduction Shell Re	Radiation		
	Rect.	Cyl.	Sph.		
R	$\frac{X}{kA}$	$\frac{\ln\left(R_{outer}/R_{inner}\right)}{2\piLk}$	$\frac{R_{inner}^{-1} - R_{outer}^{-1}}{4 \pi k}$	$\left[A\varepsilon\sigma\left(T_{j}^{2}+T_{i}^{2}\right)\left(T_{j}+T_{i}\right)\right]^{-1}$	

Radiation Heat Transfer:

Stefan-Boltzmann constant σ = 5.6703 \times 10⁻⁸ W m⁻² K⁻⁴.

Summation relationship, $\sum_{j} F_{i \to j} = 1$, and reciprocity relationship, $F_{i \to j} A_i = F_{j \to i} A_j$. Radiation shielding factor 1/(N+1).

$$Q_{rad.,i\rightarrow j} = \sigma \, \varepsilon \, F_{i\rightarrow j} \, A_i \, (T_i^4 - T_i^4) = h_{rad.} \, A \, (T_\infty - T_w)$$

Natural Convection

Ra = Gr Pr	C	m
< 10 ⁴	1.36	1/5
10 ⁴ -10 ⁹	0.59	1/4
> 109	0.13	1/3

Table 2: Natural convection coefficients for isothermal vertical plates in the empirical relation $Nu \approx C (Gr Pr)^m$.

For isothermal vertical cylinders, the above expressions for isothermal vertical plates may be used but must be scaled by a factor, F (i.e., $Nu_{v.cyl.} = F Nu_{v.plate}$):

$$F = \begin{cases} 1 & \text{for } (D/H) \ge 35 \,\text{Gr}_H^{-1/4} \\ 1.3 \left\lceil H \, D^{-1} \, \text{Gr}_D^{-1} \right\rceil^{1/4} + 1 & \text{for } (D/H) < 35 \,\text{Gr}_H^{-1/4} \end{cases}$$

where *D* is the diameter and *H* is the height of the cylinder. The subscript on Gr indicates which length is to be used as the critical length to calculate the Grashof number.

Churchill and Chu expression for natural convection from a horizontal pipe:

$$Nu^{1/2} = 0.6 + 0.387 \left\{ \frac{Gr\,Pr}{\left[1 + (0.559/Pr)^{9/16}\right]^{16/9}} \right\}^{1/6} \qquad \text{for } 10^{-5} < Gr\,Pr < 10^{12}$$

Forced Convection:

Laminar flows:

$$Nu \approx 0.332 \, Re^{1/2} \, Pr^{1/3}$$

Well-Developed turbulent flows in smooth pipes:

Nu
$$pprox rac{(C_f/2) {
m Re} \, {
m Pr}}{1.07 + 12.7 (C_f/2)^{1/2} \left({
m Pr}^{2/3} - 1
ight)} \left(rac{\mu_b}{\mu_w}
ight)^{0.14}$$

Boiling:

Forster-Zuber pool-boiling coefficient:

$$h_{nb} = 0.00122 \frac{k_L^{0.79} C_{p,L}^{0.45} \rho_L^{0.49}}{\gamma^{0.5} \mu_L^{0.29} h_{fg}^{0.24} \rho_G^{0.24}} (T_w - T_{sat})^{0.24} (p_w - p_{sat})^{0.75}$$

Mostinski correlations:

$$h_{nb} = 0.104 \, p_c^{0.69} \, q^{0.7} \left[1.8 \left(\frac{p}{p_c} \right)^{0.17} + 4 \left(\frac{p}{p_c} \right)^{1.2} + 10 \left(\frac{p}{p_c} \right)^{10} \right]$$

$$q_c = 3.67 \times 10^4 \, p_c \left(\frac{p}{p_c} \right)^{0.35} \left[1 - \frac{p}{p_c} \right]^{0.9}$$

(**Note**: for the Mostinski correlations, the pressures are in units of bar) **Condensing:**

Horizontal pipes

$$h = 0.72 \left(\frac{k^3 \, \rho^2 \, g_x \, E_{latent}}{D \, \mu \, \left(T_w - T_\infty \right)} \right)^{1/4}$$

Lumped capacitance method:

$$Bi = \frac{h L_c}{\kappa}$$

$$L_c = V/A$$
 for Bi < 0.1
$$\frac{T(t) - T_{\infty}}{T_0 - T_{\infty}} = e^{-bt}$$

$$b = \frac{hA_s}{\varrho VC_0}$$

1-D Transient Heat Conduction:

$$Fo = \frac{\alpha \Delta t}{(\Delta x)^2} = \tau, \quad \alpha = \kappa (\rho C_p)^{-1}$$

$$\theta_{\text{wall}} = \frac{T(x, t) - T_{\infty}}{T_i - T_{\infty}} = A_1 e^{-\lambda_1^2 \tau} \cos\left(\frac{\lambda_1 x}{L}\right), \qquad \theta_{\text{cyl}} = \frac{T(r, t) - T_{\infty}}{T_i - T_{\infty}} = A_1 e^{-\lambda_1^2 \tau} \mathbf{J_0}\left(\frac{\lambda_1 r}{r_0}\right)$$

$$\theta_{\rm sph} = \frac{T(r,t) - T_{\infty}}{T_i - T_{\infty}} = A_1 e^{-\lambda_1^2 \tau} \frac{\sin\left(\frac{\lambda_1 r}{r_0}\right)}{\frac{\lambda_1 r}{r_0}}$$

$$heta_{0, ext{wall}} = heta_{0, ext{cyl}} = heta_{0, ext{sph}} = rac{T_0 - T_\infty}{T_i - T_\infty} = A_1 e^{-\lambda_1^2 au}$$

$$\left(\frac{\mathcal{Q}}{\mathcal{Q}_{\text{max}}}\right)_{\text{wall}} = 1 - \theta_{0,\text{wall}} \frac{\sin \lambda_1}{\lambda_1}, \quad \left(\frac{\mathcal{Q}}{\mathcal{Q}_{\text{max}}}\right)_{\text{cyl}} = 1 - 2\theta_{0,\text{cyl}} \frac{\textbf{J}_1\left(\lambda_1\right)}{\lambda_1}$$

$$\left(\frac{\mathcal{Q}}{\mathcal{Q}_{\text{max}}}\right)_{\text{sph}} = 1 - 3\theta_{0,\text{sph}} \frac{\sin\lambda_1 - \lambda_1\cos\lambda_1}{\lambda_1^3}$$

Finite-Difference Method:

$$\frac{\partial}{\partial t} (\rho \phi) + \frac{\partial}{\partial x} (\rho \mathbf{V} \phi) = \nabla \cdot (\Gamma \nabla \phi) + \mathcal{S}$$
 (1D transport equation)

$$\left(\frac{d\phi}{dx}\right)_{i} = \frac{\phi_{i+1} - \phi_{i-1}}{2\Delta x} \quad \text{and} \quad \left(\frac{d^{2}\phi}{dx^{2}}\right)_{i} = \frac{\phi_{i-1} + \phi_{i+1} - 2\phi_{i}}{(\Delta x)^{2}}$$

$$T_i^{j+1} = (1 - 2\tau) T_i^j + \tau \left(T_{i+1}^j + T_{i-1}^j \right) + \frac{\tau (\Delta x)^2}{\kappa} S_i^j$$

Overall Heat Transfer Coefficient:

$$\dot{\mathcal{Q}} = \frac{\Delta T}{\mathcal{R}} = UA\Delta T = U_i A_i \Delta T = U_o A_o \Delta T$$

$$\mathcal{R} = R_i + R_{\text{wall}} + R_o = \frac{1}{h_i A_i} + \frac{\ln D_o/D_i}{2\pi \kappa L} + \frac{1}{h_o A_o}$$

Fouling Factor:

$$\mathcal{R} = \frac{1}{h_i A_i} + \frac{R_{f,i}}{A_i} + R_{\text{wall}} + \frac{R_{f,o}}{A_o} + \frac{1}{h_o A_o}$$

LMTD Method:

$$\begin{split} \dot{\mathcal{Q}} &= \textit{UA}_s \Delta \textit{T}_{\text{Im}} \;\; \text{with} \;\; \Delta \textit{T}_{\text{Im}} = \frac{\Delta \textit{T}_2 - \Delta \textit{T}_1}{\ln \frac{\Delta \textit{T}_2}{\Delta \textit{T}_1}} = \frac{\Delta \textit{T}_1 - \Delta \textit{T}_2}{\ln \frac{\Delta \textit{T}_1}{\Delta \textit{T}_2}} \\ &\text{Parallel flows:} \begin{cases} \Delta \textit{T}_1 = \textit{T}_{\text{hot,in}} - \textit{T}_{\text{cold,in}} \\ \Delta \textit{T}_2 = \textit{T}_{\text{hot,out}} - \textit{T}_{\text{cold,out}} \end{cases} \\ &\text{Counter flows:} \begin{cases} \Delta \textit{T}_1 = \textit{T}_{\text{hot,in}} - \textit{T}_{\text{cold,out}} \\ \Delta \textit{T}_2 = \textit{T}_{\text{hot,out}} - \textit{T}_{\text{cold,in}} \end{cases} \end{split}$$

ϵ -NTU Method:

$$\epsilon = \frac{\dot{Q}}{\dot{Q}_{\text{max}}}, \quad \text{with } \dot{Q}_{\text{max}} = \mathcal{C}_{\text{min}} \left(T_{\text{hot,in}} - T_{\text{cold,in}} \right) \quad \text{and} \quad \mathcal{C}_{\text{min}} = Min \left\{ \dot{m}_{\text{hot}} C_{\rho, \text{hot}}, \dot{m}_{\text{cold}} C_{\rho, \text{cold}} \right\}$$

$$NTU = \frac{UA_s}{C_{\min}}$$




Figure 2: Hewitt-Taylor flow pattern map for multiphase flows in vertical pipes.




Figure 3: Chhabra and Richardson flow pattern map for horizontal pipes.


TABLE 4-3

The zeroth- and first-order Bessel

TABLE 4-2 Coefficients used in the one-term approximate solution of transient one-dimensional heat conduction in plane walls, cylinders, and spheres (Bi = hL/k


dimensional heat conduction in plane walls, cylinders, and spheres (Bi = hL/k							functions of the first kind			
for a plane radius r_a)	e wall of thi	ckness 2L, a	and Bi = hr_o	/k for a cylii	nder or sphe	re of	η	$J_0(\eta)$	$J_1(\eta)$	
radiao 1 ₀ 7	D/	147-17	0.11				0.0	1.0000	0.0000	
	Plane Wall		Cylinder			Sphere		0.9975	0.0499	
Bi	λ_1	A_1	λ_1	A_1	λ_1	A_1	0.2	0.9900	0.0995	
0.01	0.0998	1.0017	0.1412	1.0025	0.1730	1.0030	0.3	0.9776	0.1483	
0.02	0.1410	1.0033	0.1995	1.0050	0.2445	1.0060	0.4	0.9604	0.1960	
0.04	0.1987	1.0066	0.2814	1.0099	0.3450	1.0120	0.5	0.0205	0.2422	
0.06	0.2425	1.0098	0.3438	1.0148	0.4217	1.0179	0.5 0.6	0.9385	0.2423	
0.08	0.2791	1.0130	0.3960	1.0197	0.4860	1.0239	0.6	0.9120	0.2867 0.3290	
0.1	0.3111	1.0161	0.4417	1.0246	0.5423	1.0298	0.7	0.8812 0.8463	0.3688	
0.2	0.4328	1.0311	0.6170	1.0483	0.7593	1.0592	0.8	0.8075	0.4059	
0.3	0.5218	1.0450	0.7465	1.0712	0.9208	1.0880	0.5	0.6075	0.4059	
0.4	0.5932	1.0580	0.8516	1.0931	1.0528	1.1164	1.0	0.7652	0.4400	
0.5	0.6533	1.0701	0.9408	1.1143	1.1656	1.1441	1.1	0.7196	0.4709	
0.6	0.7051	1.0814	1.0184	1.1345	1.2644	1.1713	1.2	0.6711	0.4983	
0.7	0.7506	1.0918	1.0873	1.1539	1.3525	1.1978	1.3	0.6201	0.5220	
0.8	0.7910	1.1016	1.1490	1.1724	1.4320	1.2236	1.4	0.5669	0.5419	
0.9	0.8274	1.1107	1.2048	1.1902	1.5044	1.2488	2.4	0.0005	0.0415	
1.0	0.8603	1.1191	1.2558	1.2071	1.5708	1.2732	1.5	0.5118	0.5579	
2.0	1.0769	1.1785	1.5995	1.3384	2.0288	1.4793	1.6	0.4554	0.5699	
3.0	1.1925	1.2102	1.7887	1.4191	2.2889	1.6227	1.7	0.3980	0.5778	
4.0	1.2646	1.2287	1.9081	1.4698	2.4556	1.7202	1.8	0.3400	0.5815	
5.0	1.3138	1.2403	1.9898	1.5029	2.5704	1.7870	1.9	0.2818	0.5812	
6.0	1.3496	1.2479	2.0490	1.5253	2.6537	1.8338				
7.0	1.3766	1.2532	2.0937	1.5411	2.7165	1.8673	2.0	0.2239	0.5767	
8.0	1.3978	1.2570	2.1286	1.5526	2.7654	1.8920	2.1	0.1666	0.5683	
9.0	1.4149	1.2598	2.1566	1.5611	2.8044	1.9106	2.2	0.1104	0.5560	
10.0	1.4289	1.2620	2.1795	1.5677	2.8363	1.9249	2.3	0.0555	0.5399	
20.0	1.4961	1.2699	2.2880	1.5919	2.9857	1.9781	2.4	0.0025	0.5202	
30.0	1.5202	1.2717	2.3261	1.5973	3.0372	1.9898				
40.0	1.5325	1.2723	2.3455	1.5993	3.0632	1.9942	2.6	-0.0968	-0.4708	
50.0	1.5400	1.2727	2.3572	1.6002	3.0788	1.9962	2.8	-0.1850	-0.4097	
100.0	1.5552	1.2731	2.3809	1.6015	3.1102	1.9990	3.0	-0.2601	-0.3391	
00	1.5708	1.2732	2.4048	1.6021	3.1416	2.0000	3.2	-0.3202	-0.2613	

Figure 4: Coefficients for the 1D transient equations.




Transient temperature and heat transfer charts for a plane wall of thickness 2L initially at a uniform temperature T_i subjected to convection from both sides to an environment at temperature T_{∞} with a convection coefficient of h.

Figure 5:



Transient temperature and heat transfer charts for a long cylinder of radius r_o initially at a uniform temperature T_i subjected to convection from all sides to an environment at temperature T_∞ with a convection coefficient of h.

Figure 6:



Transient temperature and heat transfer charts for a sphere of radius r_o initially at a uniform temperature T_i subjected to convection from all sides to an environment at temperature T_∞ with a convection coefficient of h.

Figure 7:




Figure 8: Correction-factors for LMTD Method, extracted from Y. A. Cengel, "Heat transfer:A practical approach", 2nd Ed.




Figure 9: Correction-factors for LMTD Method, extracted from Y. A. Cengel, "Heat transfer:A practical approach", 2nd Ed.




Figure 10: NTU relations extracted from Y. A. Cengel, "Heat transfer: A practical approach", 2nd Ed.




Figure 11: NTU plots extracted from Y. A. Cengel, "Heat transfer: A practical approach", 2nd Ed.

Diffusion Dimensionless Numbers

$$Sc = \frac{\mu}{\rho D_{AB}}$$

$$Le = \frac{k}{\rho C_{\rho} D_{AB}}$$

Diffusion

General expression for the flux:

$$\mathbf{N}_A = \mathbf{J}_A + x_A \sum_B \mathbf{N}_B$$

Fick's law:

$$J_A = -D_{AB} \nabla C_A$$

Stefan's law:

$$N_{s,r} = -D \frac{c}{1-x} \frac{\partial x}{\partial r}$$

Ideal Gas

$$PV = nRT$$
 $R \approx 8.314598 \text{ J K}^{-1} \text{ mol}^{-1}$

Geometry

$$P_{
m circle} = 2 \pi r$$
 $A_{
m circle} = \pi r^2$ $A_{
m sphere} = 4 \pi r^2$ $V_{
m sphere} = \frac{4}{3} \pi r^3$ $A_{
m cylinder} = P_{
m circle} L$ $V_{
m cylinder} = A_{
m circle} L$