
Phase Behaviour and Physical Properties



1	Introduction	on	3
2		Gas Components	
	2.1 Para	ıffins	3
	2.2 Aro	matics	3
	2.3 Nap	hthenes	4
	2.4 Sulp	ohur	4
	2.5 Nitr	ogen	5
	2.6 Carl	oon Dioxide	5
		er	
		cury	
3		ir Oil and Gas	
		se Diagrams	
		Single Phase Fluid	
		Multicomponent Fluid	
		Phase Behaviour for differing Reservoir types	
4		mpling	
		l Stem Test	
_		ended Well Testing	
5		odelling	
		ck Oil	
		npositional	
		Pseudo-Component	
	_	ilibrium Ratios	
		Bubble Point Calculation Dew Point Calculation	
		Flash Calculation Procedure	
		ations of State	
	_	Van der Waals	
		Soave-Redlich-Kwong (SRK)	
		Peng-Robinson	
		perty Package Selection	
		BWRS	
		CPA Model – Polar Fluids	
		Activity Models	
		Modelling Summary	
		CO2 Modelling	
		Mollier Chart	
		de Assay	
6		Properties	
	6.1 Crit	ical and Reduced Temperature and Pressure	46
	6.2 Liqu	uid Density	46
	6.3 Gas	Compressibility	50
	6.4 Viso	cosity	53
	6.4.1	Liquid	53
	6.4.2	Gas	54
		cific Heat Capacity	
		rmal Conductivity	56
		face Tension	
		our Pressure	
	•	rnings	
8	Reference	ce books	58

1 Introduction

Accurate predicting of phase behaviour, and thermodynamic and physical properties is a prerequisite of process design and rating calculations. This module sets out a range of common methods used in practice.

2 Oil and Gas Components

Naturally occurring oil and gas reservoirs contain a wide range of hydrocarbon compounds and other species.

2.1 Paraffins

The paraffinic series of hydrocarbon compounds have the general formula C_nH_{2n+2} and can be either straight chains (normal) or branched chains (isomers) of carbon atoms. Paraffinic hydrocarbons are commonly referred to as alkanes.

Methane is the simplest paraffin molecule: Examples of straight chain paraffin molecule (Butane) and branched paraffin molecule (Isobutane) with same chemical formula of:

2.2 Aromatics

Aromatics are unsaturated ring-type (cyclic) compounds. All aromatics have at least one benzene ring (a single-ring compound characterized by three double bonds alternating with three single bonds between six carbon atoms) as part of their molecular structure.

Naphthalenes are fused double-ring aromatic compounds. The most complex aromatics are the polycyclic aromatic hydrocarbons (PAH), also referred to as polynuclear hydrocarbons, with three or more fused aromatic rings and they typically are found in the heavier fractions of petroleum crude oil. PAH are generally toxic to most organisms.

Example of simple aromatic compound: Example of simple double-ring aromatic compound:

Benzene (C₆ H₆)

2.3 Naphthenes

Naphthenes are saturated hydrocarbon compounds having the general formula of C_nH_{2n} , arranged in the form of closed rings. Naphthenes are also commonly referred to as cycloparaffins or cycloalkanes.

Single-ring naphthenes (monocycloparaffins) with five and six carbon atoms predominate, with two-ring naphthenes (dicycloparaffins) found in the heavier ends of the naphtha fraction of petroleum crude oil.

Example of a typical single-ring naphthenic:

Example of naphthene with same chemical formula (C₆ H₁₂) but with a different molecular structure:

Cyclohexane

2.4 Sulphur

Sulphur compounds occur to some extent in most naturally occurring oil and gases. They are unwanted as sulphur compounds are poisons for many catalytic processes used within refinery operations. In the presence of water they are corrosive. When burned/flared the sulphur oxidises to sulphur dioxide – an atmospheric pollutant.

Typical sulphur species are shown below.

Hydrogen Sulfide	H_2S
Mercaptans Aliphatic	R—SH
Aromatic	SH
Sulfides Aliphatic	R—S—R
Cyclic	CH ₂ —(CH ₂) _n
Disulfides Aliphatic	R—S—S—R
Aromatic	S-S-R
Polysulfides	$R \longrightarrow S_n \longrightarrow R$
Thiophene and Homologs	S

2.5 Nitrogen

Nitrogen is present in many oil and gas fields. Note that nitrogen can significantly effect phase behaviour characteristics with consequent impacts on processing requirements.

2.6 Carbon Dioxide

Like Nitrogen, carbon dioxide is a feature of most reservoirs. In combination with water it is corrosive.

2.7 Water


Water is a ubiquitous component of almost oil naturally occurring hydrocarbon reservoirs. Its presence and composition can significantly impact the process plant configuration as will be discussed later.

2.8 Mercury

Mercury is found in many oil and gas fields. It is a concern for metallurgy particularly Aluminium. It is also a health hazard.

3 Reservoir Oil and Gas

Reservoir oil is conditioned to allow for pipeline transportation or as a suitable feedstock for a refinery. The components of the unprocessed fluids and the refined products are shown.






Like oil, gas is conditioned into a form suitable for transportation and sale. It should be noted that there is no typical oil or gas composition. Each field is different due to the geochemical formation processes which produced the hydrocarbons.

3.1 Phase Diagrams

An ability to predict the phase state of the fluids to be processed is an essential step in any process design. Inaccurate prediction will lead to a flawed design of the associated process equipment.


3.1.1 Single Phase Fluid

Consider the phase characteristics of water.



As can be seen the phase transition from all liquid to all vapour occurs at a single point. This is not the case for a multicomponent mixture such as a naturally occurring oil or gas.

3.1.2 Multicomponent Fluid



Here a different behaviour is seen – at a given pressure the transition from liquid to vapour occurs across a temperature range as the heavier molecular weight components change phase from liquid to vapour.

Key aspects of this phase behaviour plot are:

Bubble Point

The point at which the first infinitesimally small vapour bubble appears in a liquid system.

The bubble point curve on a phase diagram represents 0% vapour

Dew Point

The point at which the first infinitesimally small droplet of condensation forms in a gaseous system. The dew point curve on a phase diagram represents 0% liquid

Phase Envelope

The area on a pressure-temperature phase diagram for a mixture enclosed by the bubble and dew point curves. This area represents the set of conditions for the mixture where vapour and liquid phases co-exist in equilibrium.

Cricondenbar

The maximum pressure at which vapour and liquid can co-exist in equilibrium

Cricondentherm

The maximum temperature at which vapour and liquid can co-exist in equilibrium.

Critical Point

At the critical point, liquid and vapour phases of a fluid have identical physical properties.

Quality Lines

Lines through the two-phase region showing a constant percentage of liquid and vapour.

Retrograde

The name given to phase behaviour where the slope of the quality line changes from negative to positive.

3.1.3 Phase Behaviour for differing Reservoir types

Jargon used in the oilfield often categorises reservoirs into four types with a characteristic phase behaviour as follows. There is no clear definition categorising the differing types – black oil, volatile oil, condensate or gas. Typical compositions and phase characteristics are shown.


Black Oil

Component	Mol %
Methane (CH ₄)	48.83
Ethane (C ₂ H ₆)	2.75
Propane (C ₃ H ₈)	1.93
Butanes (C ₄ H ₁₀)	1.6
Pentanes (C ₅ H ₁₂)	1.15
Hexane (C ₆ H ₁₄)	1.59
C7+	42.15
Molecular Weight of C7+	225
GOR (scf/bbl)	625
Oil Gravity (° API)	34.3
Colour	Black

C7+ is a pseudo/hypothetical component representing an average of all species C7 and greater.


GOR – gas oil ratio, volume ratio of gas to liquid oil.

API – liquid density



Volatile Oil


Component	Mol %
Methane (CH ₄)	64.36
Ethane (C ₂ H ₆)	7.52
Propane (C ₃ H ₈)	4.74
Butanes (C ₄ H ₁₀)	4.12
Pentanes (C ₅ H ₁₂)	2.97
Hexane (C ₆ H ₁₄)	1.38
C7+	14.91
Molecular Weight of C7+	181
GOR (scf/bbl)	2000
Oil Gravity (° API)	50.1
Colour	Brown



Note the kick up in the envelope. This is a not a real situation; it is a function of the determined mathematical solution. This is a useful reminder that not everything generated by a computer is correct.


Gas Condensate

Component	Mol %
Methane (CH ₄)	87.07
Ethane (C ₂ H ₆)	4.39
Propane (C ₃ H ₈)	2.29
Butanes (C ₄ H ₁₀)	1.74
Pentanes (C ₅ H ₁₂)	0.83
Hexane (C ₆ H ₁₄)	0.6
C7+	3.8
Molecular Weight of C7+	112
GOR (scf/bbl)	18200
Oil Gravity (° API)	60.8
Colour	Straw



Gas

Component	Mol %
Methane (CH ₄)	95.85
Ethane (C ₂ H ₆)	2.67
Propane (C ₃ H ₈)	0.34
Butanes (C ₄ H ₁₀)	0.52
Pentanes (C ₅ H ₁₂)	0.08
Hexane (C ₆ H ₁₄)	0.12
C7+	0.42
Molecular Weight of C7+	157
GOR (scf/bbl)	105000
Oil Gravity (° API)	125
Colour	White



On inspection of the four phase envelopes the transition, temperature difference from the bubble point to the dew point reduces from black oil to gas. The gas composition is dominated by methane hence the system is behaving more like a single component. In the extreme, if the gas were 100% methane the phase behaviour would be a single line.

4 Fluid Sampling

Representative samples of the reservoir have to be obtained to allow for phase behaviour modelling. This is generally facilitated by a Drill Stem Test.

4.1 Drill Stem Test

This is a procedure to determine the productive capacity, pressure, permeability or extent (or a combination of these) of a hydrocarbon reservoir. A three phase separator is provided on the test vessel which measures the quantity of each phase – generally oil and gas but sometimes water too. Samples are taken of each phase and the composition determined by chromatography at an onshore laboratory. Knowing the rate and composition of each phase a recombined mass balance is used to determine the reservoir fluid composition.

This type of sampling may omit components which could deposit within the test well or react with the iron in the well wall. For that reason downhole samples are taken – a fluid sample is taken at reservoir rockface thus ensuring the fluid has all the compositional species.

A drill stem test may last for a day or two during which time the oil and gas are burned. The longer the test the more informative is the data received. This has to be balanced against cost, as the longer the vessel is on station the greater the expense.

4.2 Extended Well Testing

Contrary to the aforementioned, some oil fields may be subject to an extended test – many months. This can arise where the field geology and reservoir flow characteristics are very complex and a long duration test can provide additional information to offset potential risks and uncertainties. Nowadays extended well tests are less common due to the environmental impact of prolonged flaring/burning.

5 Fluid Modelling

The choice of thermodynamic model is critical when evaluating phase behaviour. Fluid phase behaviour and properties can be predicted using a either a 'Black Oil' model or a 'Compositional' model. Compositional models are now custom and practice in Process Engineering.

5.1 Black Oil

Not to be confused with the previous Black Oil Reservoir - Black Oil models are generally used for simple, multiphase modelling in flowlines and wellbores. They predict phase behaviour and bulk properties for varying conditions by relating the fluid volumetric properties at the surface (e.g. GOR, Oil Gravity and Gas Gravity) to the system conditions. No detailed knowledge of fluid composition is required. Black oil models are clearly not recommended for preparing heat and mass balances.

With the development of equations of state (see later), black oil models are now seldom used for Process Design. They are used for reservoir analysis where detailed compositional data is not required.

Compositional models are used for rigorous heat and mass balance work. They use a property package and a composition specified in terms of individual components which are available in the package database or component library. If required, pseudo-components can be specified for non-library components or for boiling point cuts. Binary interaction parameters for components pairs are used to give improved VLE property predictions.

Modern simulation packages generally have several property packages available for selection including both equations of state and activity models.

5.2 Compositional

Compositional fluid modelling is a method for describing a stream based upon its pure components. An equation of state will be used to predict VLE (vapour liquid equilibria), gas and liquid enthalpies, gas and liquid densities, gas and liquid viscosities, surface tension and thermal properties - thermal conductivity.

It is not practical to model every component of a reservoir fluid due to the large numbers of components that are present. Generally, for acceptable phase behaviour prediction, it is sufficient to specify the mole fractions of the main light end paraffins, typically C1 to C10 for black oils. If dealing with gas condensate systems, however, more rigorous compositional data may be required, particularly if modelling retrograde behaviour. Heavier components are handled as pseudo or hypothetical components.


For the heavier components in a reservoir fluid mix one or more pseudo-components (or hypothetical components) can be used. Pseudo-components are a mixture of many components with different properties but modelled as one component with generalised/average properties.

5.2.1 Pseudo-Component


Pseudo-Components are normally defined either by the critical properties or by average molecular weight, specific gravity and normal boiling point. For most computer simulations a minimum of two of these must be specified. Acentric factors and binary interaction parameters can also be entered; most simulation packages will estimate these if not supplied by the user.


Prediction of heavy end physical properties is important for accurate prediction of phase behaviour; incomplete or inaccurate data can radically affect phase calculations, for example the prediction of bubble and dew points.


Standard fractional distillation tests can be used to produce boiling point curves and physical properties allowing the heavy ends to be split into a number of pseudo components. Some simulation packages have the facility to take in distillation test data directly and to produce the pseudo-components automatically. Some 'tuning' may be required to match the properties of the modelled reservoir fluids to well test data.




Commercial heat and mass balance simulators require an equation of state to be selected then normal and hypothetical component properties are added as shown.









5.3 Equilibrium Ratios

The vapour-liquid equilibrium constant (K) is defined as the mole fraction of any component in the vapour phase divided by the mole fraction of the same component in the liquid phase:

$$K_i = y_i / x_i$$

Use of Equilibrium Ratios is key to the preparation of oil and gas processing heat and mass balances. The application of K values allows for the calculation of dew points, bubble points and the vapour-liquid behaviour inside the phase envelope (flash calculations).

5.3.1 Bubble Point Calculation

The following criteria is met;

$$\Sigma K_i\,x_i=\Sigma y_i=1.0$$

Assume a temperature for the known pressure (or assume pressure if temperature is known)

Find K_i at pressure and temperature known and assumed

Multiply K_i by the corresponding x_i

If summation of values is 1.0, then pressure and temperature is correct, if not repeat until Σ K_i $x_i = 1.0$.

5.3.2 Dew Point Calculation

The following criteria is met;

$$\Sigma (y_i/K_i) = \Sigma x_i = 1.0$$

The steps involved in a dew point calculation are the same as for the bubble point calculation.

A dew point calculation is less exact than a bubble point calculation, especially for lean gases containing a small amount of heavy ends.

5.3.3 Flash Calculation Procedure

By an overall and component mass balance the following is readily developed.

$$\sum x_i = \sum \frac{z_i}{(L + VK_i)} = 1.0$$

$$\sum y_i = \sum \frac{z_i}{(V + \frac{L}{K_i})} = 1.0$$


- For a specific pressure and temperature K_i can be determined
- Flash calculation solution is iterative
- Guess V and calculate L
- Calculate all y_i all x_i
- Test $\sum x_i$ or $\sum y_i = 1.0$ then a solution has been obtained
- If not re-initialse L or V

Using K value charts (available in many text books) the following are worked examples of the three types of calculation.

Bubble Point Estimate

Given the following mixture composition, determine the bubble point at 10 bara.

	Xi	Ki	$K_i x_i$	Ki	K _i x _i
Component	Mole Frac.	70	°C	80	°C
Propane	0.4	2.1	0.84	2.4	0.96
Butane	0.05	0.78	0.039	0.96	0.048
Pentane	0.1	0.32	0.032	0.4	0.04
Hexane	0.17	0.12	0.02	0.165	0.028
Octane	0.28	0.02	0.006	0.027	0.0076
Total	1.0		0.94		1.08




$$\sum K\alpha = 0.94 \Rightarrow \text{toolow}$$

2. Assume T = 80 °C and find K values from charts.

$$\sum K \alpha_i = 1.08 \Rightarrow \text{toohigh}$$

3. Interpolate between 70 and 80 °C to find bubble point = 74 °C



Dew Pont Estimate

Given the same composition, determine the dew point at 10 bara.

	y _i	Ki	y _i /K _i	Ki	y _i /K _i
Component	Mole Frac.	180)°C	190	°C
Propane	0.4	5.9	0.068	6.25	0.064
Butane	0.05	3.2	0.016	3.4	0.015
Pentane	0.1	2.0	0.05	2.2	0.045
Hexane	0.17	1.0	0.17	1.15	0.148
Octane	0.28	0.35	0.8	0.42	0.67
Total	1.0		1.104		0.94


1. Assume T = 180 °C and find K from charts.

$$\sum y_t/K_t = 1.104 \Rightarrow \text{toohigh}$$

2. Assume T = 190 $^{\circ}$ C and find K from charts.

$$\sum y_t/K_t = 0.94 \Rightarrow \mathsf{toolow}$$

3. Interpolate between 180 °C and 190 °C to find the dew point = 186.5 °C



Flash Calculation

Calculate the vapour Liquid split for the same fluid at 100 °C and 10 bara.

$\sum y_i - x_i$							
Component	Zı	K _i	V ₄ = 0.5	V = 0.4	V = 0.3		
Propane	0.4	3.1	0.409	0.457	0.51		
Butane	0.05	1.4	0.016	0.02	0.026		
Pentane	0.1	0.62	-0.046	-0.045	-0.04		
Hexane	0.17	0.3	-0.182	-0.165	-0.15		
Octane	0.28	0.062	-0.494	-0.42	-0.366		
Total	1.0		$\Sigma = -0.298$	$\Sigma = -0.153$	$\Sigma = -0.02$		

1. Assume V=0.5 and L=0.5 (L+V=1) and calculate x_l and y_l as in next slide.


$$\sum y_i - x_i = -0.298 \Rightarrow toohigh$$

2. Assume V=0.4 and L=0.6

$$\sum y_i - x_i = -0.153 \Rightarrow toohigh$$

3. Assume V=0.3 and L=0.7 - convergence achieved.

$$\sum y_t - x_t = -0.02$$




Vapour and Liquid Composition for V=0.3

$$\sum x_i = \sum \frac{z_i}{(L + VK_i)} = 1.0$$
 $\sum y_i = \sum \frac{z_i}{(V + \frac{L}{K_i})} = 1.0$

Component	Zi	\mathbf{K}_{i}	yi - xi	Xi	yi
Propane	0.4	3.1	0.51	0.25	0.76
Butane	0.05	1.4	0.026	0.04	0.0625
Pentane	0.1	0.62	-0.04	0.11	0.069
Hexane	0.17	0.3	-0.15	0.215	0.06
C7+	0.28	0.062	0.366	0.390	0.024
Total	1.0		$\Sigma = -0.02$	$\Sigma = 1.005$	$\Sigma = 0.98$

K values can be found from simulation packages as shown.



K values can also be estimated from the following – *Wilson, A Modified Redlich-Kwong EOS, AICHE National Meeting.* The expression is a curve fit of the K value charts.

$$K_{i} = \frac{P_{ci}}{P} e^{\left[5.37(1+\omega_{i})\left(1-\frac{T_{ci}}{T}\right)\right]}$$

P - absolute pressure

Pci – component i critical pressure in same units as P

T – absolute temperature

T_{ci} – component i critical temperature in same units as T

w_i - Acentric factor component i (discussed later)

5.4 Equations of State

Whilst the K value method is useful and provide insight for the student, more accurate calculations are provided by the use of Equations of State

5.4.1 Van der Waals

An equation of state is a thermodynamic equation describing the state of matter under a given set of physical conditions. In 1873, J. D. van der Waals introduced the first equation of state derived by the assumption of a finite volume occupied by the constituent molecules. His new formula revolutionized the study of equations of state, and was most famously continued via the Redlich–Kwong equation of state and the Soave modification of Redlich-Kwong.

The Van der Waals equation of state may be written:

$$\left(p + \frac{a}{V_m^2}\right)(V_m - b) = RT$$

where V_m is molar volume, and a and b are substance-specific constants.

a and b can be calculated from the critical properties p_c, T_c and V_c as:

Also written as:

$$a = 3p_c V_c^2$$
 $a = \frac{27(R T_c)^2}{64p_c}$ $b = \frac{V_c}{3}$. $b = \frac{R T_c}{8p_c}$.

The van der Waals equation of state was one of the first to perform markedly better than the ideal gas law. In this landmark equation a is the attraction parameter and b the repulsion parameter or the effective molecular volume. While the equation is definitely superior to the ideal gas law and does predict the formation of a liquid phase, the agreement with experimental data is limited for conditions where liquid forms. While the van der Waals equation is commonly referenced in text books and papers for historical reasons, it is now obsolete. Other modern equations of only slightly greater complexity are much more accurate. One such equation is SRK.

5.4.2 Soave-Redlich-Kwong (SRK)

SRK is robust and well proven equation of state, ideal for use in oil & gas and refinery applications. It is suitable for cryogenic conditions and pressures up to 300 bara. Binary interaction parameters (BIP, symbol k_{ij}) for component pairs are used to improve accuracy with correlations used to generate binary interaction parameters for pseudo-components. BIPs are obtained from experimental data which is regressed for EOS use in simulators.

In common with many EOS, SRK is not considered suitable where accuracy is required for systems with polar compounds.

Liquid compressibility predictions are sufficiently accurate for fugacity calculations but not for accurate liquid densities (can be 10 - 20% low).

SRK can predict phase behaviour in the critical region although calculations are somewhat unstable. Furthermore SRK is not considered to be particularly accurate for heavy end VLE prediction and vacuum systems.

Redlich, O. and Kwong, J. N. S. (1949). On the Thermodynamics of Solutions. V: An Equation of State. Fugacities of Gaseous Solutions. Chem. Rev., 44, 233-244.

Soave, G. (1972). Equilibrium Constants from a Modified Redlich-Kwong Equation of State. Chem. Eng. Sci., 27, 1197-1203.

5.4.2.1 Fugacity

Fugacity is key to the understanding of the solution of an equation state and the principles of equilibrium. To recap earlier thermodynamic lectures, fugacity is a conceptual term which is related to Gibb's free energy, temperature, volume and pressure. The units of fugacity are the same as pressure. Although fugacity has the same units as pressure it will only be equal to pressure under ideal conditions.

For a system of phases to be in equilibrium there must be no mechanical, thermal or chemical driving force. At constant temperature and pressure the chemical potential of every species must be equal. Thus there is no driving force to for species to move from one phase to another. Fugacity is directly related chemical potential hence at equilibrium species fugacity will be equal.

The fugacity coefficient for a pure component is defined as:

$$F_i = \frac{f_i}{P}$$

For a component in a gas and liquid mixture, the fugacity coefficient is:

$$F_i = \frac{f_i}{y_i P}$$

$$\mathsf{F}_i = \frac{f_i}{x_i P}$$

Where y_i and x_i is the mole fraction of component y in the vapour and liquid phase.

Classical thermodynamics shows;

$$\ln F_i = \int_0^p \left[\frac{z_i - 1}{P} \right] dP$$

Each equation of state provides a related solution to the above integral as will be shown in the following information on SRK.

Properties and parameters used;

a Attraction parameter

b Residual volume parameter

W SRK Parameter (numerical co-efficient)

A Derived parameter

B Derived parameter

z = PV/RT, compressibility factor

*f*_i Partial fugacity of species i

k_{ij} Binary Interaction Parameter

 $F = f_i/P$, Fugacity Coefficient

W Acentric Factor

ρ Molar Density

Subscripts

c Value of any variable at the critical point

r Reduced Value

pc Pseudo-critical value

Superscripts

0 property of a standard state

SRK Standard Form

$$P = \frac{RT}{(V-b)} - \frac{a\alpha}{V(V+b)}$$

The variables 'a' and 'b' are derived from the Van-der-Waals equation, which was based on a model where molecules were represented by hard spheres which behaved in a classical and predictable fashion

The parameter 'b' represents the hard-sphere volume of the molecules

The parameter 'a' represents the intermolecular attraction

Polynomial Compressibility Form – (the cubic equation)

$$z^3 - z^2 + (A - B - B^2)z - AB = 0$$

Parameters

$$A = (a\alpha P)/(R^2T^2) = 0.42748\alpha P_r/T_r^2$$

$$B = (b P)/(RT) = 0.08664 P_r/T_r$$

$$a = W_a R^2 T_c^2 / P_c = 0.42748 R^2 T_c^2 / P_c$$

$$b = W_b R T_c / P_c = 0.08664 R T_c / P_c$$

$$\sqrt{\alpha} = 1 + m(1 - Tr^{0.5})$$
 where

$$m = 0.48 + 1.574\omega - 0.172\omega^2$$

Fugacity Coefficient

$$\ln F = z - 1 - \ln (z - B) - A/B \ln (1 + B/z)$$

Mixtures

$$a\alpha = \sum \sum y_i y_j (aa)_{ij}$$

$$b = \sum y_i b_i$$


$$A = \Sigma \; \Sigma \; y_i y_j A_{ij}$$

$$B=\Sigma\ y_iB_i$$

$$(a\alpha)_{ij} = (1 - k_{ij})[(a\alpha_i)(a\alpha)_i]^{0.5}$$

Gas root

Liquid root



The system in equilibrium if the phase fugacities at roots are equal.

5.4.3 Peng-Robinson

Peng-Robinson is robust and well proven, generally ideal for use in oil & gas and refinery applications. It is similar to SRK in performance however it is generally accurate over a wider range of conditions. Specifically;

- It is more accurate around the critical point.
- Liquid phase density prediction is more accurate.

Adapted PR packages can be used for heavy end VLE prediction, vacuum distillation and glycol dehydration.

Peng, D. Y. and Robinson, D. B., (1976). A New Two-Constant Equation of State. Ind. Eng. Chem. Fundam., 15, 59-64.

PR Standard Form

$$P = \frac{RT}{(V-b)} - \frac{a\alpha}{(V^2 + 2bV - b^2)}$$

Polynomial Compressibility Form

$$z^3$$
 - $(1-B)z^2$ + $(A-3B^2-2B)z$ - $(AB-B^2-B^3)=0$

Parameters

$$a = 0.45724 [(R^{2}T_{c}^{2})/P_{c}]$$

$$b = 0.07780 RT_{c}/P_{c}$$

$$\alpha = [1 + (0.37464 + 1.54226\omega - 0.26992 \omega^{2}) (1-Tr^{0.5})]^{2}$$

$$A = (a\alpha P)/(R^2T^2) = 0.45724\alpha P_r/T_r^2$$

$$B = (bP)/(RT) = 0.0778P_r/T_r$$

Fugacity Coefficient

$$ln \; \varphi = z \; \text{-} \; 1 \; \text{-} \; ln \; (z \; \text{-} \; B) \; \text{-} \; [A/2(2B)^{0.5}] \; ln \; [(z + 2.414B)/(z - 0.414B)]$$

Mixtures

$$\begin{split} &a\alpha = \Sigma \ \Sigma \ y_i y_j \ (a\alpha)_{ij} \\ &b = \Sigma \ y_i b_i \\ &(a\alpha)_{ij} = (1 - k_{ij}) \ [(a\alpha \)_i (a\alpha \)_j]^{0.5} \\ &A = \Sigma \ \Sigma \ y_i y_j A_{ij} \\ &B = \Sigma \ y_i B_i \\ &A_{ij} = (1 - k_{ij}) (A_i A_j)^{0.5} \end{split}$$


Acentric Factor

The acentric factor (ω) describes the change in the intermolecular attraction component, **a** with temperature.

The table shows typical acentric factors, the value increases with the size of the molecule and polarity.

Compound	Acentric Factor
Nitrogen	0.039
Carbon Dioxide	0.224
Methane	0.011
Ethane	0.099
Butane	0.119
Hexane	0.299
Octane	0.398
Decane	0.489

Acentric factors can also be found in simulation packages.



SRK worked example

Calculation of the saturation pressure (boiling point) of n-Pentane at 100 °C using SRK.

The experimentally determined vapour pressure is 5.86 atm

Critical properties of n-Pentane are:

$$T_c = 469.7 \text{ K}, P_c = 33.25 \text{ bar}, w = 0.251$$

Using S-R-K:

$$\sqrt{\alpha} = 1 + m(1 - \sqrt{Tr})$$
 where $m = 0.48 + 1.574\omega - 0.172\omega^2$

$$\sqrt{\alpha} = 1 + (0.48 + (1.574 \times 0.251) - (0.172 \times 0.251^2)) \left(1 - \sqrt{\frac{373}{469.6}}\right) = 1.094$$

Calculate A & B

$$A = 0.42747\alpha (P/P_c)(Tc/T)^2 = 0.0224P$$

$$B = 0.08664(P/P_c)(T_c/T) = 0.0033P$$

Substitute values of A & B into the polynomial compressibility equation:

$$Z^3 - Z^2 + (A - B - B^2)Z - AB = 0$$

Solve to find Z for liquid and vapour phases

Calculate the fugacity of the vapour and liquid phases:

$$\ln f = z - 1 - \ln (z - B) - A/B \ln (1 + B/z)$$

$$f_V = f_V/P_V$$
 and $f_L = f_L/P_V$

At equilibrium, $f_V = f_L$ therefore $f_{V} = f_L$

	Z				
Р	Vapour	Liquid	Vapour	Liquid	Ratio
4	0.8943	0.0184	3.665	5.196	
5	0.8647	0.0229	4.4774	5.2287	0.8563
6	0.831	0.0275	5.2482	5.2512	0.9994
7	0.7955	0.0321	5.9775	5.2807	1.132

At equilibrium, the fugacity of the liquid and vapour phases is equal.


Trial and error is conducted from 4 to 7 atm. By interpolation of the above table, the predicted saturation pressure is 6.01 atm

5.5 Property Package Selection

Selection of the property package must take into account the components and the operating conditions. For most purposes, Peng Robinson (PR), Soave-Redlich-Kwong (SRK), or a modified version of these methods, will provide sufficiently accurate modelling for oil and gas equipment applications.

The PR and SRK equations of state give accurate modelling for systems containing up to 5% N₂, CO₂ or H₂S. For systems with greater than 5% N₂, CO₂ or H₂S these equations of state are still recommended if the system does not include free water. It may be advisable, however, to utilise user defined binary interaction parameters if available. This will depend upon the simulation/flash package being used and the quality of the data in its components library. It is recommended to consult the user guide for the particular simulation package being used. Polar compounds can be problematic for EOS methods - methanol, glycol and water - empirical correction factors are often required to improve accuracy. Most simulation packages offer specialised property packages to handle such systems. These utilise a combination of an EOS to predict vapour phase fugacity coefficients and an activity coefficient model for the liquid phase.

The following is the modelling output for a simple system where the gas rate to compressors is a key issue. Two EOS are used – Peng-Robinson and Zudevitch Joffe. As can be seen similar gas from the higher pressure separator are predicted by both EOS. However for the lower pressure separator a difference of around 30% is shown. This difference could be very significant when considering the design of the low pressure compressor. The question is what is correct? That is a key skill for the engineer – the selection of the most accurate EOS for the particular application.



5.5.1 BWRS


This is the Benedict-Webb-Rubin equation of state modified by Professor Kenneth E. Starling of the University of Oklahoma:

$$P = \rho RT + \left(B_0 RT - A_0 - \frac{C_0}{T^2} + \frac{D_0}{T^3} - \frac{E_0}{T^4}\right) \rho^2 + \left(bRT - a - \frac{d}{T}\right) \rho^3 + \alpha \left(a + \frac{d}{T}\right) \rho^6 + \frac{c\rho^3}{T^2} \left(\beta + \gamma \rho^2\right) \exp\left(-\gamma \rho^2\right)$$

 ρ = the molar density.

Values of the various parameters for 15 substances can be found in K.E. Starling, Fluid Properties for Light Petroleum Systems. Gulf Publishing Company (1973).

The BWRS is favoured by some gas pipeline designers. The following phase envelope shows BWRS, PR and SRK results with measured values of cricondentherm and cricondenbar for a specific gas. As can be seen PR and SRK are very accurate whereas BWRS is significantly different. If BWRS were assumed to be accurate for this application significantly more process plant would be required to achieve the pipeline cricondenbar. Once again reinforcing the requirement for appropriate package selection.



5.5.1.1 Limitations of Phase Behaviour Prediction

All phase behaviour methods assume an equilibrium is reached. Phase behaviour prediction deals with mass transfer effects and therefore does not take into account bulk fluid flow. In practice there is almost inevitably some bulk transfer of fluids between the phases: emulsions may be formed due to high fluid shear rates which disperses water in the oil phase, water will carry over into the oil phase. Also liquid droplets may be entrained into the gas phase. EOS do not accurately predict phase behaviour at the critical point.

5.5.2 CPA Model – Polar Fluids

The cubic equation of state is the most widely used thermodynamic models for phase equilibrium calculation and physical property estimation in the petroleum industry. As stated earlier, Peng-Robinson was developed originally for hydrocarbon mixtures and can have limitations when there are associating molecules present e.g. water, methanol, glycol. The Cubic Plus Association model is gaining interest as a useful EOS for handling associating molecules. It is a modified SRK model introducing an association term.

SRK

$$p = \frac{NRT}{V - b} + \frac{a}{V(V + b)}$$

CPA

$$p = \frac{NRT}{V - b} + \frac{a}{V(V + b)} + \frac{\sum_{i} n_{i} F_{i} (1 - X_{i})}{V - 0.45b}$$

Kontogeorgis GM, Voutsas EC, Yakoumis IV, Tassios DP. An equation of state for associating fluids. Ind Eng Chem Res. 1996

Within simulators the available property packages are generally grouped under the types detailed;

Property Package Type	Typical Application
Equations of State,	Ideal hydrocarbon systems
Activity Models,	Polar or non-ideal systems
Chao Seader Models	Systems containing mainly liquid or vapour H2O or high H2 contents
Vapour Pressure Models	Heavy hydrocarbon systems at low pressures (increasing light hydrocarbons
	results in decreasing accuracy)
Miscellaneous Type	Acid gas systems, steam systems, non-volatile oils, aqueous electrolyte
	systems

Non-ideal components include alcohols, acids, glycols and other non-ideal or polar chemicals. The more non-ideal components present, the less ideal the mixture.

5.5.3 Activity Models

As previously stated, although equation of state models have proven to be very reliable in predicting properties of most hydrocarbon based fluids over a large range of operating conditions, their application has been limited to primarily non-polar or slightly polar components.

Polar or non-ideal chemical systems have traditionally been handled using dual model approaches. In this approach, an equation of state is used for predicting the vapour fugacity coefficients and an activity coefficient model is used for the liquid phase. Although there is considerable research being conducted to extend equation of state applications into the chemical arena (e.g., the PRSV equation), the state of the art of property predictions for chemical systems is still governed mainly by activity models.

Activity Models are much more empirical in nature when compared to an EOS for property predictions. For example, they cannot be used as reliably as the equations of state for generalised application or extrapolating into untested operating conditions. Their tuning parameters should be fitted against a representative sample of experimental data and their application should be limited to moderate pressures. Consequently, more caution should be exercised when selecting these models for simulation.

The phase separation or equilibrium ratio K_i for component i, defined in terms of the vapour phase fugacity coefficient and the liquid phase activity coefficient, is calculated from the following expression:

$$K_{i} = \frac{y_{i}}{x_{i}}$$
$$= \frac{\gamma_{i} f_{i}^{\circ}}{P \phi_{i}}$$

where: γ_i = liquid phase activity coefficient of component i

 f_i° = standard state fugacity of component i

P = system pressure

 ϕ_i = vapour phase fugacity coefficient of component i

5.5.3.1 NRTL

The NRTL (Non-Random-Two-Liquid) equation was proposed by Renon and Prausnitz in 1968, is an extension of the original Wilson equation. It uses statistical mechanics and the liquid cell theory to represent the liquid structure.

The NRTL equation in contains five adjustable parameters (temperature dependent and independent) for fitting per binary pair.

The NRTL equation has the form shown.

$$\ln \gamma_{i} = \frac{\sum_{j=1}^{n} \tau_{ji} x_{j} G_{ji}}{\sum_{k=1}^{n} x_{k} G_{ki}} + \sum_{j=1}^{n} \frac{x_{j} G_{ij}}{\sum_{k=1}^{n} x_{k} G_{kj}} \left(\tau_{ij} - \frac{\sum_{m=1}^{n} \tau_{mj} x_{m} G_{mj}}{\sum_{k=1}^{n} x_{k} G_{kj}} \right)$$

where: \(\gamma_i = activity coefficient of component i

$$G_{ij} = \exp[-\tau_{ij}\alpha_{ij}]$$

$$\tau_{ij} = \frac{a_{ij} + b_{ij}T}{RT}$$

 $x_i = mole$ fraction of component i

T = temperature(K)

n = total number of components

a_{ij} = non-temperature dependent energy parameter between components i and j (cal/gmol)

bij = temperature dependent energy parameter between components i and j (cal/gmol-K)

 α_{ij} = NRTL non-randomness constant for binary interaction note that $\alpha_{ij} = \alpha_{ji}$ for all binaries

The five adjustable parameters for the NRTL equation are the a_{ij} , a_{ji} , b_{ij} , b_{ji} , and α_{ij} terms. The equation uses parameter values stored in the simulator or user supplied value for further fitting the equation to a given set of data.

The best results are produced when an activity model is applied in the operating region for which the parameters apply.

The table below	shows when t	ne different Activity	Models can be used
-----------------	--------------	-----------------------	--------------------

Application	Margules	van Laar	Wilson	NRTL	UNIQUAC
Binary Systems	Α	Α	Α	Α	А
Multicomponent Systems	LA	LA	Α	Α	Α
Azeotropic Systems	Α	Α	Α	Α	Α
Liquid-Liquid Equilibria	Α	А	N/A	Α	Α
Dilute Systems	?	?	Α	Α	Α
Self-Associating Systems	?	?	Α	Α	Α
Polymers	N/A	N/A	N/A	N/A	Α
Extrapolation	?	?	G	G	G

A = Applicable; N/A = Not Applicable;? = Questionable; G = Good; LA = Limited Application

5.5.4 Modelling Summary

The table below summarises recommended property packages for various systems commonly encountered in oil and gas/ petrochemical simulations.

Type of System	Recommended Property Methods
TEG Dehydration	PR
Sour Water	Sour PR
Cryogenic Gas Processing	PR, PRSV, TST
Air Separation	PR, PRSV, TST
Atm Crude Towers	PR, PR Options, GS, TST
Vacuum Towers	PR, PR Options, GS (<10 mm Hg), Braun K10, Esso K, TST
Ethylene Towers	Lee Kesler Plocker
High H2 Systems	PR, ZJ, GS, TST
Reservoir Systems	PR, PR Options, TST
Steam Systems	Steam Package, CS or GS
Hydrate Inhibition	PR
Chemical systems	Activity Models, PRSV
HF Alkylation	PRSV, NRTL*
TEG Dehydration with Aromatics	PR*
Hydrocarbon systems where H2O solubility in HC is important	Kabadi Danner
Systems with select gases and light hydrocarbons	MBWR

Validation of simulation against real data should be carried out where appropriate to check that the most appropriate property package has been selected.

In summary for oil, gas and petrochemical applications, the Peng-Robinson EOS is generally the recommended property package. Enhancements to this equation of state enable it to be accurate for a variety of systems over a wide range of conditions. It rigorously solves most

single, two-phase or three-phase system with a high degree of efficiency and reliability, and is applicable over a wide range of conditions.

The PR equation of state is enhanced to yield accurate phase equilibrium calculations for systems ranging from low temperature cryogenic systems to high temperature, high pressure reservoir systems. The same equation of state predicts component distributions for heavy oil, aqueous glycol, and CH₃OH systems.

PR equation of state recommendation is largely due to the preferential attention that is given to it by modelling packages. Although the Soave-Redlich-Kwong (SRK) equation also provides comparable results to the PR in many cases, it is known that its range of application is significantly limited and it is not as reliable for non-ideal systems. For example, it should not be used for systems with CH₃OH or glycols.

As an alternate, the CPA or PRSV equation of state should also be considered. It can handle the same systems as the PR equation with equivalent, or better accuracy, plus it is more suitable for handling moderately non-ideal systems.

Activity Models, which handle highly non-ideal systems, are much more empirical in nature when compared to the property predictions in the hydrocarbon industry. Polar or non-ideal chemical systems are traditionally handled using dual model approaches. In this type of approach, an equation of state is used for predicting the vapor fugacity coefficients and an activity coefficient model is used for the liquid phase. Since the experimental data for activity model parameters are fitted for a specific range, these property methods cannot be used as reliably for generalized application.

The CS and GS methods, though limited in scope, may be preferred in some instances. For example, they are recommended for problems containing mainly steam/water systems because they include special correlations that accurately represent the steam tables. The Grayson-Streed correlation is recommended for use with systems having a high concentration of H₂ because of the special treatment given to H₂ in the development of the model. This correlation may also be slightly more accurate in the simulation of vacuum towers.

The vapor Pressure K models, Antoine, BraunK10 and EssoK models, are designed to handle heavier hydrocarbon systems at lower pressures. These equations are traditionally applied for heavier hydrocarbon fractionation systems and consequently provide a good means of comparison against rigorous models. They should not be considered for VLE predictions for systems operating at high pressures or systems with significant quantities of light hydrocarbons.

Typical simulator default combinations are as indicated;

Property Method	VLE Calculation	Enthalpy/Entropy Calculation
Equations of State	•	•
PR	PR	PR
PR LK ENTH	PR	Lee-Kesler
SRK	SRK	SRK
SRK LK ENTH	SRK	Lee-Kesler
Kabadi Danner	Kabadi Danner	SRK
Lee Kesler Plocker	Lee Kesler Plocker	Lee Kesler
PRSV	PRSV	PRSV
PRSV LK	PRSV	Lee-Kesler
Sour PR	PR & API-Sour	PR
SOUR SRK	SRK & API-Sour	SRK
Zudkevitch-Joffee	Zudkevitch-Joffee	Lee-Kesler

	•	
Activity Models		
Liquid		
Chien Null	Chien Null	Cavett
Extended and General NRTL	NRTL	Cavett
Margules	Margules	Cavett
NRTL	NRTL	Cavett
UNIQUAC	UNIQUAC	Cavett
van Laar	van Laar	Cavett
Wilson	Wilson	Cavett
vapor		
Ideal Gas	Ideal	Ideal Gas
RK	RK	RK
Virial	Virial	Virial
Peng Robinson	Peng Robinson	Peng Robinson
SRK	SRK	SRK


Semi-Empirical Models						
Chao-Seader	CS-RK	Lee-Kesler				
Grayson-Streed	GS-RK	Lee-Kesler				
vapor Pressure Mode	ls					
Mod Antoine	Mod Antoine-Ideal Gas	Lee-Kesler				
Braun K10	Braun K10-Ideal Gas	Lee-Kesler				
Esso K	Esso-Ideal Gas	Lee-Kesler				
Miscellaneous - Special Application Methods						
Amines	Mod Kent Eisenberg (L), PR (V)	Curve Fit				
Steam Packages						
ASME Steam	ASME Steam Tables	ASME Steam Tables				
NBS Steam	NBS/NRC Steam Tables	NBS/NRC Steam Tables				
MBWR	Modified BWR	Modified BWR				


5.5.5 CO2 Modelling

 $\label{eq:carbon} Interest\ in\ Carbon\ Capture\ and\ Storage\ has\ focussed$ attention on accurate CO2 modelling. The EOS of Span and Wagner is recommended.


5.6 The Mollier Chart

The Mollier Chart is a convenient representation of the phase behaviour and thermodynamics of a fluid. The charts are very useful for preliminary calculations. Key features are shown.





The Mollier chart can be used for as a first approximation gas expansion across a valve follows an isenthalpic path. Gas expansion can result in downstream temperatures considerably below the ambient temperature. Low temperatures can result in ice and hydrate formation furthermore; materials have to be designed to handle low temperatures where appropriate. A typical application is the opening of a closed well. Here the formed gas cap expands isenthalpically.



5.7 Crude Assay

An Assay is a detailed fluid analysis of crude oil, sampled under strictly controlled conditions

Assay reports include the quantities and properties of distillates used for crude valuation purposes, the quantity of waxes, heavy metals, salt and sulphur and physical properties of the fluid such as viscosity

Assay samples are taken periodically for the purposes of crude valuation purposes and annually for crudes being exported via a pipeline shared with other fields

SPR CRUDE OIL COMPREHENSIVE ANALYSIS

Sample ID BAYOU CHOCTAW SWEET Date of Assay 18/09	9/2000
---	--------

Crude					
Specific Gravity, 60/60° F	0.8447	Ni, ppm	3.50	RVP, psi @ 100° F	4.62
API Gravity	36.0	V, ppm	5.49	Acid number, mg KOH/g	0.084
Sulfur, Wt. %	0.36	Fe, ppm	0.844	Mercaptan Sulfur, ppm	7.021
Nitrogen, Wt. %	0.114			H ₂ S Sulfur, ppm	0
Micro Car. Res., Wt. %	2.22	Org. Cl, ppm	0.3	Viscosity: 77° F 6.874 cSt	
Pour Point, °F	31	UOP "K"	11.94	100° F 4.623 cSt	

Fraction	Gas	1	2	3	4	5	6	Residuum	Residuum
	C ₂ -	C5 -	175° -	250° -	375° -	530° -	650° -		
Cut Temp.	C_4	175° F	250° F	375° F	530° F	650° F	1050° F	650° F+	1050° F+
Vol. %	1.7	7.3	8.1	14.2	16.3	10.0	31.8	42.4	10.7
Vol. Sum %	1.7	9.0	17.1	31.3	47.6	57.6	89.3	100.0	100.0
Wt. %	1.2	5.8	7.1	13.1	15.9	10.1	34.3	47.0	12.7
Wt. Sum %	1.2	7.0	14.1	27.1	43.0	53.1	87.4	100.0	100.0
Specific Gravity, 6	0/60° F	0.6730	0.7396	0.7763	0.8240	0.8526	0.9116	0.9349	1.004
API Gravity		78.8	59.8	50.8	40.2	34.5	23.7	19.9	9.4
Sulfur, Wt. %		0.0043	0.0040	0.0123	0.07	0.21	0.57	0.69	1.04
Molecular Weight		97	111	136	184	246	425		
Hydrogen, Wt. %		15.89	14.65	na				12.99	10.61
Mercaptan Sulfur,	ppm	14.6	10.1	22.5	17.4				
H ₂ S Sulfur, ppm		0.03	0.8	0.7	0.02				
Organic CI, ppm		2.1	0.5	0.5	0.6				
Research Octane	Number*	68.4	61.1	42.3					
Motor Octane Nun	nber*	66.5	58.6	40.0					
Flash Point, ° F				77	171	246	303		
Aniline Point, ° F				122.4	144.1	164.3	193.3		
Acid Number, mg	KOH/g				0.03	0.10			
Cetane Index					47.1	53.2			
Diesel Index				62.2	58.0	56.6			
Naphthalenes, Vo	l. %				4.42	8.20			
Smoke point, mm					20.3	16.8			
Nitrogen, Wt. %					0.0015	0.006	0.108	0.240	0.603
Viscosity, cSt	77° F				2.473				
1	00° F				1.951	4.795			
1	30° F					3.312	37.03	95.3	
1	80° F						14.22	28.28	5671
2	210° F								1722
2	?75° F								249.3
Freezing Point, °F					-28.54				
Cloud Point, °F						24.0	106		
Pour Point, °F						19.9	102	75	
Ni, ppm								7.539	26.2
V, ppm								11.81	41.0
Fe, ppm								3.856	13.87
Micro Car. Res., V	Vt. %							5.07	18.17

^{* =} calculated from gas chromatographic data

6 Physical Properties

Accurate physical properties are required for system and equipment design. They underpin Chemical Engineering calculations and errors here will result in a flawed design or perhaps an unsafe design. The student should not blindly assume that the physical property output from a simulation is accurate and verification should be undertaken.

A typical heat exchanger data sheet follows, as can be seen key physical properties are essential for the design to proceed.

APPLICABLE TO: T PROPOSAL		GE	NERAL INFORM	ATION		
2 Item No. HBG-3540					III T	
Service: HP Compressor Discharge Cooler Serial Number 32016-1			PURCHASE	μ АЗ ВС	/ILI	
Service: HP Compressor Discharge Cooler Serial Number 32016-1						
Size: S0.4877 Type: NEN						
Surface/Unit: S0.4 (m²) Surface/Shell (Eff): S0.4 (m²) µ Parallel	4	Service: HP Compressor Discharge Coole	r Se			
Nanufacturer Allards International Ltd Connected In:	5		Type:		Shells/Unit:	One (1)
Manufacturer Allards International Ltd Connected In: \(\lambda \) Series \(\mu \) Parallel	8	Surface/Unit: 90.4 (m²) Surf	ace/Shell (Eff):	90.4	(m²)	
PERFORMANCE OF ONE UNIT Tube Side Fluid Circulated Fluid Circu	7				44	arallel
Fluid Circulated	H				μ	
Fluid Circulated Cooling Medium (35% TEG & Water) Hydrocarbon G					7.4	6:1-
10 Fluid Quantity, Total (kg/hr) 87,273 44710 11 12 Vapor (kg/hr)	1 - 1					
12	1 ~ 1					
Vapor		riulo duantity, rotal (kg/r				Out
Liquid (Rghr) 87,273 87,273		Vapor (ko/h		- Out		44/10
14 Steam				87 273	-	-
Water (kg/hr)		Steam (kg/h	r) —	-	_	_
1	15			_	_	_
18 Density, (LV)	16			_	_	_
Niscosity (L/V)			-/-			54
Molecular Weight, (I/V)						— 247
Molecular Weight, Non-condensable (k,l/kg,*C) 3.78 3.81 - 3.13			/			- 0.03
22 Specific Heat (LV)			26 —	26 —	— 21.7	— 21.7
Thermal Conductivity (L/V)				_	_	_
Latent Heat			r			- 3.31
26 Velocity (m/sec) 0.414 1.009 27 Pressure Drop (AllowCalc.) (bar) 1 0.3 1 28 Fouling Resistance (m/sec) 0.414 1.009 29 Heat Load: 2300 (kW) 0.00035 0.00018 29 Heat Transfer Rate Service: 573.2 (W/m²-°C) Clean: 920.5 (W/m²-°C) 30 Heat Transfer Rate Service: 573.2 (W/m²-°C) Clean: 920.5 (W/m²-°C) 31 Transfer Rate Service: 573.2 (W/m²-°C) Clean: 920.5 (W/m²-°C) 32 Pressure Design/lest (bar(g)) 12 17.16 270 33 Maximum Allowable Working Pressure (bar(g)) 12 17.16 270 34 Temperature Design/Minimum (°C) 175 -6 175 35 No. of Passes 1 1 1.000 36 No. of Passes 1 1 1.000 37 Nozzles: Hange Type & Hating Note (9) 6" 6" 6" 38 Nozzles: Hange Type & Hating Note (9) 6" 6" 6" 39 Tubes: No. 389 OD: 16.2 (mm) BWG: 12 min. Length: 4877 (mm) Pitch: 22.23 40 Tube Material: SA-789 UNS 31803, Note (1) Tube Type: µ Removable Floating Head Cover: 41 Shelt: SA-516-70 IU: 508 CU: Impinge. Protection Mart: CS Baffle Material: SA-350-LF2 Impinge. Protecti	23	Thermal Conductivity (LV) (Wm-°C	C) 0.43 —	0.44 —	- 0.07	- 0.08
26 Velocity (m/sec) 0.414 1.009 27 Pressure Drop (AllowCalc.) (bar) 1 0.3 1 28 Fouling Resistance (m/sec) 0.414 1.009 29 Heat Load: 2300 (kW) 0.00035 0.00018 29 Heat Transfer Rate Service: 573.2 (W/m²-°C) Clean: 920.5 (W/m²-°C) 30 Heat Transfer Rate Service: 573.2 (W/m²-°C) Clean: 920.5 (W/m²-°C) 31 Transfer Rate Service: 573.2 (W/m²-°C) Clean: 920.5 (W/m²-°C) 32 Pressure Design/lest (bar(g)) 12 17.16 270 33 Maximum Allowable Working Pressure (bar(g)) 12 17.16 270 34 Temperature Design/Minimum (°C) 175 -6 175 35 No. of Passes 1 1 1.000 36 No. of Passes 1 1 1.000 37 Nozzles: Hange Type & Hating Note (9) 6" 6" 6" 38 Nozzles: Hange Type & Hating Note (9) 6" 6" 6" 39 Tubes: No. 389 OD: 16.2 (mm) BWG: 12 min. Length: 4877 (mm) Pitch: 22.23 40 Tube Material: SA-789 UNS 31803, Note (1) Tube Type: µ Removable Floating Head Cover: 41 Shelt: SA-516-70 IU: 508 CU: Impinge. Protection Mart: CS Baffle Material: SA-350-LF2 Impinge. Protecti	24	Latent Heat (MJ/kg @ °	C)	_	-	_
Pressure Drop (Allow/Calc.)	25	Inlet Pressure (bar (g))	3.45	2	42
Fouling Resistance	26	Velocity (m/se	c)	0.414	1.5	909
Heat Load: 2300	2/	Pressure Drop (Allow/Calc.) (ba	r) 1	0.3	1	0.1
Heat Transfer Rate Service: S73.2 (Wm²-C) Clean: 920.5 (Wm²-C)	28	Fouling Resistance (m²-°C/)	V) (0.00035	0.0	0018
Section Sec	29	Heat Load: 2300 (kW)	4	Corrected LMTD:	44.3	9 (°C)
Tube Side Tub	30	Heat Transfer Rate Service: 573.2	(W/m²-°C)	Clean:	920.5 (Wr	n²-°C)
Pressure Design/Test (bar(g)) 12 17.16 270			CONSTRUCTION	V		
Maximum Allowable Working Pressure (bar(g)) 12 270	31	Fluid Allocation	S	hell Side	Tube	: Side
1	32	Pressure Design/Test (bar(g)) 12	17.16	2/0	386.1
1	33	Maximum Allowable Working Pressure (bar(g	1))	-		
No. of Passes 1	34	Temperature Design/Minimum (*)	3) 1/5	-6	1/5	-6
Nozzles: (No.) & Size (In/Out) Note (9) 6" 6" 6" Nozzles: Hange Type & Rating Tubes: No.: 389 OD: 16.2 (mm) BWG: 12 min. Length: 4877 (mm) Pitch: 22.23 Tube Material: SA-789 UNS 31803, Note (1) Tube Type: μ Seamless λ Welded Shell: SA-516-70 μ Integral μ Removable Floating Head Cover: Channet: SA-516-70 μ Integral μ Removable Floating Head Cover: Channet: SA-516-70 μ Integral μ Removable Floating Head Cover: Tubesheets: λ Stationary μ Floating Impingement Protection: λ Yes μ No Type Baffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others Notes Notes A SME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others Weights: Shell Side: RTJ, 316 SS spiral Wound gasket, style CGI (wi inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ Notes 18 (kg) Bundle: (kg) Full of Water: 19 (3) 18 SS spiral wound gasket, style CGI (wi inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 36 (8) Buffle Mic SS spiral wound gasket, style CGI (wi inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 37 (1) Expansion joint, flanged and flued, designed for 1000 cycles, with Y= plugged vent and drain. The expansion shall be based on: 38 (18) Deleted	35	No. of Passes		1		1
Nozzles: Flange Type & Rating Tubes: No.: 389 OD: 16.2 (mm) BWG: 12 min. Length: 4877 (mm) Pitch: 22.23 Tube Material: SA-789 UNS 31803, Note (1) Tube Type: μ Seamless λ Welded Shell: SA-516-70 ID: 508 OD: Impact Plate: Shell Cover: μ Integral μ Removable Floating Head Cover: Channel: SA-518-70 Channel Cover: SA-516-70 or SA-350 LF2 Tubesheets: λ Stationary μ Floating Impingement Protection: λ Yes μ No Type Tubesheets: λ Stationary μ Floating Impingement Protection: λ Yes μ No Type Saffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others γ Gut 20 (bia.) Spacing: C/C 247.7 Inlet: 508 Seal Type: Tube Supports: Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. Notes (1) Strength weld tube to tube sheet. (2) TUU % RT on channel side. 3) 6" pressure relief connection in shell (3) 16 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ (3) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: a. Shell fluid flowing at -6 "C and tube fluid entering at 113 "C b. Normal operating condition (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles)				3.0	3	3.0
Tubes: No.: 389 OD: 18.2 (mm) BWG: 12 min. Length: 4877 (mm) Pitch: 22.23 Tube Material: SA-789 UNS 31803, Note (1) Tube Type: μ Seamless λ Welded Shell: SA-516-7U	3/	Nozzies: (No.) & Size (In/Out) Note (9)		0 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1	0 011	75.111 1111
Tube Material: SA-789 UNS 31803, Note (1) Tube Type: μ Seamless λ Welded 10 Shell: SA-516-70 ID: 508 OD: Impact Plate: 11 Shell Cover: μ Integral μ Removable Floating Head Cover: 12 Channel: SA-518-70 μ Integral μ Removable Floating Head Cover: 13 Channel: SA-518-70 μ Integral μ Removable Floating Head Cover: SA-516-70 rSA 350 LF2 14 Tubesheets: λ Stationary μ Floating Impingement Protection: λ Yes μ No Type 15 Tubesheets Material: SA-350-LF2 Impinge. Protection Mat'l: CS Baffle Microsoft Head Cover: SA-516-70 Integral μ Horizontal μ Others 16 Gaskets: Shell Side: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 17 Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others 18 Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. 19 Notes 10 Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell 19 Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: a. Shell fluid flowing at -8 °C and tube fluid entering at 113 °C 19 b. Normal operating condition 10 (8) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles)	30	Tubes: No: 200 OD: 18.2 (mm)				22.23 mm, 30°
Shell Cover: Shell Cover: Channel Cover: Channel Cover: Channel Cover: Channel Cover: Tubesheets: A Stationary μ Floating Impingement Protection: Tubesheets: A Stationary μ Floating Impingement Protection: Tubesheets Material: SA-350-LF2 Impinge. Protection Mat'l: SB Baffle Mi Baffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others Code Requirements: Shell Side: Tube Side: Tube Side: Tube Side: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 14 Code Requirements: A SME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. Notes (1) Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell (3) 316 SS spiral wound gasket, style CGI (wi inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ (3) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: a. Shell fluid flowing at -6 °C and tube fluid entering at 113 °C b. Normal operating condition (8) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles)				Spamlage 3 Wk	lded	22.25 11111, 00
Shell Cover:		Shell: SA-516-/U	- ID: 508	OD:	Impact Plate:	CS
Tubesheets: λ Stationary μ Floating Impingement Protection: λ Yes μ No Type Tubesheets Material: SA-350-LF2 Impingement Protection λ Yes μ No Type Tubesheets Material: SA-350-LF2 Impinge. Protection Mat'l: CS Baffle Mi Baffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others Tube Supports: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. Notes Type: 31 Notes Type: Segment. λ Vertical μ Horizontal μ Others Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. Notes Type: 31 Notes Type: 32 Ty		Shell Cover: u. Integra	_			
Tubesheets: λ Stationary μ Floating Impingement Protection: λ Yes μ No Type Tubesheets Material: SA-350-LF2 Impinge, Protection Math: CS Baffle Mi Baffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others 1 % Cut 20 (Uia.) Spacing: C/C 247.7 Inlet: 508 Seal type: Tube Supports: 48 Gaskets: Shell Side: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 49 Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others 50 Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. 51 Notes 52 (1) Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell 53 (4) 316 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 54 (3) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: a. Shell fluid flowing at 48 °C and tube fluid entering at 113 °C 55 b. Normal operating condition 56 (8) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles)		Channel: SA-516-70		ver:	SA-516-/U or SA 350	LF2
Tubesheets Material: SA-350-LF2 Impinge. Protection Mattl: CS Baffle Mit Baffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others """ """ """ """ """ """ """	44	Tubesheets: λ. Stationary μ Floating Imp				
8 Baffles CS, Note (7) λ Cross μ Long Type: Segment. λ Vertical μ Horizontal μ Others 47 % Cut 20 (Dia.) Spacing: C/C 247.7 Inlet: 508 Seal Type: Tube Supports: 48 Gaskets: Shell Side: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 49 Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others 50 Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. 51 Notes 52 (1) Strength weld tube to tube sheet. (2) TUD % RT on channel side. 3) 6" pressure relief connection in shell 53 (4) 316 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 54 (5) Expansion joint, flanged and flued, designed for 1000 cycles, with ½ plugged vent and drain. The expansion shall be based on: 55 a. Shell fluid flowing at -6 °C and tube fluid entering at 113 °C 55 b. Normal operating condition 56 (B) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles) 56 (8) Deleted	45	Tubesheets Material: SA-350-LF2	-	Impinge Protection	Mattl: CS B	affle Mat'l CS
48 Gaskets: Shell Side: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 49 Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others 50 Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. 51 Notes 52 (1) Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell 53 (4) 316 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 54 (5) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: 55 b. Normal operating condition 56 b. Normal operating condition 57 (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles) 58 (8) Deleted	46	Baffles CS, Note (7) λ. Cross μ Long Ty	pe: Segment.	λ Vertical μ Horiz	ontal μ Others	
48 Gaskets: Shell Side: Tube Side: RTJ, 316 SS, solid Note (4) λ Exp. Joint Type: 31 49 Code Requirements: λ ASME Sec. VIII, DIV. 1 μ Code Stamp λ TEMA Class: R μ Others 50 Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thk. 51 Notes 52 (1) Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell 53 (4) 316 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 54 (5) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: 55 b. Normal operating condition 56 b. Normal operating condition 57 (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles) 58 (8) Deleted	4/	% Cut 20 (Dia.) Spacing: C/C 24/./	Inlet: 508	Seal Type:	Tube Supports:	
Weights: Shell (kg) Bundle: (kg) Full of Water: (kg) μ Insulation Thic. Notes	48	Gaskets: Shell Side: Tube Side	ie: RTJ, 31	6 SS, solid Note (4)	λ. Exp. Joint Typ	
Notes 17 Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell 13 16 15 15 16 17 17 17 18 18 19 19 19 19 19 19			μ Code Stamp	λ. TEMA Class:		
(1) Strength weld tube to tube sheet. (2) 100 % RT on channel side. 3) 6" pressure relief connection in shell (4) 316 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ (5) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged vent and drain. The expansion shall be based on: a. Shell fluid flowing at -6 °C and tube fluid entering at 113 °C b. Normal operating condition (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles)			(kg) Full (of Water: (k	g) µ Insulation	Thk. (mm)
53 (4) 316 SS spiral wound gasket, style CGI (w/ inner and outer ring) on shell nozzles; tube nozzle, solid 316 SS for RTJ 54 (5) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged went and drain. The expansion shall be based on: a. Shell fluid flowing at -6 °C and tube fluid entering at 113 °C b. Normal operating condition (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles) (8) Deleted						
 (5) Expansion joint, flanged and flued, designed for 1000 cycles, with ½" plugged went and drain. The expansion shall be based on: a. Shell fluid flowing at -8 °C and tube fluid entering at 113 °C b. Normal operating condition (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (16 baffles) (8) Deleted 						
a. Shell fluid flowing at -8 °C and tube fluid entering at 113 °C b. Normal operating condition f(B) Both ends of channel require insulation, or personnel protection heat shields. (/) 17 crosspaths shell side (16 baffles) 8 (8) Deleted	53	(4) 310 35 spiral wound gasket, style CGI (w/ inner and ou	ter ring) on shell not	zies; tube nozzie, solid i	510 SS for KIJ	end on:
b. Normal operating condition b. (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (10 baffles) b8 (8) Deleted				eu vent anu drain. The	expansion shall be bas	seu UII.
b/ (6) Both ends of channel require insulation, or personnel protection heat shields. (7) 17 crosspaths shell side (10 baffles) b8 (8) Deleted			113 6			
58 (8) Deleted		(6) Both ends of channel require insulation, or personnel or	rotection heat shield	s. (/) 1/ crossnaths shel	side (16 baffles)	
			and 2/3 point on top	of shell for rupture pin w	alve.	
				-F F v.		

6.1 Critical and Reduced Temperature and Pressure

Critical and reduced pressure and temperature are often used as correlating parameters. As the critical temperature is approached, the properties of gas and liquid phases approach one another, resulting in only one phase at the critical point: a homogeneous supercritical fluid. The heat of vaporization is zero at and beyond this critical point, hence there is no distinction between the two phases. Above the critical temperature a liquid cannot be formed by an increase in pressure, but with enough pressure a solid may be formed. The critical pressure is the vapour pressure at the critical temperature. Critical properties vary from material to material, just as is the case for the melting point and boiling point. Critical properties for many pure substances are readily available in the literature. Obtaining critical properties for mixtures is somewhat more problematic.

The critical point for a multicomponent mixture is referred to as the state of pressure and temperature at which all intensive properties of the gas and liquid phases are equal.

Reduced Properties

Like critical properties, reduced properties are often used as correlating parameters and properties in thermodynamics. Reduced properties are temperature and pressure divided by their respective critical property.

6.2 Liquid Density

Liquid density is required for the design of numerous items of process plant. Common liquid densities are as shown.

Compound	Density @ 15 °C
	(kg/m^3)
Water	1000
Ethyl alcohol	785
Butane	563.2
Octane	706.7
Heavy Crude	903
Medium Crude	859
Light Gas Condensate	734
Steel	Approx. 7800
Concrete	Approx. 2300

One of the simplest calculation methods is the API corresponding states method which uses a correlation to obtain a correction factor that adjusts the density at standard conditions to the actual conditions.

$$v_{m} = \sum \frac{M_{i}x_{i}}{\rho_{i}}$$

$$M_{m} = \sum x_{i}M_{i}$$

$$\rho_{\text{actual}} = \rho_{\text{stan}\,dard} \left(\frac{C1}{C2}\right)$$

Where:

v - Molar Volume ($m^3/kmol$)

 ρ - density (kg/m³)

M - Molecular weight (kg/kmol)

x - Mole fraction

C1 & C2 - Correlation factors for density correction

m - mixed compound

Example:

Calculate the liquid density of a saturated mixture of 70% ethane, 20% propane and 10 %butane at 100 bara and 25°C.

Obtain the density of components at standard conditions, here data is given relative to water.

$$C_2 - \gamma = 0.3581$$
 $\therefore \rho = 358.1 \text{ kg/m}^3, M = 30.07$
 $C_3 - \gamma = 0.5083$ $\therefore \rho = 508.3 \text{ kg/m}^3, M = 44.097$
 $C_4 - \gamma = 0.5637$ $\therefore \rho = 563.7 \text{ kg/m}^3, M = 58.124$

Using volume mixing equation

$$v_{\rm m} = \frac{30.07 \times 0.7}{358.1} + \frac{44.097 \times 0.2}{508.3} + \frac{58.124 \times 0.1}{563.7} = 0.0865 \text{ m}^3/\text{kmol}$$

$$M_{\rm m} = (30.07 \times 0.8) + (44.097 \times 0.2) + (58.124 \times 0.1) = 35.68 \text{ kg/kmol}$$

$$\rho_{\text{m standard}} = \frac{M_m}{v_m} = \frac{38.69}{0.0864} = 412.6 \text{ kg/m}^3$$
 @Standard Conditions

Now find the correlation factors to adjust the standard density to the actual conditions.

Taking Critical Properties from standard databooks

$$P_{cm} = \sum x_i P_{ci} = (0.7 \times 48.8) + (0.2 \times 42.49) + (0.1 \times 36.49) = 46.31 \text{ bara}$$

$$T_{cm} = \sum x_i T_{ci} = (0.7 \times 305.43) + (0.2 \times 369.82) + (0.1 \times 408.13) = 328.6 \text{ K}$$

@ Standard Conditions (15 C & 1 bara)

$$P_{r \text{ standard}} = \text{Saturated Liquid}$$
 $T_{r \text{ standard}} = \frac{288}{328.6} = 0.876$


From Correlation chart C1 = 0.745

@ Actual Conditions (25 C & 100 barg)

$$P_{\text{ractual}} = \frac{100}{46.31} = 2.16$$
 $T_{\text{ractual}} = \frac{298}{328.6} = 0.907$

From Correlation Chart C2 = 0.764

So
$$\rho_{\text{actual}} = \rho_{s \tan dard} \left(\frac{C2}{C1} \right) = 412.6 \left(\frac{0.764}{0.745} \right) = 423.11 \text{ kg/m}^3$$



API Correction Factor Chart

Comparing the above with the simulation Unisim. Equation of State generally use the Hawkinson, Brombst & Thomson method - referred to as COSTALD because it uses Corresponding Standard Liquid Tables.

$$\frac{V_s}{V^*} = V_R^0 [1 - \omega_{SRK} V_R^{\delta}]$$

$$V_R^0 = 1 + a(1 - T_r)^{1/3} + b(1 - T_r)^{2/3} + c(1 - T_r) + d(1 - T_r)^{4/3} \qquad 0.25 < T_r < 0.95$$

$$V_R^{\delta} = [e + fT_r + gT_r^2 + hT_r^3] / (T_r - 1.00001) \qquad 0.25 < T_r < 1.0$$

Where

 V_s – Saturated Liquid Volume

 V_R^0 , V_R^δ - Functions of Tr

T_r - Reduced Temperature

$$V^*$$
 - Molar Volume ω_{SRK} - Acentric factor Found in COSTALD tables

$$\begin{array}{lll} a = -1.52816 & b = 1.43907 \\ c = -0.81446 & d = 0.190454 \\ e = -0.296123 & f = 0.386914 \\ g = -0.0427258 & h = -0.0480645 \end{array}$$

The mixing rules for the variables in the previous equations are as follows:

$$T_{cm} = \frac{\sum_{i=1}^{n} \sum_{j=1}^{n} x_{i} x_{j} V_{ij}^{*} T_{cij}}{V_{m}^{*}}$$

$$V_{m}^{*} = \frac{1}{4} \left[\sum_{i} x_{i} V_{i}^{*} + 3 \left(\sum_{i} x_{i} V_{i}^{*2/3} \right) \left(\sum_{i} x_{i} V_{i}^{*1/3} \right) \right]$$

$$V_{ij}^{*} T_{cij} = \left(V_{i}^{*} T_{ci} V_{j}^{*} T_{cj} \right)^{1/2}$$

$$\omega_{SRK_{m}} = \sum_{i} x_{i} \omega_{SRK_{i}} \qquad \text{Acentric Factor (shape sensitive)}$$

$$P_{cm} = \frac{\left(0.291 - 0.80 \omega_{SRK_{m}} \right) RT_{cm}}{V_{m}^{*}}$$

This is a much more complicated method and is not suitable for hand calculations. Using the liquid density calculation in Unisim returns a density of 456.5 kg/m³. Using the API method a value of 423.11 kg/m³ was calculated.

6.3 Gas Compressibility

The term "compressibility" is also used in thermodynamics to describe the deviance in the thermodynamic properties of a real gas from those expected from an ideal gas. The compressibility factor is defined by the familiar expression as;

$$z = \frac{PV_m}{RT}$$

where


P is the pressure of the gas


T is its temperature

 V_m is molar volume. In the case of an ideal gas

Note, Z can be either greater or less than unity for a real gas.

The deviation from ideal gas behavior tends to become particularly significant near the critical point, or in the case of high pressure or low temperature. In these cases, a generalized compressibility chart or an alternative equation of state better suited to the problem can be utilised to produce accurate results.





Typical gas densities at 15 C and 1 bara

Compound	Vapour Density (kg/m ³)
Air	1.21
Oxygen	1.335
Carbon dioxide	1.873
Methane	0.6784
Propane	1.865

The main parameter in calculating vapour density is the compressibility. This can be calculated by either the appropriate equation of state or activity model, or by generalised compressibility charts.

Example calculation using compressibility charts;

Mixed critical properties are calculated using Kay's rule and databook tables:

 $\mathbf{P}_{\mathrm{cm}} = \sum y_{i} P_{ci} \qquad , \quad \mathbf{T}_{\mathrm{cm}} = \sum \mathbf{y}_{i} T_{ci}$ where y_i is mole fraction of vapour component Reduced properties (Pr, Tr) are calculated

$$\mathbf{P}_{\mathrm{rm}} = \frac{P}{P_{cm}} \qquad , \quad \mathbf{T}_{\mathrm{rm}} = \frac{T}{T_{cm}}$$

Use the reduced properties with a compressibility chart to obtain the compressibility, Z.

The Mean molecular mass is then calculated $M_m = \sum y_i M_i$ $\rho_{\rm m} = M_m P / ZRT$ and Density is calculated

Calculate the density of the following vapour at 15 bara pressure and 25 C temperature. At these conditions the mixture is single phase gas. Watch units MPa.

Component	Yi	Tci (K)	YTci	Pci (MPa)	YPci	М	Myi	
C2	0.7	305	213.5	4.88	3.416	30.07	21.049	
C3	0.2	370	74	4.25	0.85	44.097	8.8194	
C4	0.1	408	40.8	3.65	0.365	58.124	5.8124	
Sum			328.3		4.631		35.681	

We have the mixtures critical properties, next calculate the reduced properties

$$P_{r} = \frac{P}{P_{c}}$$


$$T$$

$$T_{\rm r} = \frac{T}{T_c}$$

$$P_r = 15/46.3 = 0.324$$

$$T_r = 298.15/328.3 = 0.907$$





From generalise d compressibility charts Z = 0.84

$$\rho_{\rm m} = M_{\rm m} P / ZRT$$

= 35.68×1500/(0.84×8.314×298.15)
= 25.7 kg/m³

6.4 Viscosity

EG5099

6.4.1 Liquid

Component viscosities can be found by using viscosity charts. The charts are in many data books along with co-ordinates which relate to different compounds. There are separate charts for gases and liquids.

For viscos ity estimation of liquid mixtures the following rule can be used

$$\mu_m = \left[\sum \mathbf{x}_{\mathrm{i}} (\mu_i)^{1/3}\right]^3$$

where

 μ_m – mixture vis cos ity,

xi - component mole fraction

 μ_i – component viscosity

Example:

Using the viscosity chart estimate the viscosity of a mixture of 30% Pentane and 70% Octane at 25 °C and 1 bar.

Find the co-ordinates for Pentane and Octane to be used with the chart.


Pentane - X=14.9, Y=5.2

Octane - X=13.7, Y=10

from the chart

 μ (mPa)= 0.23 for pentane and 0.54 for octane (note: cP = mPas)

$$\mu_m = \left[\left(0.3 * (0.23)^{\frac{1}{2}} \right) + \left(0.7 * (0.54)^{\frac{1}{2}} \right) \right]^3$$
$$= \left[0.1838 + 0.5700 \right]^3$$
$$= 0.428 \text{ cP}$$



Note Unisim returns a liquid viscosity of 0.416 cP

6.4.2 Gas

For viscosity estimation of gases the following rule can be used

$$\mu_{\rm m} = \frac{\sum \mu_i y_i \sqrt{M_i}}{\sum y_i \sqrt{M_i}}$$

where;

 μ_m - Mixture viscosity,

 μ_i -Component viscosity

y, - Mole fraction of component

M. - Component molecular weight

Viscosities are found from viscosity charts. The charts give the viscosity at 1atmosphere and the required temperature. Correction for pressure and temperature


can be made by using a viscosity correction chart. This requires the reduced P & T from Kay's rule.

Example:

Estimate the viscosity of a gas with composition 40% methane & 60% propane at 25°C and 5 bara pressure.

Calculated the viscosity of the gas at 1 atmosphere and the required temperature Using co-ordinates: Methane - X= 9.9, Y= 15.5: Propane - X= 9.7, Y= 12.9 From chart μ (mPa) = 0.011 for methane

= 0.0084 for propane



$$\begin{split} \mu_m &= \frac{0.011*0.4*\sqrt{16.043} + 0.0084*0.6*\sqrt{44.097}}{0.4*\sqrt{16.043} + 0.6*\sqrt{44.097}} \\ &= \frac{0.0176 + 0.0335}{1.602 + 3.984} = 0.00915 \, (cP) \end{split}$$

6.5 Specific Heat Capacity

Typical values are given. Note the high heat capacity of water compared to hydrocarbons.

Gas/solid Compound	Isobaric Heat Capacity, Cp (J/kgK)	Liquid Compound	Isobaric Heat Capacity, Cp (kJ/kgK)
Air	0.996	Water	4.187
Propane	2.467	Octane	2.177
		Decane	1.758
Stee1	0.502	Heavy Crude	1.718
		Medium Crude	1.750
		G as C ondensate	2.077

The AIChemE method can be applied for both gases and liquids. A correction factor is used to adjust the ideal value.

A simple weight fraction average can be used as a first approximation

6.6 Thermal Conductivity

Typical values are given for some common fluids and solids.

Gas / solid Compound	Thermal Conductivity (W/m ² K)	Liquid Compound	Thermal Conductivity (W/m ² K)
Methane	0.0286	Water	0.569
Propane	0.1181	Octane	0.144
•		Heavy crude	0.164
Carbon steel	51.9	Medium crude	0.146
Stainless steel	16.3	Gas condensate	0.132

Most simulators use the general guidelines of Reid, Prausnitz & Poling to determine which model best suits each class of component.

- Hydrocarbon systems use the corresponding states method of Ely & Hanley
- Glycols & Acids are calculated by Sato-Reidel method
- Esters, alcohols and light hydrocarbons by Latini

6.7 Surface Tension

A molecule on the surface of a liquid is subject to an inward force as a result of the attraction between molecules. This surface molecule tends to adjust itself to a

minimum surface area causing the droplet to assume a spherical shape. Work is required to extend this surface or to bring molecules from the bulk of the liquid into the surface.

The units of surface tension are therefore force/unit length – N/m. However, most surface tension values are presented as dyne/cm – where 1 dyne – 10^{-5} Newton.

Component	Surface Tension		
	(dyne/cm)		
Water	73.82		
Octane	25.05		
Heavy crude	30.27		
Medium crude	27.32		
Gas condensate	23.39		


6.8 Vapour Pressure

The vapor pressure of a liquid, is the pressure exerted by its vapor when the liquid and vapor are in dynamic equilibrium. Vapor pressure is the pressure of a vapor in equilibrium with its non-vapor phases All solids and liquids have a tendency to evaporate to a gaseous form, and all gases have a tendency to condense back. At any given temperature, for a particular substance, there is a partial pressure at which the gas of that substance is in dynamic equilibrium with its liquid or solid forms. This is the vapor pressure of that substance at that temperature. In meteorology, the term vapor pressure is used to mean the partial pressure of water vapor in the atmosphere, even if it is not equilibrium, and the equilibrium vapor pressure is specified as such. Vapor pressure is an indication of a liquid's evaporation rate. It relates to the tendency of molecules and atoms to escape from a liquid or a solid. A substance with a high vapor pressure at normal temperatures is often referred to as volatile. The higher the vapor pressure of a material at a given temperature, the lower the boiling point.

The vapor pressure of any substance increases non-linearly with temperature according to the Clausius-Clapeyron relation. The boiling point of a liquid is the temperature where the vapor pressure equals the ambient atmospheric pressure. At the

boiling temperature, the vapor pressure becomes sufficient to overcome atmospheric pressure and the liquid forms bubbles inside the bulk of the substance.

Vapour pressure of common liquids. Note bubble point and



saturation pressure are commonly utilised to describe vapour pressure.

7 Key Learnings

Features of mixed hydrocarbon Phase Envelope – dew point etc.

Pseudo/hypothetical components

Concept of fugacity

Application of K values

Application of Peng-Robinson/SRK EOSs

Application of Activity Models

Importance of EOS selection

Importance of physical property prediction

Vapour pressure

8 Reference books

- 1. GPSA Engineering Data Book (Gas Processors Association)
- 2. Phase Equilibria in Chemical Engineering, Stanley M Walas
- 3. Chemical and Engineering Thermodynamics, S.I Sandler