Sistemas Digitales

Semana 12: Algoritmos y Diagramas de Flujo

Semestre 2020-2

Profesor: Kalun José Lau Gan

1

Preguntas previas:

- ?
- ??
- ???


Agenda:

- Algoritmos
- Diagramas de flujo
- Manipulación de I/O en el NIOS II (PIO)
- Ejemplos

3

Algoritmos

- ¿Qué es un algoritmo? (5minutos)
 - Secuencia ordenada de instrucciones (o pasos) para resolver un determinado problema o el uso correcto de un equipo.
- Ejemplos:
 - Programa en computadora
 - Manual de instrucciones (de operación, de uso)
 - Hoja de ruta
 - Procedimiento para dar con la solución de un problema
 - · Receta de cocina
 - Pasos para resolver un problema matemático, ingenieril, etc




Diagramas de flujo (flowchart)

- ¿Quién inventó el diagrama de flujo?
 - Frank Gilbreth (1921)
- Características:
 - Emplea formas geométricas para la representación de un algoritmo
 - Usualmente en formato vertical
 - Empleado en research papers.

5

Manipulación de puertos en el NIOS II

• Referencia: Manual de IPs de NIOS II, sección "PIO".



• Revisar librería altera_avalon_pio_regs.h

7

Registros internos del PIO

Table 273. Register Map for the PIO Core

Offset	Register Name		R/W	(n-1)	•••	2	1	0
0	data	read access	R	Data value currently on PIO inputs				
		write access	W	New value to drive on PIO outputs				
1	direction (1)		R/W	Individual direction control for each I/O port. A value of 0 sets the direction to input; 1 sets the direction to output.				
2	interruptmask (1)		R/W	IRQ enable/disable for each input port. Setting a bit to 1 enables interrupts for the corresponding port.				
3	edgecapture (1), (2)		R/W	Edge detection for each input port.				
4	outset		W	Specifies which bit of the output port to set. Outset value is not stored into a physical register in the IP core. Hence it's value is not reserve for future use.				
5	outclear	1	W	Specifies which output bit to clear. Outclear value is not stored into a physical register in the IP core. Hence it's value is not reserve for future use.				

Note


- This register may not exist, depending on the hardware configuration. If a register is not present, reading the register returns an undefined value, and writing the register has no effect.
- If the option Enable bit-clearing for edge capture register is turned off, writing any value to the edgecapture register clears all bits in the register. Otherwise, writing a 1 to a particular bit in the register clears only that bit.


Librería *altera_avalon_pio_regs.h*

```
#ifndef _ALTERA_AVALON_PIO_REGS_H
#define _ALTERA_AVALON_PIO_REGS_H
#define IOADDR_ALTERA_AVALON_PIO_DATA(base)
                                                                      IO_CALC_ADDRESS_NATIVE(base, 0)
                                                                    IORD(base, 0)
IOWR(base, 0, data)
#define IOADDR_ALTERA_AVALON_PIO_DIRECTION(base)
#define IORD_ALTERA_AVALON_PIO_DIRECTION(base)
                                                                      _IO_CALC_ADDRESS_NATIVE(base, 1)
#define IOND_ALTERA_AVALON_PIO_OIRECTION(base) 10MD(base, 1)
#define IONR_ALTERA_AVALON_PIO_OIRECTION(base, data) 10MR(base, 1, data)
#define IOADDR_ALTERA_AVALON_PIO_IRQ_MASK(base)
#define IORD_ALTERA_AVALON_PIO_IRQ_MASK(base)
                                                                      _IO_CALC_ADDRESS_NATIVE(base, 2)
#define IOADDR_ALTERA_AVALON_PIO_EDGE_CAP(base)
#define IORD_ALTERA_AVALON_PIO_EDGE_CAP(base)
                                                                      _IO_CALC_ADDRESS_NATIVE(base, 3)
#define IORD_ALTERA_AVALON_PIO_EDGE_CAP(base) IORD(base, 3)
#define IOWR_ALTERA_AVALON_PIO_EDGE_CAP(base, data) IOWR(base, 3, data)
#define IOADDR_ALTERA_AVALON_PIO_SET_BIT(base)
                                                                   __IO_CALC_ADDRESS_NATIVE(base, 4)
#define IORD_ALTERA_AVALON_PIO_SET_BITS(base) IOMD(base, 4)
#define IOWR_ALTERA_AVALON_PIO_SET_BITS(base, data) IOWR(base, 4, data)
#define IOADDR ALTERA AVALON PIO CLEAR BITS(base)
                                                                        IO CALC ADDRESS NATIVE(base,
#define IOWR ALTERA AVALON PIO CLEAR BITS(base, data) IOWR(base, 5, data)
/* Defintions for direction-register operation with bi-directional PIOs */
#define ALTERA AVALOW PIO DIRECTION OUTPUT 1
#endif /* __ALTERA_AVALON_PIO_REGS_H__ */
```

9

Ejemplo 1: Titilar un LED a través del bit0 del registro PIO de 8bits con dirección 0x5300






Ejemplo 2: Modelar una compuerta XOR en diagrama de flujo

ABC

OX5500: PTO en supert

OX5320. PTO en output



Ejemplo 3: Detectar la cantidad de veces que se presiona un botón y visualizarlo como mensaje en la consola del NIOS II

INICAO

LONFIG

LONFI

