```
Label label_wifi show
                         M5 start
LED ON
repeat while not wifi is connected
                             No WiFi
    Label label_wifi show
    Wait 📜 1
    Connect to Wi-Fi SSID
                           ASUS
                                     PASSWORD
                                                     Doktorzec1
Label label wifi show
                         WiFi ok
LED OFF
set mqtt_value v to 0
                M5_module
                192.168.1.178
              1883
              300
SSL False
H
  change mqtt_value by 1
  Label label_mqtt show mqtt_value
                             msg mqtt_value -
                                                      0
                  number
```