CAN-Messages							Identifier A							Identifier B													
Sender	Empfänger	Ziel	Messagetyp	Subtyp	8	7	6	5 4	3	2	1 (	9	8	7	6 5	4	3	2 1	L <b>O</b>	9	8	7 6	5	4 3	3 2	1 0	
Logger	Alle	ВС	Tech	Sensor Identifizierung	0	0	0	0 0	1	1	1 1	1 1	1	1	1 0	0	0	0 0	0	0	1	0 0	0	0 (	0	0 1	
Logger	Sensor	ВС	Tech	CAN-Ids vergeben	0	0	0	0 1	1	1	1 1	1 1	1	1	1 0	0	0	0 0	0	0	1	0 0	0	0 (	0	0 1	
Logger	Sensor	Single	Konfiguration	Betriebsmodus/Detaillevel auswählen	0	1	0	0 0	Se	nsc	orA	rAddr			О	0	00000			1	0 0	0	0 (	0	0 1		
Logger	Alle	ВС	Konfiguration	Betriebsmodus/Detaillevel auswählen	0	1	0	0 1	1	1	1 1	լ 1	1	1	1 0	0	0	0 0	0	0	1	0 0	0	0 0	0	0 1	
Sensor	Logger	Single	Konfiguration	Seriennummer	1	1	0	0 0	0	0	0 0	0	0	0	1 0	0	0	0 0	0	0	0	0 0	0	0 (	0	0 1	
Sensor	Logger	Single	Flow	ACK/NACK von TOKEN	1	1	0	0 1	0	0 0 0 0 0 0 0 1 5					1 S	SensorAddr					0 0	0	0 0	0	0 1		
Sensor	Logger	Single	Messdaten	Rohdaten	1	1	0	1 0	0	0	0 0	0 0	0	0	1 S	ens	orA	۸dd	r				4bs	ähle	r		
Sensor	Logger	Single	Messdaten	Ereignis Extended	1	1	0	1 1	0	0	0 0	0	0	0	1 S	ens	orA	۸dd	r			Abst. Zähler					
Sensor	Logger	Single	Messdaten	Ereignis Standard	1	1	1	0 0	0000000					0	1 S	SensorAddr					Abst. Zähler						
					Р	Type Targ					Target Addr					Source Addr					ſ	Mess-ID					