



KB360-PRO-XXX

Quick Start Guide



Congratulations on your new Kinesis Keyboard!

This Quick Start Guide is designed to get you up and running with keyboard basics. For additional details and full programming instructions please read the User's Manual and consult the other support resources before embarking on this journey.

All Support Resources: kinesis-ergo.com/support/kb360pro



Visit the Official Kinesis YouTube channel for short tutorial videos

In the Box

- Advantage360 Professional Keyboard
- 2 Charging Cables (USB-C to USB-A) and 2 A-to-C Adapters
- Bridge Connector
- Extra Keycaps & Keycap Removal Tool

System Requirements

- Computer with an available USB port or Bluetooth®
- Windows®, macOS®, iOS®, iPadOS®, Linux®, or Chrome®

Legal

Kinesis® Advantage360 Professional™ Keyboard with the ZMK Programming Engine. Keyboard models covered by this guide include all Professional series keyboards: KB360-PRO-XXX and KB365-PRO-XXX.

ZMK firmware licensed under the Apache License version 2.0.
Contains FCC ID: 2ALGY-NRF52840

© 2025 by Kinesis Corporation. All rights reserved.
KINESIS is a registered trademark of Kinesis Corporation.
ADVANTAGE360, CONTOURED KEYBOARD, and CLIQUE are trademarks of Kinesis Corporation. WINDOWS, MAC, MACOS, LINUX, ZMK, BLUETOOTH and ANDROID are property of their respective owners.

Proudly designed and hand-assembled in the USA since 1992.

Important Links

User Manual: kinesis-ergo.com/support/kb360pro/#manuals
More Tips: kinesis-ergo.com/support/kb360pro/#troubleshooting
Contact Kinesis: kinesis-ergo.com/support/kb360pro/#ticket

Warning

The Advantage360 is not a medical treatment. Please consult your doctor if you experience pain while using any keyboard and discontinue use immediately.

Getting Started: Ergonomics

The Kinesis contoured keyboard has stood the test of time since its first introduction in 1992. The Advantage360 takes those same core design principles and adds adjustable separation, rotation, and tenting to suit any body type.

Learn More: kinesis-ergo.com/solutions/keyboard-risk-factors

Separation and Rotation

The most ergonomic typing position is one in which your hands are in line with your arms for “straight” wrists. This can be achieved by separating the modules to shoulder-width, rotating the modules “outward”, or any combination of the two. New users should start with the modules closer together, and experiment with separation and rotation to see what orientation feels most natural.



Optional Bridge Connector

For those who want to recreate the classic separation of our original contoured keyboard, or those who just aren't ready to make the move to a fully split keyboard, simply snap the Bridge Connector onto the keyboard base.

Warning: The Bridge Connector is NOT designed to support the weight of the keyboard!!!



Adjustable Tenting

The Advantage360 features three adjustable “tenting” heights to reduce forearm pronation. Depress the button on the underside of each module and raise/lower it to the desired height. We recommend starting on the lowest setting and moving up from there to find the perfect position for your body.



Getting Started: Wireless Mode

If your computer does not have built-in Bluetooth, you will need to purchase a 3rd party Bluetooth dongle to enable wireless use.

Powering up the keyboard

Each module has a battery-power switch on the backside. The modules are turned **ON** by sliding the switch **AWAY** from the adjacent charging port, and turned **OFF** by sliding the switch **TOWARDS** the charging port. *Important Note: The left module is the primary device, so it communicates with the PC. The right module only communicates with the left module.*

Pairing the keyboard with your computer

When you first power-on your keyboard, the Profile LED on the left module (see Page 7) should be **flashing white rapidly**. That signals the keyboard is in "pairing mode" for Profile 1 and ready to pair with your PC. Open your computer's Bluetooth menu and locate the "Adv360 Pro" device and select "Connect". The flashing White Profile LED will go solid when Profile 1 has been successfully paired. *Note: The Bluetooth pairing sequence will vary based on the device and operating system, so consult your computer's operating manual.*

Pairing the keyboard with additional computers

The keyboard has **5 color-coded Profiles** (see page 7), each of which can each be paired to a different computer via Bluetooth. To pair the keyboard with additional devices, toggle to a different Profile and then complete the pairing process from the other device.

Toggle Bluetooth Profile: **Mod + 1 - 5**

Charging the keyboard

Each module is equipped with a rechargeable lithium-ion battery which will need to be **charged every couple of weeks** depending on your usage and backlight settings. Use the command below to periodically check battery level via the 3 indicator LEDs. Once the batteries reach the "Red" level (<20%) connect each module to your computer overnight using the included cables. *Note: While the left module is charging all keystrokes will be sent to that computer via USB regardless of the Profile, so plan your charge time accordingly.*

Getting Started: Wired Mode

This keyboard is optimized for wireless use, but many people prefer the convenience, stability and/or perceived security of a wired USB connection. It may also be necessary to use the keyboard wired in the event the batteries die unexpectedly or wireless connectivity is temporarily unavailable. The keyboard makes it easy to seamlessly switch between wired and wireless connections and you can **safely leave it plugged in full-time**.

*Note: The left and right modules **always communicate with each other wirelessly** so it is not possible to disable the Bluetooth radio, even in wired mode.*

Connecting the keyboard to your computer via USB

Simply use the included cables (and adapters if necessary) to connect the left and right modules to available ports on the computer. **Connect the left module first**, wait for the Profile LED to illuminate, and then connect the right module. *Note: When a module is connected to a computer, the battery-switch position is irrelevant.*

If you only have one USB port on your computer

If you only have one available USB port on your computer, you will need to power the right module via the rechargeable battery. Simply slide the battery-power switch **AWAY** from the adjacent charging port and charge that battery as needed per the instructions per the instructions on page 4. Do not connect the right module to the wall or a stand-alone charging device as that could damage the battery and void your warranty.

Profile 5 recommended for wired mode

While the left module is connected to a computer, all keystrokes will be sent to that computer via USB regardless of the active Profile or Bluetooth pairing status. Kinesis recommends that wired users activate Profile 5 (**Mod + 5**) to disable the flashing Profile LED.

Can I just connect the right module?

The **right module is not capable of sending data** directly to your computer. Connecting it to your computer is only serves to provide power and charge the battery.

Features and Functionality

The Advantage360 may look intimidating but the key layout is designed to work with your body, and most keys are accessed with the same fingers touch-typists are accustomed to using.

- Concave keywells place alphanumeric keys within easy reach
- Heavily-used editing keys are positioned under your thumbs
- F1 - F12 are accessed by **holding** either of the two "fn" layer keys
- The numeric keypad is accessed by **tapping** the "kp" layer key
- 4 extra "hotkeys" ① ② ③ ④ are available for custom programming

The default layout has 3 auxillary layers

Each key can perform multiple actions depending on which of the 4 "layers" is activated on the keyboard. Each module has a "layer" LED (see Page 7) which illuminates when you navigate away from the Base layer. By default, most keys perform the same action in all layers. If a key performs multiple actions, the keycap will feature a second and/or third legend on its **front face**.

Base Layer 0 (Layer LED off): In the base layer, each key performs its primary action, which is legended on the **top** of the keycap.

kp Layer 1 (Layer LED White): Tap the "kp" key on the left module to TOGGLE access the kp layer, and tap it again to return to the base layer. Kp layer actions are legended on the **lower right corner** of the keycap.

fn Layer 2 (Layer LED Blue): Hold either "fn" key with your pinky to MOMENTARILY access the fn layer, and release to return to the base layer. Fn layer actions are legended on the **lower left corner** of the keycap.

Mod Layer 3 (Layer LED Green): Hold the Mod key to MOMENTARILY access the Mod layer and then use the appropriate key to active commands for Battery Status (hold), Profile Toggle, Profile Clear, Backlight Adjustment, and Clique Unlock.

Custom programming via the new Kinesis Clique Web UI

Your keyboard layout can be quickly and easily customized using a Chrome or Edge browser when over a USB connection. Use the links below to get started with Kinesis Clique. Power users can opt to create an account on GitHub and compile their own firmware for access to advanced "ZMK" tools (see User's Manual for details).

Visit Clique: clique.kinesis-ergo.com

Learn how to use Clique: kinesis-ergo.com/clique-help

Customizing Keycaps

Extra keycaps like macOS modifiers and “blanks” are included to support keyboard customization. Use the keycap removal tool to grasp the sides of a keycap and gently pull straight up to remove.

6 Indicator LEDs

The keyboard has 6 Indicator LEDs that display important keyboard settings. The function and color of each LED are shown below.

Note: Not all indicator functionality is supported on all operating systems over Bluetooth.

Toggle RGB Indicators On/Off: **Mod + Space**

Caps Lock | Profile | Layer

Num Lock | Scroll Lock | Layer



Profile LED Color

- 1: White
- 2: Blue
- 3: Red
- 4: Green
- 5: Off

Layer LED Color

- Base 0: Off
- Kp 1: White
- Fn 2: Blue
- Mod 3: Green

Profile LED flash speed indicates pairing status

- Fast Flash: Keyboard is ready to pair to a new device in this Profile
- Slow Flash: Previously-paired device for this Profile is not in range
- Solid: Keyboard is actively paired to a device

Adjusting backlight brightness

The keyboard features white backlighting and shine-through keycaps for use in low-light environments. There are **5 brightness levels** to choose from and the backlighting can be adjusted on-the-fly. Use the shortcuts below to adjust backlighting. *Note: Battery life will be extended significantly if the backlighting is dimmed or disabled altogether.*

Adjust Brightness Up / Down: **Mod + Up / Down**

Toggle Backlight On/Off: **Mod + Enter**

Troubleshooting and Tips

If the keyboard is not working as expected, most of the time a simple power-cycle will resolve the issue:

- 1) Turn-off or disconnect **BOTH** modules
- 2) Then turn-on or connect the **LEFT** module and wait 5 seconds
- 3) Then turn-on or connect the **RIGHT** module

Flashing red lights on the right side

If all 3 LEDs on the right module are **FLASHING RED**, it means the right module is searching find the left module. Power-cycle both modules to allow them to re-establish their connection and then check battery levels using the Battery Status Command (see Page 4). Charge any batteries displaying Red.

Try to avoid having the right module on by itself

The **left module is the primary device** so it should always be connected / power-on first, and disconnected / powered-off last to reduce the risk of the right module searching for the left.

30 second sleep timer

The keyboard will automatically **go to sleep after 30 seconds of inactivity** regardless of whether its running on battery power or connected to a computer so you don't need to power down each time you step away. Each module will wakeup on the next keypress.

Profile memory

The keyboard will always **revert to the Profile that was active when it last went to sleep**. So to change the default Profile, toggle to the desired Profile and let the keyboard go to sleep on its own.

Trouble connecting wirelessly

If the Profile LED is flashing slowly and the previously paired computer is on and in range, it may be necessary to refresh the wireless connection between the keyboard and your computer.

Refreshing the Bluetooth connection is a two-step process:

- 1) Erase the connection on your computer by "Forgetting"/ "Removing" the "Adv360 Pro" from the Bluetooth menu AND
- 2) Erase the connection on the keyboard with the Bluetooth Clear command for the desired Profile. Then re-pair from scratch.