Wired 01 | Explore EOS

Overview

In this lab, you'll learn how to log into an Arista switch and explore configuration. All Arista switches, whether they're used in data center, campus, WAN, or other environments, run on Arista's Extensible Operating System (EOS). We'll also cover MLAG, how to configure it, and how to troubleshoot issues!

Let's take a closer look at the EOS interface—while it might feel familiar, it's also distinctly unique!

What you'll learn:

- Navigate the Arista EOS CLI and filter command output
- Inspect switch hardware, interfaces, and IP addressing
- Verify MLAG configuration and troubleshoot peering status
- Use VARP for active-active gateway redundancy
- Explore LLDP neighbors and interface counters

Completely Different, Totally Familiar

Let's log into the workshop spine switches.

> **I have a console cable**
>
> If you have a console cable, feel free to console into your switch. The switch is in ZTP — you can explore the same commands! The spine switch is running configuration your switch will not contain, but log in using `admin` and `enable` to start exploring.

1. Log in to the spine using the address below and the username `arista`, password `Arista!123`.

```
# Student 1
ssh arista@10.1.100.2
```

```
# Student 2
ssh arista@10.1.100.3
```

2. When you first connect to a switch, it's good practice to confirm you're on the right device and check the hardware and software details.

```
show version
```

Example Output

Example Output

```
Arista CCS-722XPM-48ZY8-F (1)
Hardware version: 11.01
Serial number: HBG23270736 (2)
Hardware MAC address: ac3d.9450.afc6
System MAC address: ac3d.9450.afc6

Software image version: 4.34.4M (3)
Architecture: i686 (4)
Internal build version: 4.34.4M-45127473.4344M
Internal build ID: 53161035-ed88-40a4-bd74-c8299d74e2f6
Image format version: 3.0
Image optimization: Strata-4GB

Uptime: 9 hours and 44 minutes (5)
Total memory: 3952756 kB
Free memory: 1712020 kB
```

1. The full switch model
2. The serial number of the switch
3. Current EOS image running
4. This EOS software is a 32-bit version, Arista EOS is also provided in a 64-bit version
5. The current uptime

8. Let's explore the hardware in a bit more detail. Text output is great, but imagine you've been asked to pull all device information programmatically. Tools like TextFSM are common for parsing unstructured data — wouldn't it be great if this data was already structured? Try running this command with the `json` pipe to see the difference.

```
show inventory
show inventory | json
```

Example Output

Example Output

```
System information
  Model                    Description
  ------------------------ ------------------------------------------------------
  CCS-722XPM-48ZY8         48 2.5GBase-T PoE & 8-port SFP28 MacSec Switch (1)

  HW Version  Serial Number  Mfg Date   Epoch
  ----------- -------------- ---------- -----
  11.01       HBG23270736    2023-07-14 01.00 (2)

System has 2 power supply slots
  Slot Model            Serial Number
  ---- ---------------- ----------------
  1    PWR-1021-AC-RED  GGJT36P13J0 (3)
  2    Not Inserted

System has 3 fan modules (4)
  Module  Number of Fans  Model            Serial Number
  ------- --------------- ---------------- ----------------
  1       1               FAN-7000-F       N/A
  2       1               FAN-7000-F       N/A
  3       1               FAN-7000-F       N/A

System has 57 ports
  Type               Count
  ------------------ ----
  Management         1
  Switched           52
  SwitchedBootstrap  4

System has 56 switched transceiver slots
  Port Manufacturer     Model            Serial Number    Rev
  ---- ---------------- ---------------- ---------------- ----
  1    Arista Networks  CCS-722XPM-48ZY8
  2    Arista Networks  CCS-722XPM-48ZY8
  ...
  49   Arista Networks  SFP-10G-SR       ACW1834004QE     20
  50   Not Present
  51   Not Present
  52   Not Present
  53   Arista Networks  SFP-10G-SR       XTH16080010E     0002 (5)
  54   Not Present
  55   Not Present
  56   Not Present

System has 1 storage device
  Mount      Type Model                Serial Number Rev Size (GB)
  ---------- ---- -------------------- ------------- --- ---------
  /mnt/flash eMMC Smart Modular 16GP1A 801f4198      1.0 8
```

(1) More information about this switch platform capabilities

2. You can see when this switch was manufactured and hardware versioning
3. Power supply details, like model and serial number
4. If you have fan modules, similar detail to that of power supplies
5. Get optics manufacturer, serial number, and model

14. Understanding what's connected to a switch is one of the first things you'll do when troubleshooting or onboarding a new device. Let's explore the interfaces.

What to look for

- Your pod has one connection to the spine (we're not in a full mesh)
- Workshop access point and raspberry pi (lab guides) are connected
- MLAG interfaces
- Your POD is configured as part of a Port-Channel

```
show interfaces status
```

Example Output

Example Output

```
Port       Name                      Status       Vlan     Duplex Speed  Type
Flags Encapsulation
Et1        POD01                     notconnect   trunk    auto   auto
2.5GBASE-T
Et2        POD02                     notconnect   trunk    auto   auto
2.5GBASE-T
Et3        POD03                     notconnect   trunk    auto   auto
2.5GBASE-T
Et4        POD04                     notconnect   trunk    auto   auto
2.5GBASE-T
Et5        POD5                      notconnect   trunk    auto   auto
2.5GBASE-T
Et6        POD06                     notconnect   trunk    auto   auto
2.5GBASE-T
Et7        POD07                     notconnect   trunk    auto   auto
2.5GBASE-T
Et8        POD08                     notconnect   trunk    auto   auto
2.5GBASE-T
Et9        POD09                     notconnect   trunk    auto   auto
2.5GBASE-T
Et10       POD10                     notconnect   trunk    auto   auto
2.5GBASE-T
Et11       POD11                     notconnect   trunk    auto   auto
2.5GBASE-T
Et12       POD12                     notconnect   trunk    auto   auto
2.5GBASE-T
Et13       POD13                     connected    trunk    a-full a-2.5G
2.5GBASE-T
Et14       POD14                     notconnect   trunk    auto   auto
2.5GBASE-T
Et15       POD15                     notconnect   trunk    auto   auto
2.5GBASE-T
...
Et33       ATD_WIFI                  connected    100      a-full a-2.5G
2.5GBASE-T
Et34       ATD_PI                    notconnect   100      auto   auto
2.5GBASE-T
...
Et47       MLAG_SPINE02_Ethernet47 connected    in Po47  a-full a-2.5G
2.5GBASE-T
Et48       MLAG_SPINE02_Ethernet48 connected    in Po47  a-full a-2.5G
2.5GBASE-T
...
Et53       TO_CORE_ETHERNET49        connected    routed   full   10G    10GBASE-
SR
...
Po47       MLAG_PEER_SPINE02_Po47  connected    trunk    full   5G     N/A
Po101      POD01                     notconnect   trunk    full   unconf N/A
Po102      POD02                     notconnect   trunk    full   unconf N/A
Po103      POD03                     notconnect   trunk    full   unconf N/A
Po104      POD04                     notconnect   trunk    full   unconf N/A
```

```
Po105      POD05                notconnect   trunk    full   unconf N/A
Po106      POD06                notconnect   trunk    full   unconf N/A
Po107      POD07                notconnect   trunk    full   unconf N/A
Po108      POD08                notconnect   trunk    full   unconf N/A
Po109      POD09                notconnect   trunk    full   unconf N/A
Po110      POD10                notconnect   trunk    full   unconf N/A
Po111      POD11                notconnect   trunk    full   unconf N/A
Po112      POD12                notconnect   trunk    full   unconf N/A
Po113      POD13                notconnect   trunk    full   unconf N/A
Po114      POD14                notconnect   trunk    full   unconf N/A
Po115      POD15                notconnect   trunk    full   unconf N/A
```

15. In a production network, show command output can be massive. EOS provides familiar filtering options like `include`, `exclude`, and `begin`, along with some unique ones we'll explore throughout the workshop.

> **Read Only Mode**
>
> You have read only on the spines, which excludes access to EOS' underlying Linux subsystem. You will have full access to this in the workshop, where you can leverage tools like `grep`, `awk`, `sed`, etc to filter content further.

```
show interfaces status | ?
show interfaces status | inc POD01
show interfaces | inc MTU|Eth
show interfaces | sec Ethernet(47|48)
```

Example Output

```
LINE      Filter command by common Linux tools such as grep/awk/sed/wc
append    Append redirected output to URL
begin     Start output at the first matching line
exclude   Do not print lines matching the given pattern
include   Print lines matching the given pattern
json      Produce JSON output for this command
no-more   Disable pagination for this command
nz        Include only non-zero counters
redirect  Redirect output to URL
section   Include sections that match
tee       Copy output to URL
```

16. Verifying IP addressing and gateway configuration is a common validation step after deploying or inheriting a switch. The spines act as the gateway for each pod, so let's confirm the addressing and virtual router configuration.

```
show ip interface brief
show ip virtual-router
```

Example Output

Example Output: interface brief

```
                                                                                Address
Interface       IP Address            Status     Protocol         MTU    Owner
--------------- --------------------- ---------- ------------ ---------- -------
Ethernet53      192.168.254.2/30      up         up              9214
Loopback0       192.168.253.2/32      up         up             65535
Management1     unassigned            down       down            1500
Vlan100         10.1.100.2/24         up         up              9214
Vlan101         10.1.1.2/24           up         up              9214
Vlan102         10.1.2.2/24           up         up              9214
Vlan103         10.1.3.2/24           up         up              9214
Vlan104         10.1.4.2/24           up         up              9214
Vlan105         10.1.5.2/24           up         up              9214
Vlan106         10.1.6.2/24           up         up              9214
Vlan107         10.1.7.2/24           up         up              9214
Vlan108         10.1.8.2/24           up         up              9214
Vlan109         10.1.9.2/24           up         up              9214
Vlan110         10.1.10.2/24          up         up              9214
Vlan111         10.1.11.2/24          up         up              9214
Vlan112         10.1.12.2/24          up         up              9214
Vlan113         10.1.13.2/24          up         up              9214
Vlan114         10.1.14.2/24          up         up              9214
Vlan115         10.1.15.2/24          up         up              9214
Vlan4094        169.254.0.0/31        up         up              9214
```

Example Output: virtual-router

```
IP virtual router is configured with MAC address: 001c.7300.0099
IP virtual router address subnet routes not enabled
IP router is not configured with Mlag peer MAC address
MAC address advertisement interval: 30 seconds

Protocol: U - Up, D - Down, T - Testing, UN - Unknown
        NP - Not Present, LLD - Lower Layer Down

Interface       Vrf           Virtual IP Address       Protocol       State
--------------- ------------- ------------------------ -------------- ------
Vl100           default       10.1.100.1/24            U              active
Vl101           default       10.1.1.1                 U              active
Vl102           default       10.1.2.1                 U              active
Vl103           default       10.1.3.1                 U              active
Vl104           default       10.1.4.1                 U              active
Vl105           default       10.1.5.1                 U              active
Vl106           default       10.1.6.1                 U              active
Vl107           default       10.1.7.1                 U              active
Vl108           default       10.1.8.1                 U              active
Vl109           default       10.1.9.1                 U              active
Vl110           default       10.1.10.1                U              active
Vl111           default       10.1.11.1                U              active
Vl112           default       10.1.12.1                U              active
```

```
Vl113           default       10.1.13.1             U              active
Vl114           default       10.1.14.1             U              active
Vl115           default       10.1.15.1             U              active
```

17. LLDP is invaluable for mapping physical topology. Let's also look at command aliases, which let you create shortcuts for frequently used commands.

```
show lldp neighbors detail
atdpods
show aliases
```

Example Output

Example Output: LLDP Detail

```
Last table change time   : 0:28:21 ago

Number of table inserts  : 6
Number of table deletes  : 1
Number of table drops    : 0
Number of table age-outs : 0

Port          Neighbor Device ID         Neighbor Port ID    TTL
--------- ------------------------- ---------------------- ---
Et13          sw-10.1.13.41              Ethernet15          120
Et33          arista-atd-ap01            3086.2d18.66bf      120
Et47          SPINE02.arista.local       Ethernet47          120
Et48          SPINE02.arista.local       Ethernet48          120
Et53          CORE01.arista.local        Ethernet49          120
```

Example Output: atdpods

```
Interface Ethernet13 detected 1 LLDP neighbors:
   - System Description: "Arista Networks EOS version 4.34.4M running on an
Arista Networks CCS-710P-16P"
Interface Ethernet33 detected 1 LLDP neighbors:
   - System Description: "ARISTA AP C-360 Version: 21.2.0F-33"
Interface Ethernet47 detected 1 LLDP neighbors:
   - System Description: "Arista Networks EOS version 4.34.4M running on an
Arista Networks CCS-722XPM-48ZY8"
Interface Ethernet48 detected 1 LLDP neighbors:
   - System Description: "Arista Networks EOS version 4.34.4M running on an
Arista Networks CCS-722XPM-48ZY8"
Interface Ethernet53 detected 1 LLDP neighbors:
   - System Description: "Arista Networks EOS version 4.34.4M running on an
Arista Networks CCS-720DP-48S-2"
```

Example Output: aliases

```
c               bash clear
```

18. When troubleshooting performance or verifying traffic flow, interface counters are your go-to. The `watch` command lets you monitor changes in real time, and the `nz` filter strips out interfaces with no activity to reduce noise.

```
show int counters rates
show int counters rates | nz
watch 1 diff show int counters rates | nz
```

19. Sometimes it's the little things that make a big difference! This was a brief introduction into the CLI. All features start in EOS, with respective show and configuration commands. We'll further explore the symbiotic relationship between EOS and CloudVision!

> **Wait! There's more!**
>
> If you're interested in exploring more fun EOS commands, we published the Arista EOS Tips for Network Operators. If you would like access, ask your Arista team for more information!
>
> There are many more commands like:
>
> - Configuration sessions
> - CLI command finder
> - Event handlers
> - Event monitor
> - Packet captures
> - Scheduler
> - Tech Support Bundles/Checkpoints
> - So much more

MLAG & VARP

Arista's Multi-Chassis Link Aggregation (MLAG) is a technology that allows two physical switches to act as a single logical switch. By syncing the control plane without the need for proprietary cabling or protocols, it provides an active-active, non-blocking redundancy between multiple pairs of switches.

Let's explore the configuration and how to troubleshoot.

1. From the switch, run the `show mlag` command to validate the high-level state.

```
show mlag
```

Example Output

Example Output

```
MLAG Configuration:
domain-id                          :               MLAG
local-interface                    :           Vlan4094
peer-address                       :        169.254.0.1
peer-link                          :     Port-Channel47
hb-peer-address                    :            0.0.0.0
peer-config                        :         consistent

MLAG Status:
state                              :             Active
negotiation status                 :          Connected
peer-link status                   :                 Up
local-int status                   :                 Up
system-id                          :   ae:3d:94:50:af:c6
dual-primary detection             :           Disabled
dual-primary interface errdisabled :              False

MLAG Ports:
Disabled                           :                 0
Configured                         :                 0
Inactive                           :                15
Active-partial                     :                 0
Active-full                        :                 0
```

2. You can also dive deeper using `show mlag detail`.

```
show mlag detail
```

Example Output

Example Output

```
...
MLAG Detailed Status:
State                              :             primary
Peer State                         :           secondary
State changes                      :                   2
Last state change time             :       10:00:15 ago
Hardware ready                     :                True
Failover                           :               False
Failover Cause(s)                  :             Unknown
Last failover change time          :               never
Secondary from failover            :               False
Peer MAC address                   :   ac:3d:94:50:d2:aa
Peer MAC routing supported         :                True
Reload delay                       :         300 seconds
Non-MLAG reload delay              :         330 seconds
Peer ports errdisabled             :               False
Lacp standby                       :               False
Configured heartbeat interval      :            4000 ms
Effective heartbeat interval       :            4000 ms
Heartbeat timeout                  :           60000 ms
Last heartbeat timeout             :               never
Heartbeat timeouts since reboot    :                   0
UDP heartbeat alive                :                True
Heartbeats sent/received           :          9043/9003
Peer monotonic clock offset        :   -0.321080 seconds
Agent should be running            :                True
P2p mount state changes            :                   1
Fast MAC redirection enabled       :                True
Peer-link forwarding restricted    :               False
Interface activation interlock     :       unconfigured
```

3. Let's look at the configuration that enables MLAG. Run the following command to show the MLAG configuration block.

```
show running-config section mlag configuration
```

Example Output

Example Output

```
mlag configuration
   domain-id MLAG (1)
   local-interface Vlan4094 (2)
   peer-address 169.254.0.1 (3)
   peer-link Port-Channel47 (4)
   reload-delay mlag 300
   reload-delay non-mlag 330
```

(1) MLAG domain is locally significant to the MLAG pair of switches, this can be any descriptor. Whether it's simply `MLAG` like shown or the name of say a pod: `POD01`

(2) The local interface used to peer to the MLAG neighbor, this will always be an SVI

(3) The MLAG neighbors address that resides within the `local-interface` subnet

(4) The peer link is the layer 2 port-channel used to trunk our MLAG vlans, we'll explore below how that's configured.

8. Let's take a closer look at the peer link itself.

```
show run interface Eth47-48; show run int Port-Channel47; show port-channel 47
detailed
```

Example Output

Example Output

```
!
interface Ethernet47
   description MLAG_SPINE02_Ethernet47
   channel-group 47 mode active
!
interface Ethernet48
   description MLAG_SPINE02_Ethernet48
   channel-group 47 mode active
!
interface Port-Channel47
   description MLAG_PEER_SPINE02_Po47
   switchport mode trunk
   switchport trunk group MLAG
!
Port Channel Port-Channel47 (Fallback State: Unconfigured):
Minimum links: unconfigured
Maximum links: unconfigured
Minimum speed: unconfigured
Current weight/Max weight: 2/8
  Active Ports:
     Port          Time Became Active    Protocol     Mode       Weight   State
    ------------- --------------------- ----------- ---------- ---------- -----
     Ethernet47    8:46:01               LACP         Active       1      Rx,Tx
     Ethernet48    8:46:01               LACP         Active       1      Rx,Tx
```

9. The port channel is using a `trunk group` — let's take a look.

Linux Sub-system

On top of the typical `includes`, `section`, `begin`, etc we commonly use to filter output. You also have access to many of the linux sub-system commands like `grep`, `sed`, `awk`, etc to filter and manipulate the output.

```
show vlan trunk group | grep -E "MLAG|Groups|-"
```

Example Output

```
VLAN     Trunk Groups
----
--------------------------------------------------------------------------------
4094     MLAG
```

10. Note that `Vlan 4094` is part of the trunk group. Trunk groups ensure that VLANs assigned to a trunk group are pruned from all interfaces except those explicitly configured. In this case, `Port-Channel47` is assigned the trunk group, so it's the only interface forwarding `Vlan 4094`.

11. Let's look at the peering SVI `Vlan4094`.

```
show running-config interfaces vlan 4094
```

Example Output: SPINE01

```
interface Vlan4094
   description MLAG_PEER
   no autostate (1)
   ip address 169.254.0.0/31 (2)
```

(1) We disable autostate to force the VLAN to be active

(2) This peering address is only locally significant, it's common to use an APIPA IP address range (/31) that's repeated across all MLAG pairs. The neighbor address is used in the mlag configuration to peer over the trunk.

14. In the previous `show mlag` output, we got a brief overview of status. During troubleshooting, there is a built-in command to ensure MLAG configuration parity between the two devices. Run the following command to validate that the configuration matches.

```
show mlag config-sanity
```

Example Output

```
No global configuration inconsistencies found.

No per interface configuration inconsistencies found.
```

15. Looking at the interfaces down to the pod, let's validate the interface configuration.

```
show run interface Ethernet 1-2
show run interface Port-Channel101
```

Example Output

Example Output

```
!
interface Ethernet1
   description POD01
   switchport mode trunk
   channel-group 101 mode active
   lldp tlv transmit ztp vlan 101
   poe disabled
!
interface Ethernet2
   description POD02
   switchport mode trunk
   channel-group 102 mode active
   lldp tlv transmit ztp vlan 102
   poe disabled
!
interface Port-Channel101
   description POD01
   switchport trunk allowed vlan 101,201
   switchport mode trunk
   port-channel lacp fallback individual
   port-channel lacp fallback timeout 20
   mlag 101
!
```

16. If we detect issues or want to verify the MLAG interfaces upstream/downstream are `up/up`, we can validate with the following command.

```
show mlag interfaces
```

Example Output

Example Output

```
                                                                local/remote
   mlag       desc           state       local       remote          status
---------- ----------- -------------- ----------- ------------ ------------
    101       POD01       inactive       Po101        Po101       down/down
    102       POD02       inactive       Po102        Po102       down/down
    103       POD03       inactive       Po103        Po103       down/down
    104       POD04       inactive       Po104        Po104       down/down
    105       POD05       inactive       Po105        Po105       down/down
    106       POD06       inactive       Po106        Po106       down/down
    107       POD07       inactive       Po107        Po107       down/down
    108       POD08       inactive       Po108        Po108       down/down
    109       POD09       inactive       Po109        Po109       down/down
    110       POD10       inactive       Po110        Po110       down/down
    111       POD11       inactive       Po111        Po111       down/down
    112       POD12       inactive       Po112        Po112       down/down
    113       POD13       inactive       Po113        Po113       down/down
    114       POD14       inactive       Po114        Po114       down/down
    115       POD15       inactive       Po115        Po115       down/down
```

17. Lastly, how do we maintain active/active forwarding with MLAG? This is where VARP comes in. A virtual router address and a common MAC is all it takes.

```
show run sec virtual-router
show ip virtual-router
```

Example Output

```
!
interface Vlan100
    ip virtual-router address 10.1.100.1/24
interface Vlan101
    ip virtual-router address 10.1.1.1 #(1)!
interface Vlan102
    ip virtual-router address 10.1.2.1
interface Vlan103
    ip virtual-router address 10.1.3.1
...
interface Vlan114
    ip virtual-router address 10.1.14.1
interface Vlan115
    ip virtual-router address 10.1.15.1
!
ip virtual-router mac-address 00:1c:73:00:00:99 #(2)!
!
```

```
IP virtual router is configured with MAC address: 001c.7300.0099
IP virtual router address subnet routes not enabled
IP router is not configured with Mlag peer MAC address
MAC address advertisement interval: 30 seconds

Protocol: U - Up, D - Down, T - Testing, UN - Unknown
        NP - Not Present, LLD - Lower Layer Down

Interface       Vrf           Virtual IP Address       Protocol       State
--------------- ------------- ------------------------ -------------- ------
Vl100           default       10.1.100.1/24            U              active
Vl101           default       10.1.1.1                 U              active
Vl102           default       10.1.2.1                 U              active
Vl103           default       10.1.3.1                 U              active
Vl104           default       10.1.4.1                 U              active
Vl105           default       10.1.5.1                 U              active
Vl106           default       10.1.6.1                 U              active
Vl107           default       10.1.7.1                 U              active
Vl108           default       10.1.8.1                 U              active
Vl109           default       10.1.9.1                 U              active
Vl110           default       10.1.10.1                U              active
Vl111           default       10.1.11.1                U              active
Vl112           default       10.1.12.1                U              active
Vl113           default       10.1.13.1                U              active
Vl114           default       10.1.14.1                U              active
Vl115           default       10.1.15.1                U              active
```

a. This is the virtual IP address configured on both MLAG pairs.

b. This vMAC will be used as the gateway vMAC associated with the Gateway VIP configured with either ip address virtual or ip virtual-router address (vARP). This vMAC will be consistent across all SVIs configured with a VIP.

18. That's it for this section! You should now have a better understanding of how MLAG is configured and how to troubleshoot it.

Bonus: Explore EOS

Streaming Telemetry

Let's take a look at the streaming telemetry agent that communicates back to CloudVision. You may not be able to do this on your switch (currently in zero-touch). Feel free to come back to this section to explore — your instructor will showcase this.

1. Let's view the telemetry agent daemon.

```
show running-config section TerminAttr
```

Example Output

```
daemon TerminAttr
   exec /usr/bin/TerminAttr
       -smashexcludes=ale,flexCounter,hardware,kni,pulse,strata
       -cvaddr=apiserver.cv-staging.corp.arista.io:443
       -cvauth=token-secure,/tmp/cv-onboarding-token
       -taillogs
       -disableaaa
   no shutdown
```

2. Now let's see this in action. Log in to CloudVision and navigate to `Devices > Inventory`.
3. Make a change to the hostname using a configuration session.

```
!
configure session namechange (1)
hostname SOMEONEWASHERE
!
show session-config diffs (2)
!
commit timer 00:05:00 (3)
```

(1) Create a configuration session, similar to branching in git, this will stage changes and wait for a commit to apply as a replace in configuration

(2) Show the differences of designed vs what's configured

3. Commit the configuration to roll back in 5 minutes (`hh:mm:ss`), if you do not commit after the fact, this will roll back.

Session Configuration Diff

```
SPINE01[16:13:56](config-s-namechange)#show session-config diffs
--- system:/running-config
+++ session:/namechange-session-config
-hostname SPINE01
+hostname SOMEONEWASHERE
```

7. You should see the hostname change immediately inside CloudVision! This is not a poll... this is a continuous stream of state from device to CloudVision.

Additional Fun Commands

There are a few other commands you can explore in your lab after deployment. As we move away from the CLI, remember all interactions with Arista EOS both via terminal or automation are leveraging the same commands.

Bash

Access to the underlying Linux system is available. Quick example is exploring the flash

```
bash
cd /mnt/flash/
ls -latr
```

Packet Capture

You have the ability to capture traffic, capturing control plane traffic or mirroring data plane to CPU.

```
bash
tcpdump -vvvnei et1
```

AAA Logs

Validate what commands have been run on the switch

```
show aaa accounting logs | tail
```

Configuration Session

Leverage a configuration session to stage config, commit as a full replace, and even configure a timed rollback.

```
configure session ATD
!
hostname IWASHERE
!
show session-config diffs
!
commit timer 00:00:30
!
show conf sessions
!
```

Additional References

- Streaming Telemetry
- CloudVision Tags

🎉 CONGRATS! You have completed this lab! 🎉

LET'S GO TO THE NEXT LAB!

2026-05-03