## Punto1

## Escala1

```
code12: 1606 | 011001000110

1.30

raw16: 25702 | 011001000110

code12: 1606 | 011001000110

1.30

raw16: 25702 | 011001000110

code12: 1606 | 011001000110

1.30
```

## Escala2

Consola ×		
COGE12: 203/	1	101100010101
2.30		
raw16: 45371		1011000100111011
code12: 2835		101100010011
2.30		
raw16: 45371	1	1011000100111011
code12: 2835		101100010011
2.30		

## Escala3

raw16: 59310 | 1110011110101110
code12: 3706 | 111001111010
3.00
raw16: 59310 | 1110011110101110
code12: 3706 | 111001111010
3.00