
## Resoluções Aula prática 3

Imagem de referência:



| Signal name | Effect when deasserted   | Effect when asserted  |
|-------------|--|---|
| RegDst      | The register destination number for the Write register comes from the rt field (bits 20:16). | The register destination number for the Write register comes from the rd field (bits 15:11).            |
| RegWrite    | None.  | The register on the Write register input is written with the value on the Write data input.             |
| ALUSrc      | The second ALU operand comes from the second register file output (Read data 2).             | The second ALU operand is the sign-<br>extended, lower 16 bits of the instruction.                      |
| PCSrc       | The PC is replaced by the output of the adder that computes the value of PC + 4.             | The PC is replaced by the output of the adder that computes the branch target.                          |
| MemRead     | None.  | Data memory contents designated by the address input are put on the Read data output.                   |
| MemWrite    | None.  | Data memory contents designated by the address input are replaced by the value on the Write data input. |
| MemtoReg    | The value fed to the register Write data input comes from the ALU.                           | The value fed to the register Write data input comes from the data memory.                              |

## Solução 4.1

Para todas as instruções os primeiros dois passos são idênticos:

- Enviar o PC à memória que contém o código e fazer fetch da instrução contida nessa memória.
- Ler um ou dois registos, utilizando os campos da instrução para selecionar os registos a ler. Para a instrução lw só precisamos de 1 registo, mas para a generalidade das instruções é preciso ler 2.

Após estes dois passos os passos dependem da instrução. As acções para cada tipo de instrução R, I e J são muito semelhantes. É de salientar a homogeneidade do Instruction Set como filosofia de desenvolvimento para facilitar a execução de muitas instruções semelhantes.

## 4.1.1. Considerações

Os sinais de controlo que temos que considerar são:

| Instruction | RegDst | ALUSrc | MemtoReg | RegWrite | MemRead | MemWrite |
|-------------|--------|--------|----------|----------|---------|----------|
| R-format    | 1      | О      | О        | 1        | О       | o        |
| lw          | 0      | 1      | 1        | 1        | 1       | О        |
| SW          | X      | 1      | Х        | 0        | 0       | 1        |
| beq         | X      | 0      | Х        | 0        | 0       | О        |

## 4.1.2. Considerações

Podemos considerar como unidades funcionais a memória (dados e instruções), o banco de registos, o PC a ALU e eventualmente ALU específica de adição **conforme a figura 4.1**.

A instrução and é uma instrução tipo R logo aplicam-se os mesmos princípios que a instrução add estudada na aula teórica. Assim as unidades funcionais são o *Banco de registos* (register file) e a *ALU* conforme o slide apresentado na teórica e a figura 4.7. Como é lógico, o PC e a memória (instruções) estão envolvidos em qualquer instrução.

