StatViewer 1

About Views 2
Run mode vs. Design mode 3

Run mode 3
Design mode 4

View Types 5
Using the Scale Controls 7
Mouse-over 9
Dragging and Docking Views 10
Dragging a View to a Separate Window 10
Returning a View to the Main Window 11
Docking a View Along the Left or Right Border 12
Docking a View Along the Bottom Border 15
Designing Views 18
Displaying the Design Controls 19
Adding a View 19
Editing a View 23
Deleting a view 23
Adding a Statistic 24
Event Log 28
Setting the Logging Level 28
Exporting the Event Log 28
Clearing the Event Log 28
Refreshing the Event Log 29
Setting the Event Log Properties 29