Simulating the 5G NR PDSCH with Multi-Process HARQ

In the previous lab, we created a simple frequency-domain channel along with a gNB TX and UE RX to simulate the downlink data processing. In this lab, we will build on the results in that lab to add multi-process Hybrid ARQ. The MATLAB's 5G Toolbox has excellent tools to simulate complete 5G NR HARQ processes.

In going through the lab, you will learn to:

- Create PDSCH allocations for a subset of the RBs
- Measure the time-varying wideband SNR and the SNR on a subset of the resource blocks (RBs)
- Encode and decode data with HARQ using MATLAB 5G Toolbox tools
- Create a simple multi-process TX and RX
- Evaluate the performance of the link with HARQ on a fading channel

Some of the code in this lab is based on MATLAB's PDSCH throuhput demo. You will need to get the R2020B version of MATLAB's 5G Toolbox for the demo. The Toolbox is rapidly evolving, and I have used some functions that are not available in R2020A. Also, along with this file, you will see three other files:

- FDChan.m: A class for frequency-domain channel simulation
- NRgNBTxFD.m: A class for NR gNB TX frequency-domain simulation
- NRUERxFD.m: A class for NR UE RX frequency-domain simulation

These files have some TODO sections to be completed.

Submission: Complete this MATLAB live file and the other files. Run the code. Print all the files to PDF. Merge to a single PDF and submit the PDF for grading.

Configuring the System Prameters

In this lab, we will configure the parameters with the following parameters.

Using the SCS and number of resource blocks, compute and print the bandwidth occupied by this waveform.

```
% TODO:
bwMHz = NRB*nscPerRB*SubcarrierSpacing/1e3;
fprintf(1, 'The bandwidth in [MHz] = %.2f\n', bwMHz);
The bandwidth in [MHz] = 9.18
```

Similar to the previous lab, get the carrierConfig and waveformConfig with the nrCarrierConfig and nrOFDMInfo methods in the 5G Toolbox.

```
% TODO
carrierConfig = nrCarrierConfig("NSizeGrid",NRB,"SubcarrierSpacing",SubcarrierSpacing);
```

Configuring a Frequency-Domain OFDM Channel

We will simulate the channel with the following paths.

- npaths=10 paths
- Set the gain so that they all have 0 dB relative gain
- Set dly so that the path delays are exponentially distributed with mean 50ns
- Set aoaAz to have paths with uniform angles from [0,360] degrees
- Set aoaE1 to have uniform angles from [-20,20] degrees

```
% Number of paths
npaths = 10;

% TODO: Set parmaeters for each path
gain = zeros(npaths,1);
dly = exprnd(50e-9,npaths,1);
aoaAz = rand(npaths,1)*360;
aoaEl = -20 + 40*rand(npaths,1);
```

Once you create these paths, you can create a frequency-domain channel using the FDChan object I have included.

Simulating the Frequency-Domain Channel

The frequency-domain channel has the identical syntax as the the previous lab as well as the demo. We first observe one realization of the channel in one slot.


We first create a grid of TX symbols. For now, we will just set them all to ones.

```
NumLayers = 1;
txGrid = nrResourceGrid(carrierConfig, NumLayers);
txGrid(:) = 1;
```

Set the frameNum=0 and slotNum=0 and call the fdchan.step() method to get the channel grid and noise variance. Compute a channel SNR matrix, chanSnr(i,j) representing the SNR in dB per RE. Plot chanSnr with the imagesc command. You should see some frequency selective fading. But, minimal fast fading.

```
frameNum = 0;
slotNum = 0;

% TODO:
[~, chanGrid, noiseVar] = fdchan.step(txGrid, frameNum, slotNum);
figure;
imagesc(1:carrierConfig.SymbolsPerSlot, 1:NRB*nscPerRB, pow2db(abs(chanGrid).^2/noiseVar));
ylabel("Subcarrier Number"); xlabel("Symbol Number");
title("Channel SNR [dB]");
colorbar();
```



Examining the Channel on a PDSCH With a Limited Frequency-Domain Allocation

We introduced PDSCH allocations in the previous lab. An additional feature of PDSCH allocations is that they can be on a subset of the RBs. This sort of allocation is often necessary if the gNB needs to schedule multiple UEs in the same time slot. In this section, we consider PDSCH allocations on a set of contiguous RBs:

```
ind,...,ind+NRBPdsch-1
```

where

NRBPdsch = 20;


Before we configure this PDSCH, complete the following code to compare how the channel SNR varies over this time in the whole band, and in the PDSCH allocation. Specifically, we run a simulation of the frequency-domain channel over slots islot=1,...,nslots. For each slot, we compute:

- chanSnrWideband(islot) = average SNR across the whole band
- chanSnrPdschFix(islot) = average SNR across PDSCH allocation with a fixed starting index, ifix=0.
- chanSnrPdschRnd(islot) = average SNR across PDSCH allocation with a random starting index,
 irnd.

You should see that there the fixed PDSCH allocation has more overall variability since it is on a smaller bandwidth. The random allocation has the same total variability but fluctuates more from one slot to the next. This property is useful for diversity.

```
% Number of slots for the simulation
nslots = 100;
% SNR measurements per slot
chanSnrWideband = zeros(nslots,1);
                                       % Avg SNR across the whole band
                                       % Avg SNR across a fixed PDSCH allocation
chanSnrPdschFix = zeros(nslots,1);
chanSnrPdschRnd = zeros(nslots,1);
                                       % Avg SNR across a random PDSCH allocation
for islot = 1:nslots
    % TODO: Get the slot and frame number
    slotNum = mod(islot-1, carrierConfig.SlotsPerFrame);
    frameNum = floor((islot-1)/carrierConfig.SlotsPerFrame);
    % TODO: Get the channel and noise variance in the slot
    [~, chanGrid, noiseVar] = fdchan.step(txGrid, frameNum, slotNum);
   % TODO: Compute the average SNR in the channel
    chanSnr = mean(abs(chanGrid).^2/noiseVar, 2);
    % Set the fixed allocation to start an PRB index = 0
    ifix = 0:
   % TODO: Select a random start index for the random allocation
         irnd = 0,..., NRB-NRBPdsch-1
    irnd = randi([0 NRB-NRBPdsch-1],1,1);
   % TODO: Compute the average SNR over the full band,
   % the average SNR on a fixed PDSCH allocation and
    % the average SNR on a random PDSCH allocation.
    chanSnrWideband(islot) = mean(chanSnr);
    chanSnrPdschFix(islot) = mean(chanSnr(ifix+1:NRBPdsch*nscPerRB));
    chanSnrPdschRnd(islot) = mean(chanSnr(irnd*nscPerRB+1:irnd*nscPerRB+NRBPdsch*nscPerRB));
end
% Convert to dB
chanSnrWideband = pow2db(chanSnrWideband);
chanSnrPdschFix = pow2db(chanSnrPdschFix);
```

```
chanSnrPdschRnd = pow2db(chanSnrPdschRnd);
% TODO: Plot the SNR vs. time in seconds.
figure;
numFrames = nslots/carrierConfig.SlotsPerFrame;
t = linspace(0,numFrames*10e-3,nslots);
plot(t,chanSnrWideband,'LineWidth',2); hold on;
plot(t,chanSnrPdschFix,'LineWidth',2); hold on;
plot(t,chanSnrPdschRnd,'LineWidth',2); hold off;
xlabel("Time [s]"); ylabel("SNR [dB]"); grid on;
legend("Wideband SNR","PDSCH SNR fixed","PDSCH SNR random","Location","southeast");
```



Building the TX with HARQ

To make the simulation simple, we will look at a fixed PDSCH allocation. However, you would get slightly better performance with a randomized allocation. We will mostly use the same parameters as the previous lab. The only difference is that we have allocated only the the RBs (0:NRBPdsch-1).

```
Modulation = '16QAM';
targetCodeRate = 490/1024;
pdschConfig = nrPDSCHConfig(...
   'Modulation', Modulation, ...
   'PRBSet', (0:NRBPdsch-1), ...
   'SymbolAllocation', [1, waveformConfig.SymbolsPerSlot-1], ...
   'EnablePTRS', 1,...
   'PTRS', nrPDSCHPTRSConfig());
```

I have created a simple TX with HARQ in the file, NRgNBTxFd.m. It is mostly the same as the previous lab. It requires some small changes to support multiple HARQ processes. The 5G Toolbox has incredible tools to manage the multiple HARQ processes.

Note: I have used the indexing iharq=1,...,nharq. But, many of the 5G Toolbox tools use zero indexing. So you will need to use iharq-1.

```
% TODO: Complete the sections labeled TODO in NRgNBTxFD.m
```

Once you have finished the modifications, you can create the class with the following command.

```
% number of HARQ processes
nHarq = 8;
tx = NRgNBTxFD(carrierConfig, pdschConfig, 'targetCodeRate', targetCodeRate, 'nharq', nHarq);
```


You can then call the step method to generate random bits for one slot of data based on the PDSCH configuration. The input is the HARQ process ID you want to use for that slot. Here we use the first HARQ process.

```
iharq = 1;
[txGrid, rv, newDat] = tx.step(iharq);
```

Use the imagesc command to plot the set of resource elements in the grid where txGrid is non-zero. These are the resource elements (REs) where the PDSCH channel is allocated. You should see that the PDSCH is allocated to the top

- The first OFDM symbol. This is where the assignment channel, called the PDCCH, will go. Basically this communicates to the UEs the resource allocation, UE identity in that slot. We will discuss
- The third OFDM symbol. which is used as demodulation reference signal (DM-RS) used in channel estimation. We will discuss this when we discuss equalization
- The horizontal strips. These are PT-RS for phase noise mitigation that we will also discuss later.

```
% TODO
figure;
imagesc(abs(txGrid)~=0);
ylabel("Subcarrier Number"); xlabel("Symbol Number");
title("Non-zero Resource Grid");
colorbar();
```



Building a Simple HARQ RX

Next, complete the code in NRUERxFD.m. Again, I have created a skeleton that does almost all the work using the 5G Toolbox methods. It also follows the structure of the previous lab closely.

```
% TODO: Complete the sections labeled TODO in NRUERxFD.m
```

Running a HARQ Simulation

We can now run a simple HARQ simulation. Complete the following code.

```
% TODO: Create the RX and TX
rx = NRUERxFD(carrierConfig, pdschConfig, 'targetCodeRate', targetCodeRate, 'nharq', nHarq);
tx = NRgNBTxFD(carrierConfig, pdschConfig, 'targetCodeRate', targetCodeRate, 'nharq', nHarq);
```

```
dataRate = zeros(nslots,1);
chanSnrPdsch = zeros(nslots,1);
chanSnrWideband = zeros(nslots, 1);
nharq = 8;
% Loop over the slots
for islot = 1:nslots
    % Set the HARQ process ID. We will use a round-robin selection
    iharq = mod(islot-1, nharq) + 1;
   % TODO: Run the transmitter for one slot
    [txGrid, rv, newDat] = tx.step(iharq);
    % TODO: Get the slot and frame number
    slotNum = mod(islot-1, carrierConfig.SlotsPerFrame);
    frameNum = floor((islot-1)/carrierConfig.SlotsPerFrame);
   % TODO: Run the channel
    [rxGrid, chanGrid, noiseVar] = fdchan.step(txGrid, frameNum, slotNum);
   % TODO: Run the data through the receiver
    rx.step(rxGrid,chanGrid,noiseVar,iharq,rv,newDat);
   % Check if data passed
    nerr = sum(rx.rxBits ~= tx.txBits{iharq}{1});
   % If there are on errors
    if nerr == 0
       % Simulate an ACK being sent back to the TX
       tx.setAck(iharq);
       % TODO: Compute data rate for the slot
        rxData = rx.rxBits;
        dataRate(islot) = length(rxData)/1e-3; % numerology 0 (SCS 15 KHz) --> slot duration 1
    end
    chanSnr = mean(abs(chanGrid).^2/noiseVar, 2);
    % TODO: Compute the average SNR in the slot
    chanSnrWideband(islot) = mean(chanSnr);
    chanSnrPdsch(islot) = mean(chanSnr(round(pdschConfig.PRBSet)+1));
chanSnrPdsch = pow2db(chanSnrPdsch);
txData = tx.txBits;
```

Plot the Results

Create two subplots:


- On the top subplot, plot chanSnrPdsch vs. time in seconds
- On the bottom subplot, plot the instantaneous data rate, dataRate along with a time average data rate. The time averaged should be a moving window of 16 slots.

```
% TODO
numFrames = nslots/carrierConfig.SlotsPerFrame;
t = linspace(0,numFrames*10e-3,nslots);

dataRate_Mbps = dataRate / 1e6;
avg_dataRate = movmean(dataRate_Mbps, 16);
```

```
figure;
subplot(2,1,1);
plot(t,chanSnrPdsch,'LineWidth',2);
xlabel("Time [s]"); ylabel("SNR [dB]"); grid on;
legend("PDSCH SNR","Location","southeast");

subplot(2,1,2);
plot(t,dataRate_Mbps, 'LineWidth',2); hold on;
plot(t,avg_dataRate, 'LineWidth',2);
xlabel("Time [s]"); ylabel("Rate [Mbps]"); grid on;
legend("Instantaneous","Average");
hold off;
```



```
classdef NRgNBTxFD < matlab.System</pre>
   % 5G NR gNB transmitter class implemented in frequency domain
    properties
       % Configuration
        carrierConfig;  % Carrier configuration
                       % PDSCH configuration
        pdschConfig;
       % Transport block data for last transmission
        targetCodeRate = 490/1024; % Target code rate
        trBlkSizes;
                                    % Transport block size
       % DLSCH encoder
        encDLSCH;
       % HARQ Process
                       % number of HARQ processes
        nharq = 8;
       \% RV sequence. This is the sequence that the TX will cycle
       % through in the RVs
       rvSeq = [0,3,2,1]';
       % TX parameters per HARQ process
        rvInd; % Index of the RV for the current transmission
        newDataAvail; % If HARQ process can take new data
        txBits;
                      % Cell array of TX bits
    end
    methods
        function obj = NRgNBTxFD(carrierConfig, pdschConfig, ...
                varargin)
            % Constructor
            % Save the carrier and PDSCH configuration
            obj.carrierConfig = carrierConfig;
            obj.pdschConfig = pdschConfig;
            % Set parameters from constructor arguments
            if nargin >= 1
                obj.set(varargin{:});
            end
            % Create DLSCH encoder system object
            obj.encDLSCH = nrDLSCH('MultipleHARQProcesses', true, ...
                'TargetCodeRate', obj.targetCodeRate);
            % Initialize the HARQ process parameters
            obj.rvInd = zeros(obj.nharq, 1);
            obj.newDataAvail = ones(obj.nharq,1);
            % TX bits for each HARQ process
            obj.txBits = cell(obj.nharq,1);
        end
         function setAck(obj, iharq)
            \% Set that the HARQ transmission was received correctly
            obj.newDataAvail(iharq) = 1;
```

```
end
end
methods (Access = protected)
    function [txGrid, rv, newDat] = stepImpl(obj, iharq)
       % step implementation. Creates one slot of samples for each
       % component carrier
       % Parameters
       % iharq: HARQ process index to use
       % Returns:
       % -----
       % txGrid: OFDM grid of transmitted symbols
       % rv: Redundancy version for the data
       % newDat: If new data was transmitted in this slot
       % Create the OFDM grid representing the array of modulation
       % symbols to be transmitted
       txGrid = nrResourceGrid(obj.carrierConfig, ...
           obj.pdschConfig.NumLayers);
       % Get indices on where the PDSCH is allocated
       [pdschInd,pdschInfo] = nrPDSCHIndices(obj.carrierConfig, obj.pdschConfig);
       if obj.newDataAvail(iharq)
            % If new data can be transmitted in the HARQ process
            % Compute the extra overhead from the PT-RS
           Xoh PDSCH = 6*obj.pdschConfig.EnablePTRS;
            % Calculate the transport block size based on the PDSCH
            % allocation and target code rate
            obj.trBlkSizes = nrTBS(obj.pdschConfig.Modulation,obj.pdschConfig.NumLayers,...
                numel(obj.pdschConfig.PRBSet),pdschInfo.NREPerPRB,...
                obj.targetCodeRate,Xoh_PDSCH);
            % Generate random bits for each codeword and set the transport
            % block
            obj.txBits{iharq} = cell(obj.pdschConfig.NumCodewords, 1);
            for icw = 1:obj.pdschConfig.NumCodewords
                % TODO: Create random bits for each codeword
                obj.txBits{iharq}{icw} = randi([0 1], obj.trBlkSizes(icw), 1);
               % TODO: Set the transport block to be encoded
                obj.encDLSCH.setTransportBlock(obj.txBits{iharq}{icw},icw-1,iharq-1)
               % You will need to pass the codeword index, icw-1,
               % and HARQ process ID, iharq-1
            end
            % Set the RV index to zero on the first transmission
            obj.rvInd(iharq) = 0;
            % Clear new data flag
            obj.newDataAvail(iharq) = 0;
```

```
% Mark that the data
            newDat = true;
        else
            % Mark that this data is a re-transmission
            newDat = false;
        end
        % TODO: Get the redundancy version from the current redundancy
        % version index, obj.rvInd(iharq). The rv should be
        irv = mod(obj.rvInd(iharq),4);
        rv = obj.rvSeq(irv+1);
        % where irv cycles, 0,1,2,3,0,1,2,3,...
        % Encode the DL-SCH transport block
        codedTrBlock = obj.encDLSCH(obj.pdschConfig.Modulation, ...
            obj.pdschConfig.NumLayers, pdschInfo.G, rv, iharq-1);
        % Increment the RV sequence
        obj.rvInd(iharq) = obj.rvInd(iharq) + 1;
        % Modulate the PDSCH modulation
        pdschSymbols = nrPDSCH(obj.carrierConfig, obj.pdschConfig, ...
            codedTrBlock);
        % Map the modulated symbols to the OFDM grid
        txGrid(pdschInd) = pdschSymbols;
    end
end
```

```
Not enough input arguments.

Error in NRgNBTxFD (line 34)

obj.carrierConfig = carrierConfig;
```

Published with MATLAB® R2020b

end

```
classdef NRUERxFD < matlab.System</pre>
   % 5G NR UR receiver class implemented in frequency domain
   properties
       % Configuration
       carrierConfig;  % Carrier configuration
       waveformConfig;  % Waveform config
       % OFDM grid
       rxGrid;
       % Transport block data for last transmission
       targetCodeRate = 490/1024; % Target code rate
       trBlkSizes;
                                   % Transport block size
       % Received data in last slots
       pdschEq;
                  % Equalized PDSCH symbols
       rxBits;
                    % RX bits
       % DLSCH decoder
       decDLSCH;
       % HARQ Process
       nharq = 8;
                       % number of HARQ processes
       % RV sequence. This is the sequence that the TX will cycle
       % through in the RVs
       rvSeq = [0,3,2,1]';
       % TX parameters per HARQ process
       TBId; % ID of the last TX packet
       rvInd; % Index of the RV for the current transmission
       newDataAvail;  % If HARQ process can take new data
                      % Cell array of TX bits
       txBits;
   end
   methods
       function obj = NRUERxFD(carrierConfig, pdschConfig, ...
               varargin)
           % Constructor
           % Save the carrier and PDSCH configuration
           obj.carrierConfig = carrierConfig;
           obj.pdschConfig = pdschConfig;
           % Create the waveform configuration from the carrier
           % configuration
           obj.waveformConfig = nrOFDMInfo(obj.carrierConfig);
           % Set parameters from constructor arguments
           if nargin >= 1
               obj.set(varargin{:});
           end
           % Create DLSCH decoder
           obj.decDLSCH = nrDLSCHDecoder('MultipleHARQProcesses', true, ...
               'TargetCodeRate', obj.targetCodeRate, ...
                'LDPCDecodingAlgorithm', 'Layered belief propagation');
```

```
end
end
methods (Access = protected)
    function stepImpl(obj, rxGrid, chanGrid, noiseVar, ...
            iharq, rv, newDat)
       % Demodulates and decodes one slot of data
       % Parameters
       % -----
       % iharq: HARQ process ID
       % rv: Rendundancy version
       % newData: If data is new
       % Note that the last three parameters would normally be
       % sent on the PDCCH
       % Get PDSCH received symbols and channel estimates
       % from received grid
       [pdschInd,pdschInfo] = nrPDSCHIndices(...
            obj.carrierConfig, obj.pdschConfig);
        [pdschRx, pdschHest] = nrExtractResources(pdschInd, rxGrid,...
            chanGrid);
       % Perform the MMSE equalization using the
       % nrEqualizeMMSE() function
        [obj.pdschEq,csi] = nrEqualizeMMSE(pdschRx,pdschHest,noiseVar);
       % TODO: Get the LLRs with the nrPDSCHDecode() function.
       % Use carrier and PDSCH configuration, the equalized symbols,
       % and the noise variance, noiseVar.
       [dlschLLRs,rxSym] = nrPDSCHDecode(obj.carrierConfig,obj.pdschConfig,obj.pdschEq, noiseVar);
       % Scale LLRs by EbN0.
       % The csi value computed in the nrEqualizeMMSE()
       % function is csi = |pdschHest|^2 + noiseVar.
       % Also, the Eb/N0 = snrEq/Qm where Qm is the number of bits
       % per symbol and snrEq is the SNR after equalization,
       %
           snrEq = (|pdschHest|^2 + noiseVar)/noiseVar = csi/noiseVar
       % Hence, Eb/N0 = csi/(noiseVar*Qm).
       % Since the LLRs from the nrPDSCHDecode function are
       % already scaled by 1/noiseVar, we multiply them by csi/Qm.
       csi = nrLayerDemap(csi); % CSI layer demapping
       numCW = length(csi);
       for cwIdx = 1:numCW
            Qm = length(dlschLLRs{cwIdx})/length(rxSym{cwIdx}); % bits per symbol
            csi{cwIdx} = repmat(csi{cwIdx}.',Qm,1);  % expand by each bit per symbol
            dlschLLRs{cwIdx} = dlschLLRs{cwIdx} .* csi{cwIdx}(:);  % scale
       end
       % Compute the extra overhead from the PT-RS
       Xoh_PDSCH = 6*obj.pdschConfig.EnablePTRS;
       % Calculate the transport block size based on the PDSCH
       % allocation and target code rate
```

```
obj.trBlkSizes = nrTBS(obj.pdschConfig.Modulation,obj.pdschConfig.NumLayers,...
                numel(obj.pdschConfig.PRBSet),pdschInfo.NREPerPRB,...
                obj.targetCodeRate,Xoh_PDSCH);
            obj.decDLSCH.TransportBlockLength = obj.trBlkSizes;
            % Reset the soft buffer for all codewords
            if newDat
                for cwIdx = 1:numCW
                    obj.decDLSCH.resetSoftBuffer(cwIdx, iharq-1);
                end
            end
            % TODO: Decode the bits with the obj.decDLSCH() method.
            % Use the scaled LLRs from above.
            obj.rxBits = obj.decDLSCH(dlschLLRs,obj.pdschConfig.Modulation,...
                                      obj.pdschConfig.NumLayers,rv,iharq-1);
        end
    end
end
```

```
Not enough input arguments.

Error in NRUERxFD (line 44)

obj.carrierConfig = carrierConfig;
```

Published with MATLAB® R2020b