All models

Special tools



•	~	1	L
۱	J	t	l

Hydraulic fluid

MB part no. 000 989 91 03/10 Refer to Factory Approved Service Products list


Note: Check fluid level with engine off. Correct if necessary.


With system in operating condition, the oil level should be between the MAX. and MIN. marks.


With vehicle loaded the resulting oil level will be near the MIN. mark (or below on vehicles with small reservoirs.)

Remove cap with integral dipstick front fluid reservoir. Read fluid level after wiping and reinserting dipstick.

Use filter funnel (060) to add fluid.







Model 123, 126 (1st version up through 08.1985) Plastic fluid reservoir


- 2 Fluid reservoir
- 2a Cap with integral dipstick.
- a Max. mark
- b Min. mark
- C Return line, level control reservoir.


Model 126 (2nd version as of 09.1985) Plastic fluid reservoir

- 2 Fluid reservoir
- 2a Cap with integral dipstick.
- a Max. mark
- b Min. mark
- C Return line, level control reservoir.

Model 124, 201 Plastic fluid reservoir

- Fluid reservoir
- 2a Cap with integral dipstick.
- а Max. mark
- Min. mark b
- C Return line, level control reservoir.





Model 124 with 4MATIC or ASD


- Fluid reservoir
- 2a Cap with integral dipstick.
- Max. mark
- Min. mark
- E1 Return line, hydraulic unit (connection T) -fluid reservoir
- E2 Without level control:

Return line, hydraulic unit (connection N) -fluid reservoir With level control:

Return line level control - fluid reservoir



- 2 Fluid reservoir
- 2a Cap with integral dipstick.
- Max. mark
- Min. mark



Model 140

- 2 Fluid reservoir
- 2a Cap with integral dipstick.
- a. Max. mark
- b Min. mark

Model 201.034 Light alloy reservoir

- 2 Fluid reservoir
- 2a Cap with integral dipstick.
- a. Max. mark
- b Min. mark

