

## Wiring diagram 2nd version

82-780

- Electronic interval rewiper backdoor

- Wiper motor, backdoor
  Washer pump, backdoor
  Detent switch wiper motor backdoor
  Detent switch interval wiper, backdoor
  Detent switch dome lamp rear
- Tipping switch washer pump, backdoor 8-point line connector above backdoor
- Fuse terminal 15
- To dome lamp rear
- Main ground behind instrument cluster Ground, luggage compartment wheelhouse right Ground, backdoor (8-point line connector) M2 M8 M9