3.1 QUICK REFERENCE GUIDE TO SUBROUTINES

a) Routines which input from the keyboard only:
```
    KBD                     Keyboard driver
    RKBD (NAS-SYS 3 only) Keyboard driver  with repeat key
```

b) Routines which output to the video display only:
```
    CRT                     Video display driver
```

c) Routines which input from the screen only:
```
    CPOS
    RLIN
```

d) Routines which input from the serial port only:
```
    SRLIN                   Serial input driver
    XKBD                    External keyboard driver
```

e) Routines which output to the serial port only:
```
    SOUT
    SRLX                    Serial output driver
    XOUT
```

f) Routines for user-defined input/output:
```
    $UIN
    $UOUT
```

g) Routines which input from devices in the input table:
```
    BLINK
    IN
    INLIN
    RIN
```

h) Routines which output to devices in the output table:
```
    B1HEX
    B2HEX
    CRLF
    ERRM
    PRS
    ROUT
    SPACE
    SP2 (NAS-SYS 3 only)
    TBCD2
    TBCD3
    TX1
```

i) Routines which call other routines:
```
    ATE
    RCAL
    SCAL
    SCALI (NAS-SYS 3 only)
    SCALJ
    START
```

A Guide to NAS-SYS

j) Routines which alter the input/output tables:
    NIM
    NOM
    NNIM
    NNOM

k) Routines which generate delays:
    RDEL
    TDEL

l) Routines which alter bits of output port 0:
    FFLP
    MFLP

m) Other routines:
    ARGS
    BRKPT
    NUM
    MRET
    STMON