Region E · label side (F.Cu)



TP7
GND

TP8
RS485 A

TP9
RS485 B

TP10
GND

TP11
RS485 A

TP12
RS485 B

TP13
+3.3V

TP14
+5V

Markers show TP reference numbers; the matching labels identify each signal.

Surface-mount service pads; these are not through holes.