


J1 · MOTOR POWER OUT
Direct PD rail and common GND

J3 · PD POWER IN
USB-C power supply

J5 · USB-C PROG
Computer / programming

J2 · RS485 / AUX
Signal names are printed beside all eight contacts.

S2 · PROG / BOOT
Hold during reset to program

Antenna socket
On the U7 module

S1 · RESET
Resets the ESP32-S3

D4 · POWER / yellow
Logic power indicator

U7 · ESP32-S3-MINI-1U

COMPONENT SIDE (B.Cu) · USB sockets at left · J2 header at right