

MUSIC MENTOR

1. Make sure your computer is switched off.
2. Insert your MUSIC MENTOR cartridge by firmly pushing it down into the Spectra-video's top-loading port.
3. Turn your computer on.

The MUSIC MENTOR landscape will now appear on the screen accompanied by music.

Press any key to move on.

"Type your name and press enter" will appear on the screen.

Type in your name and press the enter key.

A piano keyboard will appear on the screen with your name underneath.

A choice of three modes now appears on the screen:

F1 Piano Mode

F2 Replay Mode

F3 Record Mode

By pressing one of the function keys (F1, F2 or F3) you can select any of these modes.

PIANO MODE

Selecting F1 turns your Spectravideo into an electronic organ.

You can select various Rhythms by pressing F1 which will take you to the Rhythm Menu by pressing the appropriate function key at the top of your Spectravideo's keyboard.

You can select various instruments by pressing F2 which will take you to the Instrument Menu by pressing the appropriate key at the top of your Spectravideo's keyboard.

You can select various Octaves by pressing F3 which will take you to the Octave Menu by pressing the appropriate key at the top of your Spectravideo's keyboard.

You can select various Tempos by pressing F4 which will take you to the Tempo Menu by pressing the appropriate function key at the top of your Spectravideo's keyboard.

You are now ready to play the Spectravideo keyboard just like an electronic piano or organ. As you press the keys the Keys on the screen will light up to indicate the note which you have played.

REPLAY MODE

Selecting F2 turns your Spectravideo into an automatic electronic 'player' piano.

You can reply any of three tunes, two of which are built-in or one that you have entered yourself. The two built-in tunes are 'TURKEY IN THE STRAW' and 'THE BLUE DANUBE'. (Read about storing your own composition in the next section).

The rhythm, tempo, instrument or octave can be changed at any stage whilst the song is being played, by pressing the appropriate function key as in the Piano mode. Pressing the "ins/paste" key commences play while the stop key changes the mode.

RECORD MODE

Selecting F3 turns your Spectravideo into a 'tune recorder'.

You first set up your tempo, instrument, octave and rhythm (as you did when you used the piano mode) as you desire and then press the "ins/paste" key to start recording your masterpiece.

When you have completed your own composition press the "ins/paste" key to finish.

If you wish to replay your tune use the **REPLAY MODE** which we have discussed above.