

CONTENTS OF SPECTRA TYPE

1. Program cassette contains the following programs:
 - i) Main program "TYPE", located at position # 002" on your tape counter.
 - ii) Sample lesson file "MA/INW", located at position # 018" on your tape counter.
2. This instruction sheet.

ADDITIONAL EQUIPMENT OR SUPPLIES NEEDED

Blank cassette. This is needed for storing your lesson files so that you will have permanent record.

PRELIMINARY

1. Read the booklet that accompanies the SpectraVideo Data Cassette Recorder and become familiar with its use. Also read the manual that accompanied your SpectraVideo Computer.
2. Hook up the recorder to your SV-318/328 via the permanently attached cable.
3. Hook up your computer to TV or monitor.
4. Insert program cassette into your Data Cassette Recorder, rewind tape completely, and set tape counter to zero. Press stop on recorder.

5. Now read this instruction manual thoroughly.

SPECTRATYPE is a typing tutorial program designed to be a fun way to improve your typing speed and accuracy. You are able to create your own lessons and save them to cassette for further use.

1. Type CLOAD and press/ENTER/ after you see the "O.K." type RUN then press/ENTER/.
2. At this point you will be asked if you are using a cassette or disk drive. Type "T" for tape then press/ENTER/.
3. TO LOAD A RECORDED LESSON:
 - i) Select "EDIT LESSON" from the main menu (selection #4).
 - ii) Select "LOAD LESSON" from the EDIT LESSON menu (selection #1).
 - iii) Type "W" for words.
 - iv) At this time you will be prompted for the filename of the lesson you wish to load the sample word lesson, type "mainw". (be sure to use lower case letters) now press/ENTER/. Position your data tape just before the beginning of the file you wish to load. Press the play button on your cassette deck then press/ENTER/. Your lesson will now be loaded.
 - v) At this point you will be returned to the EDIT LESSON menu. Now select "MAIN MENU" (selected #6).

- vi) Choose "LESSON II, WORDS" (selection #2), followed by pressing/ENTER/.
 - vii) When you see the words appear, type as quickly and accurately as possible. If you wish to return to the Main menu just press/ESC/.
4. STORE LESSON
 - i) Select "EDIT LESSON" from the main menu.
 - ii) Select "STORE LESSON" from edit lesson menu.
 - iii) Type "W" for words or "S" for sentences.
 - iv) Type filename. Don't forget, use 5 letters for filename and they must be in lower case.

5. CREATE YOUR OWN LESSON

- i) To create your own lesson, select "EDIT LESSON" from the main menu - (selection #4).
- ii) Choose "CREATE LESSON" from the edit lesson menu (selection #2). Type "W" for words.
- iii) Type filename for the lesson you are about to create. IMPORTANT your filename must be exactly 5 letters in length and in lower case - example: "mainw". After you have typed your filename press/ENTER/.

6. GAME PLAY

- i) Choose the subject you have either just created or have loaded from cassette (selections 1,2,3). After typing the number of your selection, press /ENTER/.
- ii) When you see your words, symbols, or sentences printed, type them as quickly as possible. Be sure to press /ENTER/ after each word, symbol or sentence. And don't forget capital letters.

- iv) Now type "A" for add, in accordance with the menu at the bottom of the screen. Type your first word. You can use upper or lower case letters.
- v) Press/ENTER/after you have typed your first word. You will then be prompted to confirm your entry. If it is correct type "Y".
- vi) Type "A" and repeat this sequence if you wish to continue adding words.
- vii) When you have finished building your lesson, type "Q" to exit the "CREATE" mode.
- viii) Now select "MAIN MENU" (selection #6).

SPECTRAVIDEOTM HOME MANAGEMENT & BUSINESS PROGRAM

SD-2881



SPECTRAVIDEOTM HOME MANAGEMENT & BUSINESS PROGRAM

SD-2881

- Tips on Handling and Storage
1. Avoid touching the tape with your fingers, you may cause drop-outs or scratches.
 2. Protect your cassette from dust and damage when not in use by keeping it in its protective case.
 3. The case should be wound snugly on the cassette reels; if the tape is loose, carefully wind it on to one of the reels by gently turning one of the hubs.
 4. Keep the recorder head and pinch roller clean by regular use of a good cassette head cleaner.
 5. Avoid prolonged exposure of cassettes to excessive heat, sunlight and strong magnetic fields. Do not store near heating appliances, TV sets or similar equipment.
 6. To prevent damage to the tape, remove the tape from the top edge of the cassette.

SPECTRAVIDEO SOFTWARE AND ACCESSORIES LIMITED 90-DAY WARRANTY

SPECTRAVIDEO warrants to the original purchaser that the SPECTRAVIDEO software is free of defects in material and workmanship for a period of 90 days from the date of purchase. SPECTRAVIDEO shall repair or replace, at its option, free of charge, any software discovered to be defective within the warranty period upon receipt of the software, postage paid, with proof of date of purchase, at its Factory Service Center.

This warranty is limited to the electronic circuitry and mechanical parts originally provided by SPECTRAVIDEO and does not include any accessories. This warranty shall not be applicable and shall be void if the defect has arisen through abuse, unreasonable use, mistreatment or

neglect. This warranty is in lieu of all other express warranties and no other representation or claims of any nature shall be binding on or obligate SPECTRAVIDEO. Any implied warranties applicable to this software are limited to the 90 days period described above. In no event will SPECTRAVIDEO be liable for any special, incidental, or consequential damage resulting from possession, use or malfunction of this software.

Some states do not allow limitations on how long an implied warranty lasts and/or the exclusion or limitation of incidental or consequential damages so the above limitations and/or exclusion or limitation of liability may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state:

SPECTRAVIDEO INC.
P.O. BOX 350
PLAINVIEW, NY 11803

Copyright © 1983 by SpectraVideo International Ltd. All rights reserved

Published by
SPECTRAVIDEO INTERNATIONAL LTD.

Second Edition
First Printing 1983
Printed in Hong Kong

Every effort has been made to supply complete and accurate information in this manual.

SpectraVideo International Ltd. reserves the right to change Technical Specifications and Characteristics at any time without notice. No part of this publication may be stored in a retrieval system, transmitted, or reproduced in any way, including but not limited to photocopying, photographing, magnetic or other record, without the prior agreement and permission from SpectraVideo International Ltd.