Change R3 on detector to 200k

VR1
10k
RV097NS

J1
TILDAGON_PROTOTYPE
DIL

16 ✕	HSF	LSA 1 ✕
15 ✕	HSG	LSB 2 ✕
14	GND	SDA 3 ✕
13	3V3	SCL 4 ✕
12	3V3	DET 5
11	GND	LSC 6 ✕
10	HSH	LSD 7 ✕
9	HSI	LSE 8 ✕

1 AUDIO ✕
2 ENVEL
3 GATE ✕
4 VCC
5 GND

IC1

SPARKFUNSOUNDDETECTOR

This is the 8x2 block on the
tildagon hexpansion
prototype PCB