

N. Pilot In Command

The Pilot/Remote Control Operator in Command is at all times the final authority over the aircraft and shall be in command over all flight operations and/or related activities. The Pilot/Remote Control Operator in Command shall have the final authority to abort any flight operation in the interest of safety. Abort signals shall be specified ahead of time. In the event of a power loss, signal loss, or mechanical failure, the pilot must make every attempt to keep the safety of people and property as the highest priority. The aircraft may be crashed, or destroyed in the attempt to keep the safety of people and property. The pilot has the final authority and is responsible for the flight of the aircraft.

III. EQUIPMENT

A. Aircraft Size

Your aircraft must be of a size that is visible during flight. Orientation must be decipherable at whatever distance/altitude you fly to.

B. Use of GPS

All equipment must be equipped with GPS. GPS coordinates must be attained and verified before takeoff and used as the fail-safe return to home location in the event of signal loss or other issue. GPS systems are supplemental for flight accuracy and precise aircraft positioning. GPS is never to be used as a substitute for visibility, flight conditions, or pilot proficiency.

C. FAIL-SAFE Requirements

All aircraft systems must be programmed for fail-safe. Fail-safe is defined as the flight computer taking over in the event of a signal loss from the pilot or preset function from transmitter. Hover in place, hover-then-land, as well as return to home and land are acceptable methods of fail-safe.

D. Navigation Lighting

All FLYSAFE certified pilots must have exterior navigation lighting on their aircraft. This lighting must make the orientation decipherable for the pilot, camera operator, and spotter. The universal FLYSAFE navigation lighting is RED on the rear of the aircraft, and BLUE on the front.

E. Flight Time

All flights must be timed according to the capacity of the power system and anticipated usage. This ensures landing with safe level battery reserves of at least (1:00) minute. Before takeoff, batteries must be verified as fully charged.