



AIM: Descend in various configurations to a predetermined altitude; introduce full takeoff sequence (E8).

P E8 Takeoff: Student manages complete takeoff; instructor supervises; all turns by instructor

☐

P Climb: Student manages all climbs (Vx and Vy) to cruise altitude

☐

DP Powered descent: 4000 RPM, 90-100 kt; PAT; student practices

☐

DP Cruise descent: PAT; 5000 RPM, 105-110 kt; student practices

☐

DP Glide descent: Idle, 70 kt; trim; **clear engine every 1000 ft**; student practices

☐

DP Approach descent: 3000 RPM, flap 2, 70 kt; student practices

☐

DP Flap effect: Demo increased rate/angle; student deploys and observes

☐

P Practice: Practice all climbing and descending sequences +5/-0 kt hdg $\pm 5^\circ$. PAT/APT -> LARI

☐

D Emergency descent: Patter entry; careful attitude control to avoid spiral dive

☐

COMMON ERRORS

- **No power on level-off** -> Power **leads** – PAT; nose rises after power
- **Airspeed mismanagement** -> Set the attitude; don't chase
- **Engine cooling in glide** -> Clear every 1000 ft – build the habit now
- **Drift on climbout (E8)** -> Reference point ahead; right rudder with power

STANDARDS FOR PROGRESSION

P S **Progressing (P):** ASI ± 10 kt, hdg $\pm 10^\circ$ across ≥ 3 types; level-off ± 200 ft; E8 with light guidance
Solo (S): ASI ± 10 kt, hdg $\pm 5^\circ$ all types; level-off ± 150 ft; clears engine in glide

C NC

⚠ SAFETY Exercises **above 1000 ft AGL** · Terrain clearance during descents · Clear engine every 1000 ft in glide · Clear horizon and surface wind <25 knots