



**AIM:** Execute the ABCDEF sequence and FLWOP circuit from memory. Conduct a precautionary search.

**P** **Departure/transit:** Student as PIC; *scan for landing fields throughout every transit from this lesson onward* ☐

**D** **ABCDEF demo:** Instructor calls “engine failure”; works through full sequence aloud – A, B, C, D, E, F; FLWOP circuit to high-key then low-key; sideslip if high; go-around at 500 ft ☐

**P** **ABCDEF – first 1-2 attempts:** Instructor assists recall if needed; student works through sequence ☐

**P** **ABCDEF – subsequent attempts:** From memory; go-around at 500 ft – *never below* ☐

**P** **Precautionary search:** Student selects field; two inspection passes (1000 ft, 500 ft AGL); states landing/reject decision aloud with reasoning ☐

**P** **Return:** Student as PIC; join; land independently ☐

## ABCDEF QUICK REFERENCE

- **A – Attitude:** Best glide; trim – **first and most time-critical**
- **B – Best Field:** 6-S; aim point at **one-third**; high-key; low-key
- **C – Checks (FAST):** Fuel; Air; Switches; Throttle – after A and B only
- **D – Declare:** MAYDAY – callsign, position, problem, plan, POB; Centre preferred
- **E – Explain:** Pax brief; seatbelt tight; brace; reassure
- **F – Final:** All switches off; **flap before master if electric flaps**

## COMMON ERRORS

- **Delayed attitude** -> A is first; every second costs height
- **Checks before A and B** -> FAST only after field chosen and glide established
- **MAYDAY on CTAF** -> Centre first; CTAF if Centre not established
- **Too high on glide** -> Correct early

## STANDARDS FOR PROGRESSION

**P** **S** **Two separate flights at S required before area solo.**

**Solo (S):** A within 5 s; ABCDEF from memory; MAYDAY correct; low-key 1000 ft; field made with margin; PSL heights correct

**C** **NC**

**⚠ SAFETY** Training go-around height **minimum 500 ft AGL** – specified before flight; **never breach** · **Do not operate** such that a real engine failure would endanger the aircraft · PSL 300 ft pass: aerodrome only