



AIM: Confirm all Phase 1 elements to solo standard in a connected flight. Formally assess E8. Introduce radio procedures for circuit operations.

P E8 Assessment: Pre-takeoff brief before taxi; directional control; Vy +10/-0 kt; departure radio call ☐

P Transit and climb: Vy +10/-0 kt; level off at pre-determined altitude; active traffic awareness ☐

P S&L: Cruise and **slow** cruise – hdg $\pm 5^\circ$, alt ± 200 ft, ball centred ☐

P Vx climb: To nominated altitude; level-off APT ☐

P Powered descent: To nominated altitude; level-off PAT ☐

P HASSELL – mandatory before high-risk sequence begins ☐

P Turns (basic and advanced): up to 60° both directions; climbing and descending turns; spiral dive recognised and recovered if entered ☐

P E7 – Slow flight & stall: HASSELL complete; symptoms identified; stall and recovery executed; ≤ 300 ft ☐

P E10 – Scenario stalling: Turning stall (≤ 300 ft); go-around stall prevention; EFATO scenario ☐

P Return: All radio calls attempted; circuit entry assisted by instructor; student on flight controls ☐

COMMON ERRORS

- HASSELL omitted before E9/E10 -> NC for both elements – non-negotiable
- Incorrect radio call structure -> Callsign, position, altitude, intentions – every time
- Instructor intervening -> Assessment mode: off controls unless safety is at risk

STANDARDS FOR PROGRESSION

P S

No P standard – ALL aspects must be at Solo (S) standard before Phase 2

C NC

All at S before Phase 2: E3 hdg $\pm 5^\circ$, alt ± 150 ft · E4 Vy +10/-0, · E6 bank $\pm 5^\circ$, hdg $\pm 150^\circ$ · E7 HASSELL; recovery ≤ 300 ft · E9 $60^\circ \pm 5^\circ$ bank, ± 150 ft; correct spiral recovery · E10 turning stall ≤ 300 ft; go-around prevention; trim stall recovery · E8 brief before taxi; Vy maintained +10/-0 kt · E13 circuit calls; radio failure procedure known

⚠ SAFETY Ceiling **>3000 ft** required to include E10 · HASSELL before high-risk sequence · Assessment mode – non-interventionist but safety-ready