



AIM: Confirm E10 to S standard (student-led). Recover from unusual attitudes. Manage in-flight emergencies. Reinforce ADM (second exposure).

P Departure/transit: Student as PIC throughout

☐

DP ADM scenario: jammed control column at Vy speed; establish control in slow flight with rudder for roll control; student and instructor work through ADM procedure with student in control; conduct controllability check

☐

P E10 CHECK – Student led, instructor silent observer: HASSELL (>3000 ft ceiling required); turning stall; S&L stall and recovery; EFATO stall scenario; instructor records S or NC

☐

DP Nose-high UA: Instructor creates attitude; demo recovery – push (reduce AoA), power, roll wings level; student practises from heads-down task

☐

DP Nose-low UA: Instructor creates attitude; demo recovery – **throttle, wings level, ease back**; student practises

☐

DP Fire/smoke scenarios: Instructor calls “engine fire” or “smoke in cockpit”; student executes from memory

☐

P Return: Student as PIC; join; land independently

☐

COMMON ERRORS

- **Backpressure before wings level in nose-low** -> **Level wings first** – always; NC if incorrect
- **Fire actions delayed** -> Memory items; drill on ground before every flight with E16
- **ADM skipped for immediate action** -> “How much time?” must be asked first
- **E10 NC** -> Note in training record; continue E16; schedule remediation before L12 gate

STANDARDS FOR PROGRESSION

P S **E10 check recorded separately:** S confirmed or NC noted for remediation
E16 Solo (S): Nose-high recovery correct; nose-low recovery ≤500 ft height loss; fire actions from memory without prompting; ADM applied to novel scenarios

C NC

⚠ SAFETY Ceiling **>3000 ft AGL** (E10 requirement applies to whole lesson) · E10/E16 above 2500 ft AGL · Recoveries above 2000 ft AGL · **E10 check: instructor is observer but safety-ready; take control at first sign of incipient spin** · Nose-low: brief max airspeed before instructor intervenes