



AIM: Establish a consistent circuit pattern using go-around circuits only. Introduce BUMPFISH, radio calls, and the stable approach gate.

D Circuit 1: Instructor flies and patters – every action; gate at 300 ft assessed aloud; go-around PA(C)T; then re-join ☐

P Circuits 2-3: Student takes control; instructor assists BUMPFISH and radio while student focuses on format and height ☐

P Circuits 4+: Student assumes all BUMPFISH and radio independently; gate every approach; go-around without prompting; verbalise traffic picture every downwind ☐

STABLE APPROACH GATE – 300 FT AGL

- **Airspeed:** +5/-0 kt of target
- **Profile:** On or above – not below
- **Alignment:** Inside edge markings
- **Config:** Correct flap setting
- **If ANY not met -> go-around; no negotiation**
- Go-around: PA(C)T – power, attitude, clean-up, trim

COMMON ERRORS

- **Forgetting BUMPFISH** -> Trigger: abeam upwind threshold
- **Overriding the gate** -> It is a rule, not a suggestion
- **Losing traffic picture** -> Verbalise every downwind
- **Radio over flying** -> Attitude first; then transmit

STANDARDS FOR PROGRESSION

P S **Progressing (P):** Height ± 150 ft; BUMPFISH with reminders; go-around with minor prompting
Solo (S): Height ± 100 ft; BUMPFISH without prompting; gate every approach; go-around proactively

C NC

⚠ SAFETY Ceiling **>1500 ft AGL**. Wind **<15 kt**. Crosswind **<5 kt**. Max **30°** AoB base-to-final. Take over BUMPFISH and radio if student overloaded